

# INTERRA

*Developer of Uniqueness*

iSwitch+ KNX Room Controller

Product Manual



## Contents

|   |           |
|---|-----------|
| <b>1. Content of The Document</b> .....                                   | <b>6</b>  |
| <b>2. Product Description</b> .....                                       | <b>7</b>  |
| 2.1. Technical Information.....   | 8         |
| 2.2. Models And Variations.....   | 9         |
| 2.3. Dimensions.....  | 10        |
| 2.4. Functional Descriptions.....   | 11        |
| 2.5. Connection to The KNX Bus and Programming.....                       | 12        |
| <b>3. Mounting</b> .....  | <b>13</b> |
| <b>4. ETS Parameters</b> .....  | <b>14</b> |
| 4.1. General Page.....  | 14        |
| 4.1.1. Enable In Operation.....   | 14        |
| 4.1.2. Navigation LED.....  | 15        |
| 4.1.3. Error Identification.....  | 15        |
| 4.1.4. Parameters List.....   | 16        |
| 4.2. Push Buttons Page.....   | 18        |
| 4.2.1. Switching.....   | 18        |
| 4.2.2. Switch / Dimming.....  | 21        |
| 4.2.3. Shutter/Blinds.....  | 24        |
| 4.2.4. Value/Forced Operation.....  | 27        |
| 4.2.5. Scene Control.....   | 30        |
| 4.2.6. Mode Selection.....  | 32        |
| 4.2.7. Command Sequence.....  | 35        |
| 4.2.8. Counter.....   | 38        |
| 4.2.9. RGB Colour Control.....  | 41        |
| 4.2.10. RGBW Control.....   | 43        |
| 4.2.11. Thermostat Extension.....   | 46        |
| 4.3. External Inputs.....   | 52        |
| 4.3.2. Analog Input – Temperature.....                                    | 54        |
| 4.3.3. Analog Input – Brightness.....                                     | 56        |
| 4.3.4. Digital Input - Generic Input.....                                 | 58        |
| 4.3.5. Digital Input - Window Contact / Presence Input / Card holder..... | 60        |
| 4.4. LEDs.....  | 64        |
| 4.4.1. General.....   | 64        |
| 4.4.2. LED X.....   | 65        |
| 4.5. Measurement.....   | 68        |

|   |            |
|---|------------|
| 4.5.1. Temperature Internal.....                    | 69         |
| 4.5.2. Humidity Internal .....                      | 74         |
| 4.5.3. Air Quality Internal.....                    | 79         |
| 4.5.4. Brightness Internal .....                    | 84         |
| 4.5.5. External X .....                             | 89         |
| 4.6. Calculations .....                             | 94         |
| 4.6.1. Calculation X.....                           | 94         |
| 4.7. Room Controller Page.....                      | 98         |
| 4.7.1. Control Types Theoretical Explanations ..... | 98         |
| 4.7.2. Thermostat.....                              | 102        |
| 4.7.3. Thermostat - General .....                   | 103        |
| 4.7.4. Thermostat - Heating .....                   | 106        |
| 4.7.5. Thermostat - Cooling .....                   | 116        |
| 4.7.6. Thermostat - Heating & Cooling.....          | 125        |
| 4.7.7. Thermostat - Set Points .....                | 127        |
| 4.7.8. Thermostat – Temperature Limitation .....    | 131        |
| 4.7.9. Thermostat – Energy Saving.....              | 135        |
| 4.7.10. Thermostat – Fan Controller .....           | 142        |
| 4.7.11. Thermostat – Weekly Program.....            | 150        |
| 4.8. LCD Page .....                                 | 152        |
| 4.8.1. General .....                                | 153        |
| <b>5. ETS Objects List &amp; Descriptions .....</b> | <b>156</b> |
| 5.1. General Objects .....                          | 169        |
| 5.2. Button Objects .....                           | 170        |
| 5.3. Input Objects .....                            | 180        |
| 5.4. LED Objects .....                              | 189        |
| 5.5. Measurements Objects.....                      | 190        |
| 5.5.1. Temperature Measurement Objects .....        | 190        |
| 5.5.2. Humidity Measurement Objects.....            | 192        |
| 5.5.3. Air Quality Measurement Objects .....        | 193        |
| 5.5.4. Brightness Measurement Objects.....          | 195        |
| 5.5.5. External Measurement Objects.....            | 197        |
| 5.6. Calculation Objects.....                       | 199        |
| 5.7. Thermostat Objects.....                        | 201        |
| 5.8. LCD Objects.....                               | 211        |

Information in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets your specifications.

INTERRA MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR NONSTATUTORY, RELATED TO THE INFORMATION INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE.

Interra disclaims all liability arising from this information and its use. Use of Interra devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Interra from any damages, claims, suits, or expenses resulting from such use. No licenses are implicitly or otherwise conveyed under any Interra intellectual rights.

## Trademarks

The Interra name, logo and the Interra ITR340-XXXX Interra iSwitch+ device are registered trademarks of Interra Technology in Turkey and other countries.

All other trademarks mentioned herein are property of Interra Technology.

©2023, Interra, Printed in Turkey, All Rights Reserved.



Printed on recycled paper.

**TS EN ISO 9001:2008**

---

## TO OUR CUSTOMERS

---

One of our most important aims is to provide you with the best documentation possible to use successfully your Interra products. Focusing on this, we will keep on improving our documentation to better suit your needs. Our publications will be updated as new volumes as soon as changes are introduced.

If you have any questions or comments regarding this publication, do not hesitate to contact us:

E-Mail: [info@interra.com.tr](mailto:info@interra.com.tr)

Tel: +90 (216) 326 26 40 Fax: +90 (216) 324 25 03

### Most Current Product Manual

To obtain the most up-to-date version of this product manual, please visit our Web site at:

<http://www.interratechnology.com>

You can determine the version of an Interra document by examining its literature number found on the bottom right corner of any page.

The first two letters of the literature are the type of document. The following numbers are the document's creation date and the last letter is the version (e.g., PM181017001A is version A of a product manual created on 17/10/18).

## 1. Content of The Document

This document contains Interra's ITR340-XXXX coded iSwitch+ room controller device's electronic and all essential feature information for programming this product. In each subtitle is explained the characteristics of the device are. Modifications of the product and special change requests are only allowed in coordination with product management.

## 2. Product Description

Interra ITR340-XXXX iSwitch+, is a wall-mounting room controller for on / off switching loads, dimming of lighting devices, control of motor drives or other programmable switching and control functions. At the same time, iSwitch+ can be used as a secondary product that can act as a room probe or thermostat, as a section of the building or a room, as an electronic digital temperature controller, heating, cooling and air conditioning control and regulation. iSwitch+ room temperature controller is developed according to the KNX standard for use in house and building control systems. iSwitch+ room temperature controller thanks to integrated sensors can be used for heating, cooling and air-conditioning and regulation, and also can directly measure room temperature, air quality and relative humidity values. iSwitch+ can receive temperature, relative humidity and CO<sub>2</sub> concentration values from other bus devices via the KNX bus system. Various information can be visually displayed in iSwitch+ models with LCD, related to room controller function.

iSwitch+ is equipped with a user interface to display room air conditions and modify the desired setpoint. Depending on the air conditioning infrastructure, the end-user can determine up to 5 different fan speed values manually or automatically, working in an integrated system. iSwitch+ product range includes 16 different models, there are 6 models with LCD, and 12 models without LCD. In models with LCD, LCD is located vertically at the center area of the product between the gangs. In models without LCD (except the 6-10 button model) the center area is designed as a blank cover like the other buttons which got the same materials to provide a decorative fit. In the 6-10 button model without LCD, the center area buttons are designed with the same materials as other button covers that provide a decorative fit with 2 separate buttons. All iSwitch+ models can be programmed with only one database.

iSwitch product can be attached to the ETS database file, and the model used in the project is selected on the same file hence it is aimed to program the devices in a flexible structure, and a simple system that is not complex is presented to the implementers.

iSwitch+ is equipped with an integrated KNX bus communication module and is designed for wall installation on a flush mounting box. Several colour variations and materials of plates are available (non-flammable plastic, aluminum, stainless steel, glass and each material have colour options) which can be combined to obtain different combinations. All RAL codes, except the standard ones, can be produced by the user's request.


## 2.1. Technical Information

The following table shows the technical information of the Interra iSwitch+.

|                              |   |
|------------------------------|---|
| <b>Product Code</b>          | <b>ITR340-XXXX</b>  |
| <b>Power Supply</b>          | KNX Power Supply  |
| <b>Current Consumption</b>   | 10mA  |
| <b>Push Buttons</b>          | 2 to 10 buttons (Depending on the model)<br>1 x KNX Programming Button  |
| <b>LED Indicators</b>        | RGB LEDs for each button<br>1x Blue Navigation LED<br>1x Red Programming LED  |
| <b>Sensors</b>               | Temperature Sensor ( $\pm 0.4^{\circ}\text{C}$ acc.)<br>Humidity Sensor ( $\pm 4\%$ RH acc.)<br>Air Quality Sensor (0-500 VOC Index)<br>Brightness Sensor (Up to 1800 Lux.) |
| <b>Interfaces</b>            | VA-Type Low-Power LCD   |
| <b>Mode of Commissioning</b> | S-Mode  |
| <b>Type of Protection</b>    | IP 20   |
| <b>Temperature Range</b>     | Operation ( $-5^{\circ}\text{C}$ ... $45^{\circ}\text{C}$ )<br>Storage ( $-20^{\circ}\text{C}$ ... $60^{\circ}\text{C}$ )   |
| <b>Maximum Air Humidity</b>  | < 90 RH   |
| <b>Colour</b>                | Buttons: Depends on the models<br>Back Cover: Matte Black   |
| <b>Dimensions</b>            | 90 x 90 x 12 mm (W x H x D)   |
| <b>Configuration</b>         | Via ETS   |

## 2.2. Models And Variations

ITR340-XXXX



### Models with LCD




Fig. 1: View of 6 different models with LCD

### Models without LCD




Fig. 2: View of 10 different models without LCD

X<sub>1</sub>: 0, 1: No AQI / 2, 4: with AQI


## Materials and Colour Options

Material and colour options can be exclusively designed for special projects.

| 0<br>Plastic         | 1<br>Aluminum | 2<br>Stainless Steel | 3<br>Glass |
|----------------------|---------------|----------------------|------------|
| 1 – Black            | 0 – Natural   | 0 – Natural          | 1 – Black  |
| 2 – Glossy White     | 1 – Black     | 1 – Copper           | 2 – White  |
| 3 – Matte White      | 2 – Bronze    | 2 – Bronze           |            |
| 4 – Matte Anthracite | 3 – Gold      |                      |            |
| 5 – Metallic Gray    |               |                      |            |

**Table 1:** iSwitch+ Materials and Colours

## 2.3. Dimensions



**Fig. 3:** Dimensions of the iSwitch+

- All values given in the device dimensions are millimeters.
- All of the iSwitch+ models, with or without LCD, have got the same dimensions.


## 2.4. Functional Descriptions

The prominent features of the iSwitch+ are the followings:

- All 16 models can be programmable with only one database.
- Switching, toggle, dimming, shutter/blinds controls, predetermined scenes by users, value functions that can send presented values, 2 channels control functions, thermostat air conditioning functions, and step-switching mode features are available.
- Enhanced and extended **Sensor Measurement** functions.
- It can measure with integrated temperature, humidity, brightness and air quality (depending on the model) sensors.
- Configurable and programmable **External Inputs** as analog or digital over ETS.
- Scenes from 1 to 64 can be specified and these scenes can be implemented by request.
- Room temperature regulation can be done with 2 – Points (Hysteresis), PWM or Continuous PI control options.
- Enhanced and extended **Room Controller** functions
- Operating modes: comfort, standby, economy and building protection.
- Automatic switching between operating modes via the weekly program.
- Each LED can be configured independently from buttons.
- Enhanced and extended **LCD Screen** functions.
- Locking is available for all features.
- Ventilation control with continuous or 5 – speed regulation
- External – internal temperature, (measured, setpoint, outdoor values as °C and °F), operating mode, settings, air quality index, fan control, humidity, and on/off features are displayed on LCDs.
- **Calculation** functions that are produced the weighted sensor values for special cases.

## 2.5. Connection to The KNX Bus and Programming

The connection of the KNX bus line is made with the terminal block (black/red socket group) included in delivery and inserted into the slot of housing.



**Fig. 4:** Connection to KNX and Programming Button


To enter the programming mode, first press and hold the button in the upper left corner. While holding down the button in the upper left corner, press and release the button in the upper right corner 5 times. Then the button in the upper left corner is released and pressed again. So red programming LED turn on and the device is ready for programming.

## 3. Mounting

The iSwitch+'s mounting steps are described below.

### Mounting

The device is suitable for use in dry interior rooms and can only be mounted on a standard-sized round or square wall flush mounting box. The iSwitch+ should be mounted after the wall painting process is finished. Otherwise, the product's cosmetics may be damaged. The mounting steps are shown below.




**Fig. 5:** Mounting the to Flush Mounting Box

1. Check the mounting box, and whether is done properly
2. Insert the metal frame of the Switch+ into the wall flush mount.
3. Connect the KNX cable and other cables (optional) to respective terminals.
4. Finally, insert the iSwitch+ into the metal frame.

## 4. ETS Parameters

### 4.1. General Page

When the iSwitch+ is attached to the project from the ETS program, a configuration setting must be made primarily before loading, depending on the model to be programmed. When entering the “GENERAL” in the parameter page, the configuration screen will appear shown above. As previously mentioned, all models can be configured via an ETS file thus the programmers can work flexibly.



**Fig. 6:** General Parameter Configuration Page

According to the model of the device, the programmer can configure whether the LCD exists or not and the number of push buttons via corresponding tabs. To ensure that the models are selected correctly and also to be able to program correctly, the iSwitch+ model appears on the screen as shown above.

#### 4.1.1. Enable In Operation

This function has an important role to detect whether the device is working or not. By enabling the “Enable in operation” parameter, it is possible to know if the device is working properly. The value set in “in operation send” parameter is sent with a preset time via the “In Operation” object. If this telegram is received periodically, it shows that the device is working properly. Since the period time is in seconds, it is better to keep the period time higher in order not to increase the bus line traffic.

## 4.1.2. Navigation LED

Navigation LED is used to show a pleasant display generally in dark ambient. It can be configured via a 1-bit communication object or “always-on” and “always-off” parameter options.

## 4.1.3. Error Identification

This feature is especially for iSwitch+ model which is without LCD. The faults which are sensor faults, digit overflow of the sensor value and out of the operation range of room controller etc., can be indicated via object.

| Error Code | Cause                               |
|------------|-------------------------------------|
| E0.1       | Integrated temperature sensor fault |
| E0.2       | Integrated humidity sensor fault    |
| E0.3       | Integrated air quality sensor fault |
| E0.4       | Integrated brightness sensor fault  |
| E0.5       | External input - 1 sensor fault     |
| E0.6       | External input - 2 sensor fault     |

**Table 2:** Error Codes

| Caution Code | Cause                                     | Minimum Limit                        | Maximum Limit |
|--------------|---|--------------------------------------|---------------|
| C1.1         | Integrated temperature out of range       | -999                                 | 999           |
| C1.2         | Integrated humidity out of range          | 0                                    | 999           |
| C1.3         | Integrated air quality out of range       | 0                                    | 999           |
| C1.4         | Integrated brightness out of range        | 0                                    | 999           |
| C1.5         | External input - 1 sensor out of range    | 0 (brightness)<br>-999 (temperature) | 999           |
| C1.6         | External input - 2 sensor out of range    | 0 (brightness)<br>-999 (temperature) | 999           |
| C1.7         | Room temperature out of operational range | -60                                  | 60            |

**Table 3:** Caution Codes

- ➔ If any sensor fault is occurred, a string message is transmitted to KNX with error code. For example; if internal temperature sensor is on fault, “E0.1: True” message is sent. If error is fixed, “E0.1: False” message is sent.
- ➔ If room temperature is higher/lower than -60°C / 60°C, “E1.7: True” message is sent to indicate ambient temperature is too high/low.
- ➔ On measurement channel, internal and external sensor measurements are made. If sensor’s output values are out of range as the table, related error code is sent over KNX bus.

## 4.1.4. Parameters List

| PARAMETERS                                     | DESCRIPTION   | VALUES  |
|--|---|---|
| <b>Device type</b>                             | This parameter determines the device type.  | ITR340-0XXX<br><b>ITR340-1XXX</b><br>ITR340-2XXX<br>ITR340-3XXX   |
| <b>Button count</b>                            | This parameter determines the number of push buttons depending on the models.   | 2 Button<br><b>4 Button</b><br>6 Button<br>8 Button<br>10 Button  |
| <b>Delay time after voltage recovery (sec)</b> | This parameter is used to determine the delay time after voltage recovery in seconds. When in a delayed state, the iSwitch+ does not send any KNX telegrams. Incoming telegrams are received and updated in the background. The updated values are only executed when the wait state ends and then sent according to the parametrization. | 1...60  |
| <b>Maximum number of consecutive telegrams</b> | This parameter is used to set the maximum number of sent telegrams by the device in the given time period.  | 0...255   |
| <b>Telegram period<sup>1</sup></b>             | This parameter is used to determine the total period time of maximum number of consecutive telegrams.<br><br>For example; "Maximum number of consecutive telegrams" is set 5 and "Telegram period" is set to 500ms. This means that maximum 5 telegrams can be sent along 500ms.  | 50ms<br><b>100ms</b><br>200ms<br>500ms<br>1 s<br>2 s<br>3 s<br>5 s<br>10 s<br>30 s<br>1 min<br>2 min<br>3 min<br>4 min<br>5 min<br>10 min |

|  |   |  |
|--|---|--|
| <p><b>Enable in operation</b></p>                                | <p>This parameter is used to determine the existence of the iSwitch+ on the KNX bus line. The cyclic telegram can be monitored by an external KNX device. If a telegram is not received, the device may be defective or the KNX cable to the transmitting device may be interrupted.</p> <p><b>No:</b> The group object is not enabled.</p> <p><b>Yes:</b> The group object is enabled.</p>   | <p><b>No</b></p> <p>Yes</p>  |
| <p><b>-&gt; In operation send<sup>1</sup></b></p>                | <p>This parameter is used to determine the send value of the “General - In operation” group object on the KNX bus line.</p>   | <p><b>Alive value 0</b></p> <p>Alive value 1</p>                             |
| <p><b>-&gt; In operation send interval (min)<sup>1</sup></b></p> | <p>This parameter is used to set the cyclically sending time interval value of the “General - In operation” group object.</p>   | <p>1...<b>5</b>...255</p>  |
| <p><b>Navigation LED</b></p>                                     | <p>There is a navigation LED under the device. This parameter is used to control the determined LED.</p> <p><b>Always off:</b> Navigation LED is permanently off.</p> <p><b>Always on:</b> Navigation LED is permanently on.</p> <p><b>Via communication object:</b> When this parameter is selected, the navigation LED’s control will be done with the “LEDs Intensity” object that will be opened in the device object list.</p> | <p><b>Always off</b></p> <p>Always on</p> <p>Via communication object</p>    |
| <p><b>-&gt; Brightness<sup>2</sup></b></p>                       | <p>This parameter, allows you to set the LEDs’ in per cent over the ETS parameter.</p>  | <p><b>auto</b> (auto, 10%, 20%, 30%, 40%, 50%, 60%, 70%, 80%, 90%, 100%)</p> |
| <p><b>Error identification object</b></p>                        | <p>This parameter is used to send an error message to indicate the error type if an error occurs. If it is selected “Yes”, the “General – Error Identification” group object is visible.</p>  | <p><b>No</b></p> <p>Yes</p>  |

<sup>1</sup> This parameter is only visible when the function “Enable in operation” at the GENERAL parameter page is set to “Yes”.

<sup>2</sup> This parameter is only visible when the function “Navigation LED” at the GENERAL parameter page is set to “Always on” or “Via comm object”.

## 4.2. Push Buttons Page

### 4.2.1. Switching

This function is used to perform the switching operation. Depending on the settings configured in the switching process, when the button is pressed or released, the ON or OFF values are generated. After each operation, a telegram is sent to the KNX bus line. Telegram is generated based on the configured settings.

If you want to configure the push button with the “switching” function, choose it from the parameter page and then a new object will appear under the device object list on the left side. This object’s name is “switching”. General configurations are made via this object. When the “switching” function is enabled, it is added to the object list of the device. After assigning the group address to this object, attention should be paid to the type of data it uses. It is a good technique to use default data types.




Fig. 7: Switching Function Configuration

## 4.2.1.1. Parameters List

| PARAMETERS  | DESCRIPTION   | VALUES   |
|---|---|--|
| <b>Button name</b>                                  | This parameter is used to type a button name. The name can be consisting of 40 characters.  | <b>40 Bytes allowed</b>  |
| <b>Button function</b>                              | This parameter is used to determine the button function. If no function is selected, Button X will not be used. For other choices, all functionalities are configured separately. | No function<br><b>Switch</b><br>Switch/dimming<br>Shutter/blinds<br>Value / forced operation<br>Scene control<br>Mode selection<br>Command sequence<br>Counter<br>RGB colour control<br>RGBW control<br>Thermostat Extension |
| <b>Distinction between long and short press: No</b> |   |  |
| <b>Cyclic sending of object "Switch"</b>            | This parameter is used to periodically send the commands to the bus line.   | <b>No</b><br>If "Switch" = ON<br>If "Switch" = OFF<br>Always   |
| <b>-&gt; Telegram repeated every<sup>1</sup></b>    | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams                        | 00:00:01... <b>00:08:20</b> ...<br>18:12:15  |
| <b>Reaction on pressing button</b>                  | This parameter is visible if there is a distinction between pressing and releasing operations. It is used to determine the pressing operation sending the value of the Button X.  | No reaction<br>On<br>Off<br><b>Toggle</b>  |
| <b>Reaction on releasing button</b>                 | This parameter is visible if there is a distinction between pressing and releasing operations. It is used to determine the releasing operation sending the value of the Button X. | <b>No reaction</b><br>On<br>Off<br>Toggle  |

|  |   |  |
|--|---|--|
| <b>Send button value after bus voltage recovery</b>  | This parameter is used to determine the sending value of the inputs when the bus voltage has been recovered.  | <b>No</b><br>Yes   |
| <b>Distinction between long and short press: Yes</b> |   |  |
| <b>Cyclic sending of object "Switch"</b>             | This parameter is used to periodically send the commands to the bus line.   | <b>No</b><br>If "Switch" = ON<br>If "Switch" = OFF<br>Always |
| <b>Reaction on short press</b>                       | This parameter is visible if there is a distinction between short and long operations. It is used to determine the short press operation sending the value of the Button X.   | <b>No reaction</b><br>On<br>Off<br>Toggle                    |
| <b>Reaction on long press</b>                        | This parameter is visible if there is a distinction between short and long operations. It is used to determine the long press operation sending the value of the Button X.  | <b>No reaction</b><br>On<br>Off<br>Toggle                    |
| <b>Long press after</b>                              | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value.   | 00:00.200... <b>00:00.500</b><br>...01:05.535                |
| <b>Number of object for short/long press</b>         | This parameter is used to determine the object count to use for short and long operations.<br><br><b>1 object:</b> short and long operations will proceed with the same object.<br><br><b>2 objects:</b> short and long operations will proceed with 2 different objects. | <b>1 object</b><br>2 objects                                 |

\*1 This parameter is only visible when the parameter "Cyclic sending of object "Switch" is set to "If "Switch" = ON" or "If "Switch" = OFF" or "Always".

### 4.2.2. Switch / Dimming

This feature enables increasing or decreasing of lighting circuit’s lighting level. There is 2 functionality such as “only dimming” and “dimming and switching”. Also, each functionality has 2 dimming mode such as “start/stop dimming” and “step dimming”.




Fig. 8: Switch/Dimming Function Configuration

If the “Only dimming” function is enabled, dimming control is done via only a group object on press operation. If the “Dimming and switching” function is enabled, also another group object is available for switching function on short press operation and another group object is available for dimming function on long press operation. In start/stop dimming mode, if the button is pressed, the dimming value (4-bit) is sent via the “dimming” object. If the button is released, the “stop” telegram is sent to the bus line and dimming control is over. In step dimming mode, if the button is pressed, the dimming value (4-bit) is sent step by step via the “dimming” object. The step value is determined via the “Brightness change on every sent” parameter. Each step is sent cyclically according to “Sending cycle time: Telegram is repeated every” parameter.

## 4.2.2.1. Parameters List

| PARAMETERS   | DESCRIPTIONS  | VALUES   |
|--|---|--|
| <b>Button name</b>   | This parameter is used to type an input name. The name can be consisting of 40 characters.  | <b>40 Bytes allowed</b>  |
| <b>Button function</b>                                     | This parameter is used to determine the input x operation mode. If no function is selected, Button X will not be used. For other choices, all functionalities are configured separately.  | No function<br><b>Switch</b><br>Switch/dimming<br>Shutter/blinds<br>Value/forced operation<br>Scene control<br>Mode selection<br>Command sequence<br>Counter<br>RGB colour control<br>RGBW control<br>Thermostat Extension |
| <b>Dimming functionality</b>                               | This parameter is used to define if the lighting can only be dimmed “Only dimming” or if additional switching is also permitted “Dimming and switching”. In this case, a long button presses dims and a short button pushes switches. | <b>Only dimming</b><br>Dimming and switching   |
| <b>-&gt; Reaction on press<sup>1</sup></b>                 | A distinction is not made between short and long operations here. It is used to determine the press operation sending the value of the Button X.  | Dim brighter<br>Dim darker<br><b>Dimming brighter/darker</b>   |
| <b>-&gt; Reaction on short press<sup>2</sup></b>           | This parameter is visible if there is a distinction between short and long operations. It is used to determine the short press operation sending the value of the Button X.   | <b>No reaction</b><br>On<br>Off<br>Toggle  |
| <b>-&gt; Reaction on long press<sup>2</sup></b>            | This parameter is visible if there is a distinction between short and long operations. It is used to determine the long press operation sending the value of the Button X.  | Dim brighter<br>Dim darker<br><b>Dimming brighter/darker</b>   |
| <b>-&gt; Dimming direction after switch ON<sup>3</sup></b> | This parameter is used to determine the dimming direction when the switch object is ON on long operation.   | <b>Brighter</b><br>Darker  |
| <b>-&gt; Long press after<sup>2</sup></b>                  | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value.   | 00:00.200... <b>00:00.500</b><br>... 01:05.535   |

|  |   |   |
|--|---|---|
| <p><b>Dimming mode</b></p>   | <p>This parameter is used to determine the dimming mode. Normal “Start-stop-dimming” starts the dimming process with a telegram BRIGHTER or DARKER and ends the dimming process with a STOP telegram. Cyclic sending of the telegram is not necessary in this case. With “Step dimming”, the dimming telegram is sent cyclically during a long operation. The STOP telegram ends the dimming process at the end of the operation.</p> | <p><b>Start stop dimming</b><br/>Step dimming</p>   |
| <p>-&gt; <b>Brightness change on every sent telegram<sup>4</sup></b></p>       | <p>This parameter is set to change the brightness (in per cent), which is cyclically sent with every dimming telegram.</p>  | <p>100%<br/>50%<br/><b>25%</b><br/>12.5%<br/>6.25%<br/>3.125%<br/>1.563%</p>  |
| <p>-&gt; <b>Sending cycle time: Telegram is repeated every<sup>4</sup></b></p> | <p>This parameter is used to determine the sending cycle time. The dimming telegram is sent cyclically during a long operation if “Dimming steps” are set. The cycle time for sending corresponds with the time interval between two telegrams during cyclical sending.</p>   | <p>0.3s<br/>0.4s<br/><b>0.5s</b><br/>0.6s<br/>0.8s<br/>1s<br/>1.2s<br/>1.5s<br/>2s<br/>3s<br/>4s<br/>5s<br/>6s<br/>7s<br/>8s<br/>9s<br/>10s</p> |

<sup>\*1</sup> This parameter is only visible when the parameter “Dimming functionality” is set to “Only dimming”.

<sup>\*2</sup> This parameter is only visible when the parameter “Dimming functionality” is set to “Dimming and switching”.

<sup>\*3</sup> This parameter is only visible when the parameter “Reaction on long press” is set to “dimming brighter/darker”.

<sup>\*4</sup> This parameter is only visible when the parameter “Dimming mode” is set to “Step dimming”.

### 4.2.3. Shutter/Blinds

A shutter/blinds circuit can be controlled up-down or on-off methods with a “slat angle/stop” object courtesy of this feature. Each function has 2 different “up / down” and “slat angle/stop” objects. At the control of the shutter/blinds circuit, a short press of the button sends a “step movement” telegram and a long press of the button sends a “nonstop movement” telegram to the bus line. A shutter/blinds circuit is controlled by “1 button toggle” or “2 buttons up/down” control modes.




Fig. 9: Shutter/blinds Function Configuration

**Shutter/blinds circuit control with 1 button;** Push up, pull down and stop controls can be done with 1 push button. At every time of short press, the push button will send the following sequential values in the form of; down movement, stop, up movement and stop. The movement aspect of the shutter or slat angle adjustment aspect always depends on the previous action. There is a push-button status object to prevent sending wrong commands to the bus line and the current values of the object can be updated by the devices at the same KNX bus line. This object must be connected to the actuator’s status parameter via a related group address.

**Shutter/blinds circuit control with 2 buttons;** 2 buttons must be used for this option. If both buttons are configured, with long press action the shutter can be moved up or down and with short press action, the movement stops or slat angle step movement can be configured. The minimum time to detect the long press action is configured via a parameter. Every command controls the buttons defined as “Up” or “Down” via the “Direction” parameter. When short pressed to the button configured as “up”, it sends an “up” value to the bus line, and when short pressed to the button configured as “down”, it sends a “down” value to the bus line.

## 4.2.3.1. Parameters List

| PARAMETERS  | DESCRIPTION   | VALUES   |
|---|---|--|
| <b>Button name</b>                                    | This parameter is used to type an input name. The name can be consisting of 40 characters.  | <b>40 Bytes allowed</b>  |
| <b>Button function</b>                                | This parameter is used to determine the input x operation mode. If no function is selected, the input x will not be used. For other choices, all functionalities are configured separately. | No function<br>Switch<br>Switch/dimming<br><b>Shutter/blinds</b><br>Value/forced operation<br>Scene control<br>Mode selection<br>Command sequence<br>Counter<br>RGB colour control<br>RGBW control<br>Thermostat Extension   |
| <b>Operating functionality of blind</b>               | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value.     | 1-push button, short = stepping, long = moving <sup>1</sup><br>1-push button, short = moving, long = stepping <sup>2</sup><br>1-push button operation <sup>3</sup><br>1-switch button operation<br>2-push button, standard <sup>5</sup><br>2-switch operation, moving <sup>6</sup><br>2-push button operation, moving <sup>7</sup><br>2-push button operation, stepping <sup>8</sup> |
| <b>1-push button, short = stepping, long = moving</b> |   |  |
| <b>Long operation after</b>                           | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value.     | 0,3s, 0,4s, <b>0.5s</b> , 0.6s, 0.8s, 1.0s, 1.2s, 1.5s, 2s, 3s, 4s, 5s, 6s, 7s, 8s, 9s, 10s  |
| <b>1-push button, short = moving, long = stepping</b> |   |  |
| <b>Long operation after</b>                           | This parameter is used to determine long operation detection after the button press operation. For  | 0,3s, 0,4s, <b>0.5s</b> , 0.6s, 0.8s, 1.0s, 1.2s, 1.5s,  |

|  |   |   |
|--|---|---|
|  | making a long operation, the button should be pressed at least the configured value.  | 2s, 3s, 4s, 5s, 6s, 7s, 8s, 9s, 10s   |
| <b>“STOP/lamella adj,” is repeated every</b> | This parameter is used to determine the time between two telegrams is set. This parameter is visible in operations in which the object “STOP/lamella adjustment” is sent cyclically on the bus during a long operation. | 0,3s, 0,4s, <b>0.5s</b> , 0.6s, 0.8s, 1.0s, 1.2s, 1.5s, 2s, 3s, 4s, 5s, 6s, 7s, 8s, 9s, 10s |
| <b>2-push button operation, standard</b>     |   |   |
| <b>Reaction on short operation</b>           | This parameter is used to determine the reaction when an operation occurs. A distinction is not made between short and long operations here.  | <b>Stop/lamella up</b><br>Stop/lamella down   |
| <b>Reaction on long operation</b>            | This parameter is visible if there is a distinction between short and long operations. It is used to determine the long press operation sending the value of the Button X.  | <b>Move up</b><br>Move down   |
| <b>Long operation after</b>                  | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value.                                 | 0,3s, 0,4s, <b>0.5s</b> , 0.6s, 0.8s, 1.0s, 1.2s, 1.5s, 2s, 3s, 4s, 5s, 6s, 7s, 8s, 9s, 10s |
| <b>2-switch operation, moving</b>            |   |   |
| <b>Reaction on press</b>                     | It is used to determine the press operation sending the value of the Button X.  | <b>Move up</b><br>Move down   |
| <b>2-push button operation, moving</b>       |   |   |
| <b>Reaction on press</b>                     | It is used to determine the press operation sending the value of the Button X.  | <b>Move up</b><br>Move down   |
| <b>2-push button operation, stepping</b>     |   |   |
| <b>Reaction on press</b>                     | It is used to determine the press operation sending the value of the Button X.  | <b>Stop/lamella up</b><br>Stop/lamella down   |

\*1 Short operation: Lamella, Long operation: Move UP / DOWN

\*2 Short operation: Move UP/DOWN, Long operation: Lamella

\*3 On every operation in succession: UP – DOWN – STOP

\*4 On operation: UP / DOWN, End of operation: STOP

\*5 Short operation: STOP – Lamella UP / DOWN, Long operation: Move UP / DOWN

\*6 On operation: Moving End of operation: STOP

\*7 On operation: Moving

\*8 On operation: Stepping

### 4.2.4. Value/Forced Operation

In this section, it is explained how to control an automation unit via iSwitch+ via a value/forced via buttons connected to digital inputs. Detailed information on the relevant parameter configurations is described in the table below.




Fig. 10: Value/Forced Operation Function Configuration

## 4.2.4.1. Parameters List

| PARAMETERS                                      | DESCRIPTION   | VALUES   |
|---|---|--|
| <b>Button name</b>                              | This parameter is used to type an input name. The name can be consisting of 40 characters.  | <b>40 Bytes allowed</b>  |
| <b>Button function</b>                          | This parameter is used to determine the Button X operation mode. If no function is selected, Button X will not be used. For other choices, all functionalities are configured separately.   | No function<br>Switch<br>Switch/dimming<br>Shutter/blinds<br><b>Value/forced operation</b><br>Scene control<br>Mode selection<br>Command sequence<br>Counter<br>RGB colour control<br>RGBW control<br>Thermostat Extension |
| <b>Distinction between long and short press</b> | This parameter is used to set if the input differentiates between short and long operations. With the option “yes”, after opening/closing of the contract, it must, first of all, be ascertained if a short or long operation has occurred here. Only thereafter will a possible reaction be triggered. | <b>No</b><br>Yes   |
| <b>-&gt; Long press after<sup>1</sup></b>       | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value.   | 00:00.200... <b>00:00.500</b><br>... 01:05.535   |
| <b>-&gt; Reaction on long press<sup>1</sup></b> | This parameter is visible if there is a distinction between short and long operations. It is used to determine the long press operation sending the value of the Button X.  | <b>2-bit DPT 2.001 Switch Control</b><br>1 Byte DPT 5.001 Percent (0...100%)<br>1 Byte DPT 5.005 Decimal factor(0...255)<br>1 Byte DPT 17.001 Scene number   |

|                                     |   |   |
|-------------------------------------|---|---|
|                                     |   | <p>2 Byte DPT 7.600<br/>Colour temperature<br/>(Kelvin)</p> <p>2 Byte DPT 9.001<br/>Temperature (°C)</p> <p>2 Byte DPT 9.004<br/>Brightness (lux)</p> <p>3-Byte DPT 232.600<br/>RGB value 3x(0...255)</p>   |
| <b>-&gt; Sent Value<sup>1</sup></b> | This parameter is used to determine the sending value to the bus when a long operation occurs.  | Values depend on DPT selection.   |
| <b>Reaction on press</b>            | This parameter is visible if there is a distinction between short and long operations. It is used to determine the short press operation sending the value of the Button X. | <p><b>2 – bit DPT 2.001<br/>Switch Control</b></p> <p>1Byte DPT 5.001<br/>Percent (0...100%)</p> <p>1Byte DPT 5.005<br/>Decimal factor<br/>(0...255)</p> <p>1Byte DPT 17.001<br/>Scene number</p> <p>2Byte DPT 7.600<br/>Colour temperature<br/>(Kelvin)</p> <p>2Byte DPT 9.001<br/>Temperature (°C)</p> <p>2Byte DPT 9.004<br/>Brightness (lux)</p> <p>3-Byte DPT 232.600<br/>RGB value 3x (0...255)</p> |
| <b>Sent Value</b>                   | This parameter is used to determine the sending value to the bus when a short operation occurs.   | Values depend on DPT selection.   |

<sup>1</sup>This parameter is only visible when the parameter “Distinction between long and short press” is set to “Yes”.

### 4.2.5. Scene Control

The scene function is used to control devices and make pre-registration of their status with the push button which sends a command via a related group address. This feature allows one to register a setting as a scene and after a while, when the same settings or conditions are requested, each device can be activated only with 1 command instead of configuring them separately.




Fig. 11: Scene Control Function Configuration

This feature in the button sends telegrams that contain “scene run” or “scene register” functions, via the “scene” object. Scene numbers between 1 and 64 can be selected via the related group address. The scene number configured in the button must match the scene number configured on the parameters in other devices. Scene number (1 – 64) is used to run the scene using the related object. The values sent via related object must be as in the form “Scene Number + 128” for storing the scene feature.



If a scenario number is configured as 2 and it is wished to register this scenario, a value of 130 should be sent (128 + 2). If the scenario number is configured as 24, the value of 152 (128 + 24) should be sent for the scenario registering feature.

To run every scene, a time-delayed is defined or not in the parameters should be checked, whether to send with or without time delay. This feature allows the creation of dynamic scene arrays in which several outputs connect with time delay.



After programming with ETS, scene values that are used for parameterization will be written to the actuator. This means related scenes will be erased and defined by the customer. Hence, before any maintenance, all configurations should be gotten by the programmer and whether the customer wants to use the same conditions.

## 4.2.5.1. Parameters List

| PARAMETERS                                | DESCRIPTION  | VALUES   |
|---|--|--|
| <b>Button Name</b>                        | This parameter is used to type an input name. The name can be consisting of 40 characters  | <b>40 Bytes allowed</b>  |
| <b>Button Function</b>                    | This parameter is used to determine the Button X operation mode. If no function is selected, Button X will not be used. For other choices, all functionalities are configured separately.  | No function<br>Switch<br>Switch/dimming<br>Shutter/blinds<br>Value/forced operation<br><b>Scene control</b><br>Mode selection<br>Command sequence<br>Counter<br>RGB colour control<br>RGBW control<br>Thermostat Extension |
| <b>Scene number</b>                       | This parameter is used to give the scenario number to the generated scenario before.   | <b>Scene no: 1 ... 64</b>  |
| <b>Recall scene</b>                       | This parameter is used to determine the recall of the scene. If this parameter is selected as "recall enabled" the configured scene number will be called.   | Recall disabled<br><b>Recall enabled</b>   |
| <b>Store scene</b>                        | This parameter is used to determine whether to store or not store the related scene.<br><b>On long operation:</b> The scene will be stored after a long operation.<br><b>With "Store scene" obj. value = 1:</b> The scene will be stored on operation if the Store scene object value is 1.<br><b>On long operation ("Store scene" obj. value = 1):</b> The scene will be stored on long operation if the Store scene object is 1. | <b>Do not store</b><br>On long operation<br>With "store scene" obj value = 1<br>On long operation ("store scene" obj value = 1)  |
| <b>-&gt; Long press after<sup>1</sup></b> | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value.  | 00:00.200... <b>00:00.500</b><br>... 01:05.535   |

<sup>1</sup>This parameter is only visible when the parameter "Long press after" is set to "On long operation" or "On long operation ("store scene" obj value = 1)".

### 4.2.6. Mode Selection

This section, it is explained how to control the operating modes of an HVAC unit via the buttons connected to the iSwitch+. Detailed information on the relevant parameter configurations is described in the table below.




Fig. 12: Mode Selection Function Configuration

## 4.2.6.1. Parameters List

| PARAMETERS  | DESCRIPTION   | VALUES   |
|---|---|--|
| <b>Button Name</b>                                | This parameter is used to type an input name. The name can be consisting of 40 characters   | <b>40 Bytes allowed</b>  |
| <b>Button Function</b>                            | This parameter is used to determine the Button X operation mode. If no function is selected, Button X will not be used. For other choices, all functionalities are configured separately.   | No function<br>Switch<br>Switch/dimming<br>Shutter/blinds<br>Value/forced operation<br>Scene control<br><b>Mode selection</b><br>Command sequence<br>Counter<br>RGB colour control<br>RGBW control<br>Thermostat Extension |
| <b>Distinction between long and short press</b>   | This parameter is used to set if the input differentiates between short and long operations. With the option “yes”, after opening/closing of the contract, it must, first of all, be ascertained if a short or long operation has occurred here. Only thereafter will a possible reaction be triggered. | <b>No</b><br>Yes   |
| <b>-&gt; Switching on press<sup>1</sup></b>       | A distinction is not made between short and long operations here. It is used to determine the press operation sending the value of the Button X.  | <b>Comfort / standby</b><br>Comfort / economy<br>Comfort / standby / economy<br>Comfort / standby / economy / protection   |
| <b>-&gt; Switching on short press<sup>2</sup></b> | This parameter is visible if there is a distinction between short and long operations. It is used to determine the short press operation sending the value of the Button X.   | <b>Comfort / standby</b><br>Comfort / economy<br>Comfort / standby / economy<br>Comfort / standby / economy / protection   |
| <b>-&gt; Reaction on long press<sup>2</sup></b>   | This parameter is visible if there is a distinction between short and long operations. It is used to determine the long press operation sending the value of the Button X.  | <b>Comfort</b><br>Standby<br>Economy<br>Protection   |

|  |  |  |
|--|--|--|
| <p>-&gt; Long press after<sup>2</sup></p>                | <p>This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value.</p>   | <p>00:00.200... <b>00:00.500</b><br/>... 01:05.535</p> |
| <p>Switchover considers<br/>"State HVAC-Mode" object</p> | <p>This parameter is used to enable the HVAC-Mode state object to change the current HVAC mode via KNX. If this parameter is selected as "Yes", the new value is sent according to feedback object's value. If feedback object doesn't update, the new value doesn't change.</p> | <p><b>No</b><br/>Yes</p>                               |

<sup>\*1</sup> This parameter is only visible when the parameter "Distinction between long and short press" is set to "No".

<sup>\*2</sup> This parameter is only visible when the parameter "Distinction between long and short press" is set to "Yes".

### 4.2.7. Command Sequence

In this section, it is explained how the command sequence function works. Up to 4 commands are attainable with either 1-bit, 1-byte (percentage) or 1-byte (0..255) objects. Each press event toggles through the used commands (Object A, B, C, D) via the assigned buttons. Detailed information on the relevant parameter configurations is described in the table below.




Fig. 13: Command Sequence Function Configuration

## 4.2.7.1. Parameters List

| PARAMETERS                                      | DESCRIPTION   | VALUES   |
|---|---|--|
| <b>Button name</b>                              | This parameter is used to type an input name. The name can be consisting of 40 characters   | <b>40 Bytes allowed</b>  |
| <b>Button function</b>                          | This parameter is used to determine the Button X operation mode. If no function is selected, Button X will not be used. For other choices, all functionalities are configured separately.   | No function<br>Switch<br>Switch/dimming<br>Shutter/blinds<br>Value/forced operation<br>Scene control<br>Mode selection<br><b>Command sequence</b><br>Counter<br>RGB colour control<br>RGBW control<br>Thermostat Extension |
| <b>Distinction between long and short press</b> | This parameter is used to set if the input differentiates between short and long operations. With the option “yes”, after opening/closing of the contract, it must, first of all, be ascertained if a short or long operation has occurred here. Only thereafter will a possible reaction be triggered. | <b>No</b><br>Yes   |
| <b>-&gt; Long press after<sup>1</sup></b>       | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value.   | 00:00.200... 00:00.500<br>... 01:05.535  |
| <b>Delay between commands</b>                   | This parameter is used to determine the delay between sending the value of the sequence   | 00:00.000...00:20.000  |
| <b>Use single object?</b>                       | This parameter decides whether each sequence is sent to a single object or multiple objects.  | <b>No</b><br>Yes   |
| <b>-&gt; Use “object X”<sup>2</sup></b>         | This parameter is used to enable each command object when they are set to yes.  | <b>No</b><br>Yes   |
| <b>-&gt; Data type<sup>2</sup></b>              | This parameter is used to determine the sending data type to the bus when an operation occurs.  | 1 bit<br>1 byte (0...255)<br>1 byte (0...100%)<br>HVAC mode  |

|  |  |   |
|--|--|---|
| -> Value 'X' <sup>2</sup>                | This parameter is used to determine the sending value to the bus when a short operation occurs.  | Values depend on DPT selection.                             |
| -> Value 'X' for long press <sup>3</sup> | This parameter is used to determine the sending value to the bus when a long operation occurs.   | Values depend on DPT selection.                             |
| -> Value amount <sup>4</sup>             | This parameter is used to determine the debounce time. Debouncing prevents unwanted multiple operations of the button, e.g., due to bouncing of the contact. | 2<br>3<br>4   |
| -> Data type <sup>4</sup>                | This parameter is used to determine the sending value to the bus when a short operation occurs.  | 1 bit<br>1 byte (0...255)<br>1 byte (0...100%)<br>HVAC mode |
| -> Value 'X' <sup>4</sup>                | This parameter is used to determine the sending value to the bus when a short operation occurs.  | Values depend on DPT selection.                             |
| -> Value 'X' for long press <sup>5</sup> | This parameter is used to determine the sending value to the bus when a long operation occurs.   | Values depend on DPT selection.                             |

<sup>1</sup> This parameter is only visible when the parameter “Distinction between long and short press” is set to “Yes”.

<sup>2</sup> This parameter is only visible when the parameter “Use single object?” is set to “No”.

<sup>3</sup> This parameter is only visible when the parameter “Distinction between long and short press” is set to “Yes” and the parameter “Use single object?” is set to “No”.

<sup>4</sup> This parameter is only visible when the parameter “Use single object?” is set to “Yes”.

<sup>5</sup> This parameter is only visible when the parameters “Distinction between long and short press” and “Use single object?” are set to “Yes”.

### 4.2.8. Counter

In this section, it is explained how to count input pulses on the iSwitch+. Detailed information on the relevant parameter configurations is described in the table below.




Fig. 14: Counter Function Configuration

## 4.2.8.1. Parameters List

| PARAMETERS  | DESCRIPTION   | VALUES   |
|---|---|--|
| <b>Button name</b>                                      | This parameter is used to type a button name. The name can be consisting of 40 characters.  | <b>40 Bytes allowed</b>  |
| <b>Button function</b>                                  | This parameter is used to determine the button function. If no function is selected, Button X will not be used. For other choices, all functionalities are configured separately.       | No function<br>Switch<br>Switch/dimming<br>Shutter/blinds<br>Value/forced operation<br>Scene control<br>Mode selection<br>Command sequence<br><b>Counter</b><br>RGB colour control<br>RGBW control<br>Thermostat Extension |
| <b>Counter increase on</b>                              | This parameter is used to set how the input pulse is to be generated.   | <b>Only when pressed</b><br>Only when released<br>Both when pressed and released   |
| <b>Change by</b>  | This parameter is used to assign the changing size when a press event occurs.   | 1..255   |
| <b>Counter size</b>                                     | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value. | <b>1 byte</b><br>2 bytes<br>4 bytes  |
| <b>Start value</b>                                      | This parameter is used to set the initial value of the counter after a reset or failure.  | Values depend on DPT selection.  |
| <b>End value</b>  | This parameter is used to set the end value of the counter.   | Values depend on DPT selection.  |
| <b>Enable cyclic transmission of counter</b>            | This parameter is used to determine if the counter value is sent cyclically on the bus.   | <b>No</b><br>Yes   |
| <b>-&gt; Repeated transmit cycle period<sup>1</sup></b> | This parameter is used to determine the sending value to the bus when a short operation occurs.   | 00:00.200... <b>00:00.500</b><br>...01:05.535  |

|   |   |   |
|---|---|---|
| -> Wait button trigger after reset <sup>1</sup> | This parameter is used to set startup behavior of periodic sending of counter value.<br><br>*Counter value starts from “Start value” parameter after reset.             | <b>No</b><br><br>Yes                          |
| Overflow telegram length                        | This parameter is used to set the length of the overflow telegram which will be sent to the bus when the counter value exceeds the end value set in the parameter list. | <b>No telegram</b><br><br>1 bit<br><br>1 byte |
| -> Overflow telegram value <sup>2</sup>         | This parameter is used to determine the sending value to the bus when a short operation occurs.   | Values depend on DPT selection.               |

<sup>1</sup>This parameter is only visible when the parameter “Enable cyclic transmission of counter” is set to “Yes”.

<sup>2</sup>This parameter is only visible when the parameter “Overflow telegram length” is set to “1 bit” or “1 byte”.

### 4.2.9. RGB Colour Control

This section, it is explained how to control an RGB LED device through the buttons connected to the iSwitch+. Detailed information on the relevant parameter configurations is described in the table below.




Fig. 15: RGB Colour Control Function Configuration

## 4.2.9.1. Parameters List

| PARAMETER                                 | DESCRIPTION   | VALUES   |
|---|---|--|
| <b>Button name</b>                        | This parameter is used to type a button name. The name can be consisting of 40 characters.  | <b>40 Bytes allowed</b>  |
| <b>Button Function</b>                    | This parameter is used to determine the button function. If no function is selected, Button X will not be used. For other choices, all functionalities are configured separately.       | No function<br>Switch<br>Switch/dimming<br>Shutter/blinds<br>Value/forced operation<br>Scene control<br>Mode selection<br>Command sequence<br>Counter<br><b>RGB colour control</b><br>RGBW control<br>Thermostat Extension |
| <b>Set colour value</b>                   | This parameter is used to set RGB colours according to the configured values.   | <b>Red</b><br>Orange<br>Yellow<br>Green-yellow<br>Green<br>Green-cyan<br>Cyan<br>Blue-cyan<br>Blue<br>Blue-magenta<br>Magenta<br>Red-magenta<br>White  |
| <b>Change colour with long press</b>      | This parameter is used to enable or disable the colour changing with long press operation.  | <b>No</b><br>Yes   |
| <b>-&gt; Long press after<sup>1</sup></b> | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value. | 00:00.200... <b>00:00.500</b><br>...01:05.535  |
| <b>Object type</b>                        | This parameter is used to determine the RGB colour object value.  | <b>common</b><br>separated   |

<sup>1</sup>This parameter is only visible when the parameter "Change colour with long press" is set to "Yes".

### 4.2.10. RGBW Control

This section, it is explained how to control an RGBW device through the buttons connected to the iSwitch+. Detailed information on the relevant parameter configurations is described in the table below.




Fig. 16: RGBW Control Configuration Page

## 4.2.10.1. Parameters List

| PARAMETERS                                      | DESCRIPTION   | VALUES   |
|---|---|--|
| <b>Button name</b>                              | This parameter is used to type a button name. The name can be consisting of 40 characters.  | <b>40 Bytes allowed</b>  |
| <b>Button function</b>                          | This parameter is used to determine the button function. If no function is selected, Button X will not be used. For other choices, all functionalities are configured separately. | No function<br>Switch<br>Switch/dimming<br>Shutter/blinds<br>Value/forced operation<br>Scene control<br>Mode selection<br>Command sequence<br>Counter<br>RGB colour control<br><b>RGBW control</b><br>Thermostat Extension |
| <b>Colour value</b>                             | This parameter is used to set RGBW colours according to the configured values.  | <b>Red</b><br>Orange<br>Yellow<br>Green-yellow<br>Green<br>Green-cyan<br>Cyan<br>Blue-cyan<br>Blue<br>Blue-magenta<br>Magenta<br>Red-magenta<br>White  |
| <b>Distinction between long and short press</b> | This parameter is used to enable or disable the colour changing with long press operation.  | <b>No</b><br>Yes   |

|   |   |  |
|---|---|--|
| <b>-&gt; Long press after<sup>1</sup></b> | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value. | <b>00:00.200...00:00.500</b><br>...01:05.535 |
| <b>Lowest white value</b>                 | This parameter is set to the lowest white value.  | <b>0...254</b>                               |
| <b>Highest white value</b>                | This parameter is set to the highest white value.   | <b>1...255</b>                               |
| <b>%100 to %0 period</b>                  | This parameter is used to set how long it takes to go from 100% to 0%.  | <b>1s...3s...10s</b>                         |
| <b>%0 to %100 period</b>                  | This parameter is used to set how long it takes to go from 0% to 100%.  | <b>1s...3s...10s</b>                         |
| <b>Object type</b>                        | This parameter is used to determine the RGBW colour object type.  | <b>common</b><br>separated                   |

<sup>1</sup>This parameter is only visible when the parameter “Distinction between long and short press” is set to “Yes”.

### 4.2.11. Thermostat Extension

This section, it is explained how to control a thermostat device through the buttons connected to the iSwitch+. Detailed information on the relevant parameter configurations is described in the table below.




Fig. 17: Thermostat Extension Configuration Page

## 4.2.11.1. Parameters List

| PARAMETERS                                      | DESCRIPTION   | VALUES  |
|---|---|---|
| <b>Button name</b>                              | This parameter is used to type a button name. The name can be consisting of 40 characters.  | <b>40 Bytes allowed</b>   |
| <b>Button function</b>                          | This parameter is used to determine the button function. If no function is selected, Button X will not be used. For other choices, all functionalities are configured separately.       | No function<br><b>Switch</b><br>Switch/dimming<br>Shutter/blinds<br>Value/forced operation<br>Scene control<br>Mode selection<br>Command sequence<br>Counter<br>RGB colour control<br>RGBW control<br><b>Thermostat Extension</b> |
| <b>Connect to</b>                               | This parameter selects whether the thermostat to be connected to the device is external or internal.  | <b>External thermostat</b><br>Internal thermostat   |
| <b>Distinction between long and short press</b> | This parameter is used to enable or disable the control changing with long press operation.   | <b>No</b><br>Yes  |
| <b>-&gt; Reaction on long press<sup>1</sup></b> | This parameter is used to determine the long press operation sending the value of the Button X.   | <b>None</b><br>Status Control<br>Heating cooling control<br>HVAC mode control<br>Setpoint control<br>Fan control  |
| <b>-&gt; Long press after<sup>1</sup></b>       | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value. | 00:00.200... <b>00:00.500</b><br>...01:05.535   |
| <b>Reaction on short press</b>                  | This parameter is used to determine the short press operation sending the value of the Button X.  | <b>None</b><br>Status Control   |

|  |  |  |
|--|--|--|
|  |  | <p>Heating cooling control</p> <p>HVAC mode control</p> <p>Setpoint control</p> <p>Fan control</p> |
| <b>Reaction on short press / Reaction on long press: Status Control</b>          |  |  |
| <b>Status operation</b>  | <p>This parameter is used to determine which status value will be sent for each long or short press operation.</p> <p><b>Fixed:</b> Disable or Enable value will be sent according to the parameter that will be appear so the user can select the value.</p> <p><b>Toggle:</b> On each short or long operation, toggled of the last status value will be sent.</p>      | <p><b>Fixed</b></p> <p>Toggle</p>  |
| <b>-&gt; Status set value<sup>2</sup></b>  | <p>This parameter is used to determine the status value to be sent.</p>  | <p><b>Disable</b></p> <p>Enable</p>  |
| <b>-&gt; Seperate feedback object<sup>3</sup></b>                                | <p>This parameter is used to activate the group object for status feedback.</p>  | <p><b>No</b></p> <p>Yes</p>  |
| <b>Reaction on short press / Reaction on long press: Heating cooling control</b> |  |  |
| <b>Working mode operation</b>  | <p>This parameter is used to determine which status value will be sent for each long or short press operation.</p> <p><b>Fixed:</b> Cooling or Heating value will be sent according to a parameter that will be appear so the user can select the value.</p> <p><b>Toggle:</b> On each short or long operation, toggled of the last working mode value will be sent.</p> | <p><b>Fixed</b></p> <p>Toggle</p>  |
| <b>-&gt; Working mode set value<sup>4</sup></b>                                  | <p>This parameter is used to determine the working mode value to be sent.</p>  | <p><b>Cooling</b></p> <p>Heating</p>   |
| <b>-&gt; Seperate feedback object<sup>5</sup></b>                                | <p>This parameter is used to activate the group object for working mode feedback.</p>  | <p><b>No</b></p> <p>Yes</p>  |
| <b>Reaction on short press / Reaction on long press: HVAC mode control</b>       |  |  |
| <b>Mode operation</b>  | <p>This parameter is used to determine which HVAC mode value will be sent for each long or short press operation.</p>  | <p><b>Fixed</b></p> <p>Toggle</p>  |

|  |  |   |
|--|--|---|
|  | <p><b>Fixed:</b> HVAC mode value will be sent according to a parameter that will be appear so the user can select the value.</p> <p><b>Toggle:</b> On each short or long operation, the next HVAC mode that was activated, will be sent.</p> |   |
| -> Mode set value <sup>6</sup>         | This parameter is used to determine the HVAC mode value to be sent.  | <p>Auto</p> <p><b>Comfort</b></p> <p>Standby</p> <p>Economy</p> <p>Protection</p>   |
| -> Switch over modes <sup>7</sup>      | This parameter is used to determine which HVAC modes will be sent sequentially.  | <p><b>Comfort / standby</b></p> <p>Comfort / economy</p> <p>Comfort / standby / economy</p> <p>Comfort / standby / economy/protection</p> |
| -> Enable feedback object <sup>7</sup> | This parameter is used to activate the group object for HVAC mode feedback.  | <p><b>No</b></p> <p>Yes</p>   |

**Reaction on short press / Reaction on long press: Setpoint control**

|                                  |  |   |
|----------------------------------|--|---|
| <p><b>Setpoint operation</b></p> | <p>This parameter is used to determine the setpoint value will be sent for each long or short press operation.</p> <p><b>Fixed:</b> The setpoint value will be sent according to a parameter that will be appear so the user can select the value.</p> <p><b>Decrease:</b> On each long or short operation the setpoint value will decrease step by step according to a parameter that will be appear so the user can select the step value.</p> <p><b>Increase:</b> On each long or short operation the setpoint value will increase step by step according to a parameter that will be appear so the user can select the step value.</p> | <p><b>Fixed</b></p> <p>Decrease</p> <p>Increase</p> |
| -> Setpoint type <sup>8</sup>    | This parameter is used to determine the setpoint data type.  | <p><b>Individual</b></p> <p>Dependent</p>           |

|  |   |  |
|--|---|--|
| -> Setpoint set value <sup>8</sup>                                   | This parameter is used to determine the setpoint value to be sent.  | <b>25.0°C</b> (10.0 ... 40.0)<br><b>0.0°C</b> (-10.0 ... 10.0) |
| -> Setpoint step <sup>9</sup>  | This parameter is used to determine the step value for increasing or decreasing the setpoint value.   | 0.1K, 0.5K, 1K, 2K   |
| -> Seperate feedback object <sup>9</sup>                             | This parameter is used to activate the group object for setpoint value feedback.  | <b>No</b><br>Yes   |
| <b>Reaction on short press / Reaction on long press: Fan control</b> |   |  |
| Fan control type   | This parameter is used to determine which parameter of fan will be controlled.  | <b>Fan level</b><br>Fan mode                                   |
| -> Fan level operation <sup>10</sup>                                 | This parameter is used to determine the fan level value will be sent for each long or short press operation.<br><b>Fixed:</b> The fan level will be sent according to a parameter that will be appear so the user can select the value.<br><b>Decrease:</b> On each long or short operation the fan level value will decrease step by step up to minimum level.<br><b>Increase:</b> On each long or short operation the fan level value will increase step by step up to maximum level.<br><b>Sequential:</b> On each long or short operation, the fan level value increases step by step up to the maximum level. After reaching the maximum level, it goes back to the minimum level again. | <b>Fixed</b><br>Decrease<br>Increase<br>Sequential             |
| -> Fan level set value <sup>11</sup>                                 | This parameter is used to determine the fan level value to be sent.   | <b>0...5</b>   |
| -> Fan max level <sup>12</sup>                                       | This parameter is used to determine the maximum fan level of the external thermostat.   | <b>0...5</b>   |
| -> Fan mode control <sup>13</sup>                                    | This parameter is used to determine which fan mode value will be sent for each long or short press operation.<br><b>Fixed:</b> Fan mode value will be sent according to a parameter that will be appear so the user can select the value.<br><b>Toggle:</b> On each short or long operation, toggled of the last fan mode value will be sent.   | <b>Fixed</b><br>Toggle   |

|  |  |                |
|--|--|----------------|
| -> Fan mode set value <sup>14</sup>          | This parameter is used to determine the fan mode value to be sent.   | Auto<br>Manual |
| -> Seperate feedback object <sup>12,15</sup> | This parameter is used to activate the group object for fan level <sup>12</sup> and fan mode <sup>15</sup> value feedback. | No<br>Yes      |

<sup>\*1</sup> This parameter is only visible when the parameter “Distinction between long and short press” is set to “Yes”.

<sup>\*2</sup> This parameter is only visible when the parameter “Status operation” is set to “Fixed”.

<sup>\*3</sup> This parameter is only visible when the parameter “Status operation” is set to “Toggle” and connected to “External Thermostat”.

<sup>\*4</sup> This parameter is only visible when the parameter “Working mode operation” is set to “Fixed”.

<sup>\*5</sup> This parameter is only visible when the parameter “Working mode operation” is set to “Toggle” and connected to “External Thermostat”.

<sup>\*6</sup> This parameter is only visible when the parameter “Mode operation” is set to “Fixed”.

<sup>\*7</sup> This parameter is only visible when the parameter “Mode operation” is set to “Toggle” and connected to “External Thermostat”.

<sup>\*8</sup> This parameter is only visible when the parameter “Setpoint operation” is set to “Fixed”.

<sup>\*9</sup> This parameter is only visible when the parameter “Setpoint operation” is set to “Decrease” or “Increase”.

<sup>\*10</sup> This parameter is only visible when the parameter “Fan control type” is set to “Fan level”.

<sup>\*11</sup> This parameter is only visible when the parameter “Fan level operation” is set to “Fixed”.

<sup>\*12</sup> This parameter is only visible when the parameter “Fan level operation” is set to “Decrease” or “Increase” or “Sequential” and connected to “External Thermostat”.

<sup>\*13</sup> This parameter is only visible when the parameter “Fan control type” is set to “Fan mode”.

<sup>\*14</sup> This parameter is only visible when the parameter “Fan mode control” is set to “Fixed”.

<sup>\*15</sup> This parameter is only visible when the parameter “Fan mode control” is set to “Toggle” and connected to “External Thermostat”.

### 4.3. External Inputs

This section, it is explained how to control the external inputs connected to the iSwitch+. Digital or analog inputs can be connected to external inputs. If external input's type is selected as analog, it is considered a sensor. Therefore, the end-users can be configured the parameters below measurement channel. Temperature and brightness sensor can be connected to external inputs. Temperature and brightness measurements are made with these inputs.

If external input's type is selected as digital, the inputs are used as generic input with button functions such as switch, dimming, value forced etc. Additionally, window contact, presence input and card holder input can be used for energy-saving functions below the room controller channel.




Fig. 18: External Inputs Page

## 4.3.1. Parameters List

| PARAMETERS        | DESCRIPTION  | VALUES                              |
|-------------------|--|-------------------------------------|
| <b>Input name</b> | This parameter is used to type an Input name. The name can be consisting of 40 characters.   | <b>40 Bytes allowed</b>             |
| <b>Input type</b> | This parameter is used to determine the button function. If disable is selected, the External Input X will not be used. For other choices, all functionalities are configured separately.  | <b>Disable</b><br>Analog<br>Digital |
| <b>Input type</b> | This parameter is used to determine the analog external input x functionality.<br>In this section temperature functionality is described.<br><b>Temperature:</b> The input connected to the analog input is an NTC temperature sensor.<br><b>Brightness:</b> The input connected to the analog input is a light-dependent resistor (LDR) sensor. | Temperature<br>Brightness           |

### 4.3.2. Analog Input – Temperature

This section describes how to configure a parameter for an NTC sensor that can be connected to the analog input of the iSwitch+. After obtaining the necessary information about the NTC sensor to be connected from the relevant document, you should configure it.




Fig. 19: Analog Input – Temperature Page

## 4.3.2.1. Parameters List

| PARAMETERS            | DESCRIPTION   | VALUES                              |
|-----------------------|---|-------------------------------------|
| <b>Input name</b>     | This parameter is used to type an Input name. The name can be consisting of 40 characters.  | <b>40 Bytes allowed</b>             |
| <b>Input type</b>     | This parameter is used to determine the type of external input function. If disable is selected, the External Input X will not be used. For other choices, all functionalities are configured separately. | <b>Disable</b><br>Analog<br>Digital |
| <b>NTC resistance</b> | This parameter is used to determine the resistance value of the NTC sensor to be used to measure the ambient temperature.   | 1... <b>10000</b> ...65535          |
| <b>NTC B value</b>    | This parameter is used to determine the beta value of the NTC sensor to be used to measure the ambient temperature.   | 1... <b>3850</b> ...65535           |

### 4.3.3. Analog Input – Brightness

This section describes how to configure a parameter for an LDR resistance that can be connected to the analog input of the iSwitch+. After obtaining the necessary information about the LDR resistance to be connected from the relevant document, you should configure it.

The screenshot shows a configuration window for an analog input. On the left is a sidebar menu with options: General, Push Buttons, External Inputs, External Input 1 (selected), External Input 2, Leds, Measurements, Calculations, and Room Controller. The main area is titled 'External Input 1' and contains the following fields:

- Input name:
- Input type: analog (dropdown menu)
- Input type: brightness (dropdown menu)
- LDR resistance: 10000 (spin button)
- LDR coefficient: 600 (spin button) x0.01

At the bottom of the configuration area, there is a blue information box with an 'i' icon and the text: "Detailed parameters are available under the measurements tab".

Fig. 20: Analog Input – Brightness Page

## 4.3.3.1. Parameters List

| PARAMETERS               | DESCRIPTION  | VALUES                       |
|--------------------------|--|------------------------------|
| Input name               | This parameter is used to type an Input name. The name can be consisting of 40 characters.   | 40 Bytes allowed             |
| Input type               | This parameter is used to determine the button function. If disable is selected, the External Input X will not be used. For other choices, all functionalities are configured separately.  | Disable<br>Analog<br>Digital |
| Input type               | This parameter is used to determine the analog external input x functionality.<br>In this section temperature functionality is described.<br><b>Temperature:</b> The input connected to the analog input is an NTC temperature sensor.<br><b>Brightness:</b> The input connected to the analog input is a light-dependent resistor (LDR) sensor. | Temperature<br>Brightness    |
| LDR resistance           | This parameter is used to determine the resistance value of the LDR to be used to measure the ambient brightness.  | 1...10000...65535            |
| LDR coefficient (x 0.01) | This parameter is used to determine the coefficient value of the LDR to be used to measure the ambient brightness.   | 1...600...65535              |

### 4.3.4. Digital Input - Generic Input

This section describes how to configure a parameter for an external digital input that can be connected to the iSwitch+. Detailed information on the relevant parameter configurations is described in the table below.

Fig. 21: Digital Input – Generic Input Page

## 4.3.4.1. Parameters List

| PARAMETERS            | DESCRIPTION   | VALUES   |
|-----------------------|---|--|
| <b>Input name</b>     | This parameter is used to type an Input name. The name can be consisting of 40 characters.  | <b>40 Bytes allowed</b>  |
| <b>Input type</b>     | This parameter is used to determine the type of external input function. If disable is selected, the External Input X will not be used. For other choices, all functionalities are configured separately. | <b>Disable</b><br>Analog<br>Digital  |
| <b>Contact type</b>   | This parameter is used to specify the contact type that is connected to the iSwitch+.   | <b>Normally closed</b><br>Normally open  |
| <b>Debounce time</b>  | This parameter is used to determine the debounce time. Debouncing prevents unwanted multiple operations of the input, e.g., due to bouncing of the contact.   | 10ms<br>20ms<br>30ms<br>40ms<br><b>50ms</b><br>70ms<br>100ms<br>150ms  |
| <b>Input type</b>     | This parameter is used to determine the input type. For other choices, all functionalities are configured separately.   | <b>Generic input</b><br>Window contact<br>Presence input<br>Card holder  |
| <b>Input function</b> | This parameter is used to determine the input function. If no function is selected, the input x will not be used. For other choices, all functionalities are configured separately.                       | <b>No function</b><br>Switch<br>Switch/dimming<br>Shutter/blinds<br>Value/forced operation<br>Scene control<br>Mode selection<br>Command sequence<br>Counter<br>RGB colour control<br>RGBW control<br>Thermostat Extension |

### 4.3.5. Digital Input - Window Contact / Presence Input / Card holder

This section describes how to configure a parameter for an external digital input such as window contact, presence input and card holder that can be connected to the iSwitch+. Detailed information on the relevant parameter configurations is described in the table below.

|                         |  |  |
|-------------------------|--|--|
| General                 | Input name                                     | <input type="text"/>   |
| + Push Buttons          | Input type                                     | digital  |
| - External Inputs       | Contact type                                   | <input type="radio"/> normally closed <input checked="" type="radio"/> normally open |
|                         | Debounce time                                  | 50 ms  |
| <b>External Input 1</b> |  |  |
| External Input 2        | Input type                                     | window contact   |
| + Leds                  | Distinction between long and short operation   | <input checked="" type="radio"/> no <input type="radio"/> yes                        |
| + Measurements          | Cyclic sending of object "Switch"              | no   |
| + Calculations          | Reaction on closing the contact (rising edge)  | no reaction  |
| + Room Controller       | Reaction on opening the contact (falling edge) | no reaction  |
|                         | Scan input after bus voltage recovery          | <input checked="" type="radio"/> no <input type="radio"/> yes                        |

Fig. 22: Digital Input – Window Contact Page

## 4.3.5.1. Parameters List

| PARAMETERS  | DESCRIPTION  | VALUES  |
|---|--|---|
| Input name  | This parameter is used to type an input name. The name can be consisting of 40 characters.   | <b>40 Bytes allowed</b>   |
| Input type  | This parameter is used to determine the type of external input function. If disable is selected, the External Input X will not be used. For other choices, all functionalities are configured separately.  | <b>Disable</b><br>Analog<br>Digital   |
| Contact type  | This parameter is used to specify the contact type that is connected to the iSwitch+.  | <b>Normally closed</b><br>Normally open                                       |
| Debounce time                                       | This parameter is used to determine the debounce time. Debouncing prevents unwanted multiple operations of the input, e.g., due to bouncing of the contact.  | 10 ms<br>20 ms<br>30 ms<br>40 ms<br><b>50 ms</b><br>70 ms<br>100 ms<br>150 ms |
| Input type  | This parameter is used to determine the input type. For other choices, all functionalities are configured separately.  | <b>Generic input</b><br>Window contact<br>Presence input<br>Card holder       |
| Distinction between long and short press            | This parameter is used to set if the input differentiates between short and long operations. With the option "yes", after opening/closing of the contact, it must, first of all, be ascertained if a short or long operation has occurred here. Only thereafter will a possible reaction be triggered. | <b>No</b><br>Yes  |
| <b>Distinction between long and short press: No</b> |  |   |
| Cyclic sending of object "Switch"                   | This parameter is used to periodically send the commands to the bus line.  | <b>No</b><br>If "Switch" = ON<br>If "Switch" = OFF<br>Always                  |

|  |   |   |
|--|---|---|
| -> Telegram repeated every <sup>1</sup>              | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams  | 00:00:01...00:08:20...<br>18:12:15                    |
| Reaction on closing the contact (rising edge)        | This parameter is visible if there is no distinction between short and long operations. For each edge, you can set if the object value is to be switched ON, OFF or TOGGLE, or if no reaction should occur.<br><br>If cyclical sending has been parameterized, it is possible by setting the parameter value "terminate cyclic sending" with an operation of the input, to stop cyclic sending without a new object value being sent. | <b>No reaction</b><br><br>On<br><br>Off<br><br>Toggle |
| Reaction on opening the contact (falling edge)       | This parameter is visible if there is no distinction between short and long operations. For each edge, you can set if the object value is to be switched ON, OFF or TOGGLE, or if no reaction should occur.<br><br>If cyclical sending has been parameterized, it is possible by setting the parameter value "terminate cyclic sending" with an operation of the input, to stop cyclic sending without a new object value being sent. | <b>No reaction</b><br><br>On<br><br>Off<br><br>Toggle |
| Send button value after bus voltage recovery         | This parameter is used to determine the sending value of the inputs when the bus voltage has been recovered.  | <b>No</b><br><br>Yes                                  |
| <b>Distinction between long and short press: Yes</b> |   |   |
| Reaction on short press                              | This parameter is used to determine the short press operation sending the value of the input x.   | <b>No reaction</b><br><br>On<br><br>Off<br><br>Toggle |
| Reaction on long press                               | This parameter is used to determine the long press operation sending the value of the input x.  | <b>No reaction</b><br><br>On<br><br>Off<br><br>Toggle |
| Long press after                                     | This parameter is used to determine long operation detection after the button press operation. For making a long operation, the button should be pressed at least the configured value.   | 00:00.200...00:00.500<br>...01:05.535                 |

|   |  |   |
|---|--|---|
| <p><b>Number of object for short/long press</b></p> | <p>This parameter is used to determine the object count to use for short and long operations.</p> <p><b>1 object:</b> short and long operations will proceed with the same object.</p> <p><b>2 objects:</b> short and long operations will proceed with 2 different objects.</p> | <p><b>1 object</b></p> <p>2 objects</p> |
|---|--|---|

\*1 This parameter is only visible when the parameter “Cyclic sending of object “Switch” ” is set to “If “Switch” = ON” or “If “Switch” = OFF” or “Always”.

## 4.4. LEDs

This section describes how to configure the parameters for the LEDs of the iSwitch+. Each pushbutton channel has a programmable LED. This LED is used to indicate feedback status, pressing or release the button etc.

### 4.4.1. General




Fig. 23: LEDs General Page

#### 4.4.1.1. Parameters List

| PARAMETERS        | DESCRIPTION  | VALUES  |
|-------------------|--|---|
| <b>Brightness</b> | This parameter is used to set the brightness levels of the LEDs. | <b>Auto</b> , 10%, 20%, 30%, 40%, 50%, 60%, 70%, 80%, 90%, 100% |

## 4.4.2. LED X

This section describes how to configure the parameters for each LED of the iSwitch+. The LEDs can be configured in 4 different types such as “Always off”, “Always on”, “On press/on release” and “Status object”.




Fig. 24: Led X Page

## 4.4.2.1. Parameters List

| PARAMETERS                                      | DESCRIPTION   | VALUES  |
|---|---|---|
| <b>Led name</b>                                 | This parameter is used to type a Led name. The name can be consisting of 40 characters.   | <b>40 Bytes allowed</b>   |
| <b>Led Configuration</b>                        | <p>This parameter allows for controlling the LED status of the button.</p> <p><b>Always off:</b> The button LED is always off whether the button is pressed or not.</p> <p><b>Always on:</b> The button LED is always on whether the button is pressed.</p> <p><b>On press / On release:</b> When the push button is pressed or released, the push-button LED is on or off.</p> <p><b>Status object:</b> LED control is done via the status object.</p> | <p>Always off</p> <p><b>Always on</b></p> <p>On press / on release</p> <p>Status object</p> |
| <b>Led configuration: Always on</b>             |   |   |
| <b>Color</b>                                    | LED colour is selected by this parameter when the status is "Always on".  | Red / Green / Yellow / Blue / Magenta / Cyan / White  |
| <b>Led configuration: On press / on release</b> |   |   |
| <b>Source</b>                                   | This parameter determines the button number that is connected to the LED.   | Button 1-8,<br>Button Up<br>Button Down   |
| <b>Release delay</b>                            | This parameter determines a release delay for controlling the button LED when the push button is released.  | 0...1...255   |
| <b>Color for pressing</b>                       | This parameter allows controlling the button LED when the push button is pressed.   | None, Red, Green, Yellow, Blue, Magenta, Cyan, White  |
| <b>Color for releasing</b>                      | This parameter allows controlling button LED when the push button is released.  | None, Red, Green, Yellow, Blue, Magenta, Cyan, White  |
| <b>Led configuration: Status object</b>         |   |   |
| <b>Color for "1"</b>                            | LED colour is selected by this parameter when the status is "1".  | None, Red, <b>Green</b> , Yellow, Blue, Magenta, Cyan, White                                |

|                      |  |  |
|----------------------|--|--|
| <b>Color for "0"</b> | LED colour is selected by this parameter when the status is "0". | None, <b>Red</b> , Green, Yellow, Blue, Magenta, Cyan, White                       |
| <b>Blink Time</b>    | The blinking time is selected by this parameter.                 | 0.25s, <b>0.50s</b> , 0.75s<br>1.00s, 1.25s, 1.50s<br>1.75s, 2.00s, 2.25s<br>2.50s |

## 4.5. Measurement

The measurement channel folder includes the following sensors.

- Temperature Internal
- Humidity Internal
- Air Quality Internal
- Brightness Internal
- External 1 (Brightness / Temperature)
- External 2 (Brightness / Temperature)

The end-users can be configured the parameters related to the sensors given above. The sensor values can periodically be sent on the bus with a specified transmission interval, and whenever a specified variation occurs. Each sensor can be calibrated via a parameter or group object.

Thanks to the “Sampling rate” parameter, the end-users can be configured the updating interval of the channel value and additionally, the value filters such as median or low pass, are applied to the channel value for measurement noises. For example; if the filter type is median and the sampling rate is 10 seconds. The filtered value is updated per 10 seconds.

The median filter calculates an average with a series of measured values before sending on the bus. The parameter can have the following values:

- low = average value every 5 measurements;
- medium = average value every 15 measurements;
- high = average value every 25 measurements.

The low pass filter calculates and average with new measured values and previous measured value according to the following values:

- low = output value relies on new measurement more.
- medium = output value relies on new and previous measurements equally.
- high = output value relies on the previous measurements more.

Each sensor has an “Additional function”. This feature provides to send the additional value to the KNX bus according to configured threshold levels.

Each sensor checks the bus healthy internally. If any error occurs, an alarm object is sent to the KNX bus to indicate that an error has occurred. Additionally, the error code of the sensor is displayed on LCD screen. The error codes are going to explain in “LCD Page”.

### 4.5.1. Temperature Internal

This section describes how to configure the parameters for the internal temperature sensor of the iSwitch+. The integrated temperature sensor allows the measuring of the room temperature in the range from -40 °C to +125 °C with a resolution of 0.2 °C.

|                      |                               |   |
|----------------------|-------------------------------|---|
| General              | Measurement name              | <input type="text"/>  |
| + Push Buttons       | Measurement type              | temperature   |
| + External Inputs    | Activate measurement          | <input type="radio"/> no <input checked="" type="radio"/> yes |
| + Leds               | Send sensor fault             | on change   |
| - Measurements       | Filter type                   | median  |
| Temperature Internal | Filter weight                 | medium  |
| Humidity Internal    | Sampling rate                 | 00:00:10 hh:mm:ss   |
| AirQuality Internal  | Adjustment factor             | 100 %   |
| Brightness Internal  | Update via calibration object | <input checked="" type="radio"/> no <input type="radio"/> yes |
| External 1           | Adjustment ofset              | 0 x0.1K   |
| External 2           | Send value                    | on change   |
| + Calculations       | Send changed by               | 1K  |
| + Room Controller    | Additional function           | none  |

Fig. 25: Temperature Internal Page

## 4.5.1.1. Parameters List

| PARAMETERS                               | DESCRIPTION   | VALUES  |
|--|---|---|
| <b>Measurement name</b>                  | This parameter is used to type a Measurement name. The name can be consisting of 40 characters.   | <b>40 Bytes allowed</b>                                     |
| <b>Activate measurement</b>              | This parameter is used to enable or disable the measurement.  | <b>No</b><br>Yes  |
| <b>Activate measurement: Yes</b>         |   |   |
| <b>Send sensor fault</b>                 | This parameter allows sending the sensor fault information.<br><b>On change:</b> The sensor fault information is only sent when it changed.<br><b>Cyclic:</b> The sensor fault information is sent periodically.<br><b>On change and cyclic:</b> The value is sent both on change and cyclic.   | Disable<br><b>On change</b><br>Cyclic<br>On change & cyclic |
| <b>-&gt; Send cycle time<sup>1</sup></b> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams.   | 00:00:01 ... <b>00:10:00</b><br>... 18:12:15                |
| <b>Filter type</b>                       | This parameter is determined the type of sensor noise filter.<br><b>Median:</b> This filter calculates an average with a series of measured values before sending on the bus.<br><b>Low pass:</b> This filter calculates a value via <u>1st order IIR filter</u> before sending on the bus.   | None<br><b>Median</b><br>Low pass                           |
| <b>-&gt; Filter weight<sup>2</sup></b>   | The parameter is determined the coefficient of the filter.<br><b>If median filter is selected;</b><br><b>Low:</b> Average value every <b>5</b> measurements;<br><b>Medium:</b> Average value every <b>15</b> measurements;<br><b>High:</b> Average value every <b>25</b> measurements.<br><b>If low pass filter is selected;</b><br><b>Low:</b> Output value relies on new measurement;<br><b>Medium:</b> output value relies on new and previous measurements equally. | Low<br><b>Medium</b><br>High                                |

|  |  |  |
|--|--|--|
|  | <b>High:</b> output value relies on the previous measurements more   |  |
| <b>Sampling rate</b>                     | The parameter is determined the sampling time of the sensor.<br><br>E.g., sampling rate is selected as 00:00:10, the sensor value is updated per 10 seconds.   | 00:00:01 ... 00:00:10<br>... 18:12:15  |
| <b>Adjustment factor (%)</b>             | This parameter determines the calibration factor. This parameter can be changed on runtime via group object.<br><br>In this case, the value measured by the sensor is multiplied by 0.01 of the set adjustment factor.<br><br>Adjustment factor value can be calculated by this formula:<br><br>Adjustment factor = (The real value that is read from external sensor / device value that is measured internally) × 100                          | 0...100...65535  |
| <b>Update via calibration object</b>     | If this parameter is set to “ <b>Yes</b> ”, sensor calibration is carried out either via an object.  | <b>No</b><br><br>Yes   |
| <b>Adjustment offset (x0.1K)</b>         | This parameter is used to determine the calibration value of the sensor.   | -200... 0 ...200   |
| <b>Send value</b>                        | This parameter determines whether and when the value will be sent via an object.<br><br><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission.<br><br><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.<br><br><b>On change and cyclic:</b> The value is sent both on change and cyclic. | Disable<br><br><b>On change</b><br><br>Cyclic<br><br>On change & cyclic                        |
| <b>-&gt; Send changed by<sup>3</sup></b> | This parameter determines the minimum variation for the sensor value to send the object.   | 0.1K, 0.2K, 0.3K, 0.5K,<br><b>1K</b> , 1.5K, 2K, 2.5K, 3K,<br>3.5K, 4K, 4.5K, 5K,<br>7.5K, 10K |
| <b>-&gt; Send cycle time<sup>4</sup></b> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams   | 00:00:01 ... 00:00:10<br>... 18:12:15  |

|  |   |  |
|--|---|--|
| <b>Additional function</b>                       | <p>This parameter is used to determine the additional function of sensor measurement besides sending its value.</p> <p>If “Alarm function” is selected, low-level alarm and high-level alarm can be transmitted to bus via an object. Otherwise, a specific value can be transmitted via object with specific type.</p> | <p><b>None</b></p> <p>Send alarm</p> <p>Send bit</p> <p>Send byte</p> <p>Send Scene</p> <p>Send Percentage</p> |
| <b>Low level threshold (x0.1K)<sup>5</sup></b>   | <p>This parameter determines the low-level value of the additional function. The low threshold must be less than the high threshold.</p>  | -300...0...700   |
| <b>High level threshold (x0.1K)<sup>5</sup></b>  | <p>This parameter determines the high-level value of the additional function. The high threshold must be higher than the low threshold.</p>   | -300...0...700   |
| <b>Threshold hysteresis (x0.1K)<sup>5</sup></b>  | <p>This parameter determines the hysteresis value of the additional function.</p>   | -200...0...200   |
| <b>Send low level alarm<sup>6</sup></b>          | <p>This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.</p> <p>If this parameter is set to “<b>Yes</b>” another parameter will appear so the user can enter the value.</p>  | <p><b>No</b></p> <p>Yes</p>  |
| <b>-&gt; Send low level value<sup>7</sup></b>    | <p>The value to be sent when the measurement value is lower than low-level threshold.</p>   | Values depend on DPT selection.  |
| <b>Send normal level alarm<sup>6</sup></b>       | <p>This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.</p> <p>If this parameter is set to “<b>Yes</b>” another parameter will appear so the user can enter the value.</p>  | <p><b>No</b></p> <p>Yes</p>  |
| <b>-&gt; Send normal level value<sup>8</sup></b> | <p>The value to be sent when the measurement value is between low-level and high-level threshold.</p>   | Values depend on DPT selection.  |
| <b>Send high level alarm<sup>6</sup></b>         | <p>This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.</p> <p>If this parameter is set to “<b>Yes</b>” another parameter will appear so the user can enter the value.</p>  | <p><b>No</b></p> <p>Yes</p>  |
| <b>-&gt; Send high level value<sup>9</sup></b>   | <p>The value to be sent when the measurement value is higher than low-level threshold.</p>  | Values depend on DPT selection.  |
| <b>Send alarm<sup>5</sup></b>                    | <p>This parameter determines whether and when the value will be sent via an object.</p>   | <p>Disable</p> <p>On change</p>  |

|                                 |   |   |
|---------------------------------|---|---|
|                                 | <p><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission.</p> <p><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.</p> <p><b>On change and cyclic:</b> The value is sent both on change and cyclic.</p> | <p>Cyclic</p> <p>On change &amp; cyclic</p> |
| -> Send cycle time <sup>4</sup> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams  | 00:00:01 ... 00:00:10<br>... 18:12:15       |

<sup>1</sup>This parameter is only visible when the parameter “Send sensor fault” is set to “Cyclic” or “On change & cyclic” or “Always”.

<sup>2</sup>This parameter is only visible when the parameter “Filter type” is set to “Median” or “Low pass”.

<sup>3</sup>This parameter is only visible when the parameter “Send value” is set to “On change” or “On change & cyclic”.

<sup>4</sup>This parameter is only visible when the parameter “Send value” is set to “Cyclic” or “On change & cyclic”.

<sup>5</sup>This parameter is only visible when the parameter “Additional function” is set to “Send alarm” or “Send bit” or “Send byte” or “Send scene” or “Send percentage”. If the low threshold value is higher than the high threshold value and current value is exceed (high threshold) or dropped below (low threshold) the values, just low-level alarm value is sent over “Additional Value” object.

<sup>6</sup>This parameter is only visible when the parameter “Additional function” is set to “Send bit” or “Send byte” or “Send scene” or “Send percentage”.

<sup>7</sup>This parameter is only visible when the parameter “Send bit > Send low-level alarm” is set to “Yes”.

<sup>8</sup>This parameter is only visible when the parameter “Send bit > Send normal-level alarm” is set to “Yes”.

<sup>9</sup>This parameter is only visible when the parameter “Send bit > Send high-level alarm” is set to “Yes”.

### 4.5.2. Humidity Internal

This section describes how to configure the parameters for the internal humidity sensor of the iSwitch+. The integrated relative humidity sensor allows the measuring of the relative humidity value in the room in the range from 0 %RH to 100 %RH with a resolution of 1.8 %RH. The measured value allows you to make an advanced room thermoregulation and enlarge the opportunities for a safe operation of certain types of terminal equipment used for cooling.

|                          |                               |   |
|--------------------------|-------------------------------|---|
| General                  | Measurement name              | <input type="text"/>  |
| + Push Buttons           | Measurement type              | humidity  |
| + External Inputs        | Activate measurement          | <input type="radio"/> no <input checked="" type="radio"/> yes |
| + Leds                   | Send sensor fault             | on change   |
| - Measurements           | Filter type                   | median  |
| Temperature Internal     | Filter weight                 | medium  |
| <b>Humidity Internal</b> | Sampling rate                 | 00:00:10 hh:mm:ss   |
| AirQuality Internal      | Adjustment factor             | 100 %   |
| Brightness Internal      | Update via calibration object | <input checked="" type="radio"/> no <input type="radio"/> yes |
| External 1               | Adjustment ofset              | 0 %   |
| External 2               | Send value                    | on change   |
| + Calculations           | Send changed by               | 1 %   |
| + Room Controller        | Additional function           | none  |

Fig. 26: Humidity Internal Page

## 4.5.2.1. Parameters List

| PARAMETERS                      | DESCRIPTION   | VALUES  |
|---------------------------------|---|---|
| Measurement name                | This parameter is used to type a Measurement name. The name can be consisting of 40 characters.   | <b>40 Bytes allowed</b>                                     |
| Activate measurement            | This parameter is used to enable or disable the measurement.  | <b>No</b><br>Yes  |
| Activate measurement: Yes       |   |   |
| Send sensor fault               | <p>This parameter determines whether and when the value will be sent via an object.</p> <p><b>On change:</b> "On change" means that the value is sent if the measured value has changed by at least the configured value since the last transmission.</p> <p><b>Cyclic:</b> "Cyclic" means that the measured value is transmitted cyclically at the selected time.</p> <p><b>On change and cyclic:</b> The value is sent both on change and cyclic.</p>   | Disable<br><b>On change</b><br>Cyclic<br>On change & cyclic |
| -> Send cycle time <sup>1</sup> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams.   | 00:00:01 ... <b>00:10:00</b><br>... 18:12:15                |
| Filter type                     | <p>This parameter is determined the type of sensor noise filter.</p> <p><b>Median:</b> This filter calculates an average with a series of measured values before sending on the bus.</p> <p><b>Low pass:</b> This filter calculates a value via <u>1st order IIR filter</u> before sending on the bus.</p>  | None<br><b>Median</b><br>Low pass                           |
| -> Filter weight <sup>2</sup>   | <p>The parameter is determined the coefficient of the filter.</p> <p><b>If median filter is selected;</b></p> <p><b>Low</b> = average value every <b>5</b> measurements;<br/> <b>Medium</b> = average value every <b>15</b> measurements;<br/> <b>High</b> = average value every <b>25</b> measurements.</p> <p><b>If low pass filter is selected;</b></p> <p><b>Low</b> = output value relies on new measurement;<br/> <b>Medium</b> = output value relies on new and previous measurements equally.</p> | Low<br><b>Medium</b><br>High                                |

|  |  |   |
|--|--|---|
|  | <b>High</b> = output value relies on the previous measurements more  |   |
| <b>Sampling rate</b>                     | The parameter is determined the sampling time of the sensor.<br><br>For example, sampling rate is selected as 00:00:10, the sensor value is updated per 10 seconds.  | 00:00:01 ... 00:00:10<br>... 18:12:15                                   |
| <b>Adjustment factor (%)</b>             | This parameter determines the calibration factor. This parameter can be changed on runtime via group object.<br><br>In this case, the value measured by the sensor is multiplied by 0.01 of the set adjustment factor.<br><br>Adjustment factor value can be calculated by this formula:<br><br>Adjustment factor = (The real value that is read from external sensor / device value that is measured internally) × 100                          | 0...100...65535   |
| <b>Update via calibration object</b>     | If this parameter is set to “ <b>Yes</b> ”, sensor calibration is carried out either via an object.  | <b>No</b><br><br>Yes  |
| <b>Adjustment offset (%)</b>             | This parameter is used to determine the calibration value of the sensor.   | -40...0...40  |
| <b>Send value</b>                        | This parameter determines whether and when the value will be sent via an object.<br><br><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission.<br><br><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.<br><br><b>On change and cyclic:</b> The value is sent both on change and cyclic. | Disable<br><br><b>On change</b><br><br>Cyclic<br><br>On change & cyclic |
| <b>Send changed by (%)<sup>3</sup></b>   | This parameter determines the minimum variation for the sensor value to send the object.   | 0...1...40  |
| <b>-&gt; Send cycle time<sup>4</sup></b> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams.  | 00:00:01 ... 00:00:10<br>... 18:12:15                                   |
| <b>Additional function</b>               | This parameter is used to determine the additional function of sensor measurement besides sending its value.   | <b>None</b><br><br>Send alarm<br><br>Send bit                           |

|  |  |  |
|--|--|--|
|  | If “Alarm function” is selected, low-level alarm and high-level alarm can be transmitted to bus via an object. Otherwise, a specific value can be transmitted via object with specific type.   | Send byte<br>Send Scene<br>Send Percentage           |
| <b>Low level threshold (%)<sup>5</sup></b>       | This parameter determines the low-level value of the additional function. The low threshold must be less than the high threshold.  | 0... <b>30</b> ...100                                |
| <b>High level threshold (%)<sup>5</sup></b>      | This parameter determines the high-level value of the additional function. The high threshold must be higher than the low threshold.   | 0... <b>60</b> ...100                                |
| <b>Threshold hysteresis (%)<sup>5</sup></b>      | This parameter determines the hysteresis value of the additional function.   | 0... <b>1</b> ...100                                 |
| <b>Send low level alarm<sup>6</sup></b>          | This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.<br><br>If this parameter is set to “ <b>Yes</b> ” another parameter will appear so the user can enter the value.                    | <b>No</b><br>Yes                                     |
| <b>-&gt; Send low level value<sup>7</sup></b>    | The value to be sent when the measurement value is lower than low-level threshold.   | Values depend on DPT selection.                      |
| <b>Send normal level alarm<sup>6</sup></b>       | This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.<br><br>If this parameter is set to “ <b>Yes</b> ” another parameter will appear so the user can enter the value.                    | <b>No</b><br>Yes                                     |
| <b>-&gt; Send normal level value<sup>8</sup></b> | The value to be sent when the measurement value is between low-level and high-level threshold.   | Values depend on DPT selection.                      |
| <b>Send high level alarm<sup>6</sup></b>         | This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.<br><br>If this parameter is set to “ <b>Yes</b> ” another parameter will appear so the user can enter the value.                    | <b>No</b><br>Yes                                     |
| <b>-&gt; Send high level value<sup>9</sup></b>   | The value to be sent when the measurement value is higher than low-level threshold.  | Values depend on DPT selection.                      |
| <b>Send alarm<sup>5</sup></b>                    | This parameter determines whether and when the value will be sent via an object.<br><br><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission. | Disable<br>On change<br>Cyclic<br>On change & cyclic |

|  |   |  |
|--|---|--|
|  | <p><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.</p> <p><b>On change and cyclic:</b> The value is sent both on change and cyclic.</p> |  |
| -> <b>Send cycle time</b> <sup>4</sup> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams                                    | 00:00:01 ... <b>00:00:10</b><br>... 18:12:15 |

<sup>1</sup>This parameter is only visible when the parameter “Send sensor fault” is set to “Cyclic” or “On change & cyclic” or “Always”.

<sup>2</sup>This parameter is only visible when the parameter “Filter type” is set to “Median” or “Low pass”.

<sup>3</sup>This parameter is only visible when the parameter “Send value” is set to “On change” or “On change & cyclic”.

<sup>4</sup>This parameter is only visible when the parameter “Send value” is set to “Cyclic” or “On change & cyclic”.

<sup>5</sup>This parameter is only visible when the parameter “Additional function” is set to “Send alarm” or “Send bit” or “Send byte” or “Send scene” or “Send percentage”. If the low threshold value is higher than the high threshold value and current value is exceed (high threshold) or dropped below (low threshold) the values, just low-level alarm value is sent over “Additional Value” object.

<sup>6</sup>This parameter is only visible when the parameter “Additional function” is set to “Send bit” or “Send byte” or “Send scene” or “Send percentage”.

<sup>7</sup>This parameter is only visible when the parameter “Send bit > Send low-level alarm” is set to “Yes”.

<sup>8</sup>This parameter is only visible when the parameter “Send bit > Send normal-level alarm” is set to “Yes”.

<sup>9</sup>This parameter is only visible when the parameter “Send bit > Send high-level alarm” is set to “Yes”.

### 4.5.3. Air Quality Internal

This section describes how to configure the parameters for the internal air quality sensor of the iSwitch+.




Fig. 27: Air Quality Internal Page

The integrated air quality sensor allows the measuring of the air quality value in the room by unit of VOC index. VOC Index is referenced to the average of VOCs present over the last 24 h in the room and notifies end users or air treatment devices when air pollution changes. Notifications are actionable in environments with low and high VOC backgrounds independent of the absolute VOC concentrations.




Fig. 28: Interpretation of Scaling

## 4.5.3.1. Parameters List

| PARAMETERS                      | DESCRIPTION   | VALUES  |
|---------------------------------|---|---|
| Measurement name                | This parameter is used to type a Measurement name. The name can be consisting of 40 characters.   | <b>40 Bytes allowed</b>                                     |
| Activate measurement            | This parameter is used to enable or disable the measurement.  | <b>No</b><br>Yes  |
| Activate measurement: Yes       |   |   |
| Send sensor fault               | <p>This parameter determines whether and when the value will be sent via an object.</p> <p><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission.</p> <p><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.</p> <p><b>On change and cyclic:</b> The value is sent both on change and cyclic.</p>   | Disable<br><b>On change</b><br>Cyclic<br>On change & cyclic |
| -> Send cycle time <sup>1</sup> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams.   | 00:00:01 ... <b>00:10:00</b><br>... 18:12:15                |
| Filter type                     | <p>This parameter is determined the type of sensor noise filter.</p> <p><b>Median:</b> This filter calculates an average with a series of measured values before sending on the bus.</p> <p><b>Low pass:</b> This filter calculates a value via <u>1st order IIR filter</u> before sending on the bus.</p>  | None<br><b>Median</b><br>Low pass                           |
| -> Filter weight <sup>2</sup>   | <p>The parameter is determined the coefficient of the filter.</p> <p><b>If median filter is selected;</b></p> <p><b>Low</b> = average value every <b>5</b> measurements;<br/> <b>Medium</b> = average value every <b>15</b> measurements;<br/> <b>High</b> = average value every <b>25</b> measurements.</p> <p><b>If low pass filter is selected;</b></p> <p><b>Low</b> = output value relies on new measurement;<br/> <b>Medium</b> = output value relies on new and previous measurements equally.</p> | Low<br><b>Medium</b><br>High                                |

|  |  |   |
|--|--|---|
|  | <b>High</b> = output value relies on the previous measurements more  |   |
| <b>Sampling rate</b>                           | The parameter is determined the sampling time of the sensor.<br><br>For example, sampling rate is selected as 00:00:10, the sensor value is updated per 10 seconds.  | 00:00:01 ... 00:00:10<br>... 18:12:15                                   |
| <b>Adjustment factor (%)</b>                   | This parameter determines the calibration factor. This parameter can be changed on runtime via group object.<br><br>In this case, the value measured by the sensor is multiplied by 0.01 of the set adjustment factor.<br><br>Adjustment factor value can be calculated by this formula:<br><br>Adjustment factor = (The real value that is read from external sensor / device value that is measured internally) × 100                          | 0...100...65535   |
| <b>Update via calibration object</b>           | If this parameter is set to “ <b>Yes</b> ”, sensor calibration is carried out either via an object.  | <b>No</b><br><br>Yes  |
| <b>Adjustment offset (ppm)</b>                 | This parameter is used to determine the calibration value of the sensor.   | -32768...0...32767  |
| <b>Send value</b>                              | This parameter determines whether and when the value will be sent via an object.<br><br><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission.<br><br><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.<br><br><b>On change and cyclic:</b> The value is sent both on change and cyclic. | Disable<br><br><b>On change</b><br><br>Cyclic<br><br>On change & cyclic |
| <b>-&gt; Send changed by (ppm)<sup>3</sup></b> | This parameter determines the minimum variation for the sensor value to send the object.   | 1...255   |
| <b>-&gt; Send cycle time<sup>4</sup></b>       | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams.  | 00:00:01 ... 00:00:10<br>... 18:12:15                                   |
| <b>Additional function</b>                     | This parameter is used to determine the additional function of sensor measurement besides sending its value.   | <b>None</b><br><br>Send alarm<br><br>Send bit                           |

|  |  |   |
|--|--|---|
|  | If "Alarm function" is selected, low-level alarm and high-level alarm can be transmitted to bus via an object. Otherwise, a specific value can be transmitted via object with specific type.   | Send byte<br>Send Scene<br>Send Percentage                  |
| <b>Low level threshold (ppm)<sup>5</sup></b>     | This parameter determines the low-level value of the additional function. The low threshold must be less than the high threshold.  | 0... <b>100</b> ...1200                                     |
| <b>High level threshold (ppm)<sup>5</sup></b>    | This parameter determines the high-level value of the additional function. The high threshold must be higher than the low threshold.   | 0... <b>300</b> ...1200                                     |
| <b>Threshold hysteresis (ppm)<sup>5</sup></b>    | This parameter determines the hysteresis value of the additional function.   | 0... <b>80</b> ...1200                                      |
| <b>Send low level alarm<sup>6</sup></b>          | This parameter is available if "Additional function" is set as send 1 bit, scene number, percentage or 1 byte.<br><br>If this parameter is set to " <b>Yes</b> " another parameter will appear so the user can enter the value.                    | <b>No</b><br>Yes  |
| <b>-&gt; Send low level value<sup>7</sup></b>    | The value to be sent when the measurement value is lower than low-level threshold.   | Values depend on DPT selection.                             |
| <b>Send normal level alarm<sup>6</sup></b>       | This parameter is available if "Additional function" is set as send 1 bit, scene number, percentage or 1 byte.<br><br>If this parameter is set to " <b>Yes</b> " another parameter will appear so the user can enter the value.                    | <b>No</b><br>Yes  |
| <b>-&gt; Send normal level value<sup>8</sup></b> | The value to be sent when the measurement value is between low-level and high-level threshold.   | Values depend on DPT selection.                             |
| <b>Send high level alarm<sup>6</sup></b>         | This parameter is available if "Additional function" is set as send 1 bit, scene number, percentage or 1 byte.<br><br>If this parameter is set to " <b>Yes</b> " another parameter will appear so the user can enter the value.                    | <b>No</b><br>Yes  |
| <b>-&gt; Send high level value<sup>9</sup></b>   | The value to be sent when the measurement value is higher than low-level threshold.  | Values depend on DPT selection.                             |
| <b>Send alarm<sup>5</sup></b>                    | This parameter determines whether and when the value will be sent via an object.<br><br><b>On change:</b> "On change" means that the value is sent if the measured value has changed by at least the configured value since the last transmission. | Disable<br><b>On change</b><br>Cyclic<br>On change & cyclic |

|                                 |   |  |
|---------------------------------|---|--|
|                                 | <p><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.</p> <p><b>On change and cyclic:</b> The value is sent both on change and cyclic.</p> |  |
| -> Send cycle time <sup>4</sup> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams                                    | 00:00:01 ... <b>00:00:10</b><br>... 18:12:15 |

<sup>1</sup>This parameter is only visible when the parameter “Send sensor fault” is set to “Cyclic” or “On change & cyclic” or “Always”.

<sup>2</sup>This parameter is only visible when the parameter “Filter type” is set to “Median” or “Low pass”.

<sup>3</sup>This parameter is only visible when the parameter “Send value” is set to “On change” or “On change & cyclic”.

<sup>4</sup>This parameter is only visible when the parameter “Send value” is set to “Cyclic” or “On change & cyclic”.

<sup>5</sup>This parameter is only visible when the parameter “Additional function” is set to “Send alarm” or “Send bit” or “Send byte” or “Send scene” or “Send percentage”. If the low threshold value is higher than the high threshold value and current value is exceed (high threshold) or dropped below (low threshold) the values, just low-level alarm value is sent over “Additional Value” object.

<sup>6</sup>This parameter is only visible when the parameter “Additional function” is set to “Send bit” or “Send byte” or “Send scene” or “Send percentage”.

<sup>7</sup>This parameter is only visible when the parameter “Send bit > Send low-level alarm” is set to “Yes”.

<sup>8</sup>This parameter is only visible when the parameter “Send bit > Send normal-level alarm” is set to “Yes”.

<sup>9</sup>This parameter is only visible when the parameter “Send bit > Send high-level alarm” is set to “Yes”.

### 4.5.4. Brightness Internal

This section describes how to configure the parameters for the internal brightness sensor of the iSwitch+. The integrated ambient brightness sensor allows the measuring of the intensity of light value in the room. The brightness sensor can be measured intensity of light up to 1800 Lux.

|                            |                               |   |
|----------------------------|-------------------------------|---|
| <b>General</b>             | Measurement name              | <input type="text"/>  |
| + Push Buttons             | Measurement type              | brightness  |
| + External Inputs          | Activate measurement          | <input type="radio"/> no <input checked="" type="radio"/> yes |
| + Leds                     | Send sensor fault             | on change   |
| - Measurements             | Filter type                   | median  |
| Temperature Internal       | Filter weight                 | medium  |
| Humidity Internal          | Sampling rate                 | 00:00:10 hh:mm:ss   |
| AirQuality Internal        | Adjustment factor             | 100 %   |
| <b>Brightness Internal</b> | Update via calibration object | <input checked="" type="radio"/> no <input type="radio"/> yes |
| External 1                 | Adjustment offset             | 0 Lux   |
| External 2                 | Send value                    | on change   |
| + Calculations             | Send changed by               | 1 Lux   |
| + Room Controller          | Additional function           | none  |

Fig. 29: Brightness Internal Page

| Lighting Condition | From (lux) | To (lux) | Average value (lux) |
|--------------------|------------|----------|---------------------|
| Very dark          | 11         | 50       | 30                  |
| Dark Indoors       | 51         | 200      | 125                 |
| Dim Indoors        | 201        | 400      | 300                 |
| Normal Indoors     | 401        | 1000     | 700                 |
| Bright Indoors     | 1001       | 5000     | 3000                |

Table 4: Examples of Illuminance

## 4.5.4.1. Parameters List

| PARAMETERS                      | DESCRIPTION   | VALUES  |
|---------------------------------|---|---|
| Measurement name                | This parameter is used to type a Measurement name. The name can be consisting of 40 characters.   | <b>40 Bytes allowed</b>                                     |
| Activate measurement            | This parameter is used to enable or disable the measurement.  | <b>No</b><br>Yes  |
| Activate measurement: Yes       |   |   |
| Send sensor fault               | <p>This parameter determines whether and when the value will be sent via an object.</p> <p><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission.</p> <p><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.</p> <p><b>On change and cyclic:</b> The value is sent both on change and cyclic.</p>   | Disable<br><b>On change</b><br>Cyclic<br>On change & cyclic |
| -> Send cycle time <sup>1</sup> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams.   | 00:00:01 ... <b>00:10:00</b><br>... 18:12:15                |
| Filter type                     | <p>This parameter is determined the type of sensor noise filter.</p> <p><b>Median:</b> This filter calculates an average with a series of measured values before sending on the bus.</p> <p><b>Low pass:</b> This filter calculates a value via <u>1st order IIR filter</u> before sending on the bus.</p>  | None<br><b>Median</b><br>Low pass                           |
| -> Filter weight <sup>2</sup>   | <p>The parameter is determined the coefficient of the filter.</p> <p><b>If median filter is selected;</b></p> <p><b>Low</b> = average value every <b>5</b> measurements;<br/> <b>Medium</b> = average value every <b>15</b> measurements;<br/> <b>High</b> = average value every <b>25</b> measurements.</p> <p><b>If low pass filter is selected;</b></p> <p><b>Low</b> = output value relies on new measurement;<br/> <b>Medium</b> = output value relies on new and previous measurements equally.</p> | Low<br><b>Medium</b><br>High                                |

|  |  |   |
|--|--|---|
|  | <b>High</b> = output value relies on the previous measurements more  |   |
| <b>Sampling rate</b>                           | The parameter is determined the sampling time of the sensor.<br><br>For example, sampling rate is selected as 00:00:10, the sensor value is updated per 10 seconds.  | 00:00:01 ... 00:00:10<br>... 18:12:15                                   |
| <b>Adjustment factor (%)</b>                   | This parameter determines the calibration factor. This parameter can be changed on runtime via group object.<br><br>In this case, the value measured by the sensor is multiplied by 0.01 of the set adjustment factor.<br><br>Adjustment factor value can be calculated by this formula:<br><br>Adjustment factor = (The real value that is read from external sensor / device value that is measured internally) × 100                          | 0...100...65535   |
| <b>Update via calibration object</b>           | If this parameter is set to “ <b>Yes</b> ”, sensor calibration is carried out either via an object.  | <b>No</b><br><br>Yes  |
| <b>Adjustment offset (Lux)</b>                 | This parameter is used to determine the calibration value of the sensor.   | -1200...0...1200  |
| <b>Send value</b>                              | This parameter determines whether and when the value will be sent via an object.<br><br><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission.<br><br><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.<br><br><b>On change and cyclic:</b> The value is sent both on change and cyclic. | Disable<br><br><b>On change</b><br><br>Cyclic<br><br>On change & cyclic |
| <b>-&gt; Send changed by (Lux)<sup>3</sup></b> | This parameter determines the minimum variation for the sensor value to send the object.   | 1...255   |
| <b>-&gt; Send cycle time<sup>4</sup></b>       | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams   | 00:00:01 ... 00:00:10<br>... 18:12:15                                   |
| <b>Additional function</b>                     | This parameter is used to determine the additional function of sensor measurement besides sending its value.   | <b>None</b><br><br>Send alarm<br><br>Send bit                           |

|  |  |   |
|--|--|---|
|  | If “Alarm function” is selected, low-level alarm and high-level alarm can be transmitted to bus via an object. Otherwise, a specific value can be transmitted via object with specific type.   | Send byte<br>Send Scene<br>Send Percentage                  |
| <b>Low level threshold (Lux)<sup>5</sup></b>     | This parameter determines the low-level value of the additional function. The low threshold must be less than the high threshold.  | <b>0...1200</b>   |
| <b>High level threshold (Lux)<sup>5</sup></b>    | This parameter determines the high-level value of the additional function. The high threshold must be higher than the low threshold.   | <b>0...500...1200</b>                                       |
| <b>Threshold hysteresis (Lux)<sup>5</sup></b>    | This parameter determines the hysteresis value of the additional function.   | <b>0...50...1200</b>  |
| <b>Send low level alarm<sup>6</sup></b>          | This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.<br><br>If this parameter is set to “ <b>Yes</b> ” another parameter will appear so the user can enter the value.                    | <b>No</b><br>Yes  |
| <b>-&gt; Send low level value<sup>7</sup></b>    | The value to be sent when the measurement value is lower than low-level threshold.   | Values depend on DPT selection.                             |
| <b>Send normal level alarm<sup>6</sup></b>       | This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.<br><br>If this parameter is set to “ <b>Yes</b> ” another parameter will appear so the user can enter the value.                    | <b>No</b><br>Yes  |
| <b>-&gt; Send normal level value<sup>8</sup></b> | The value to be sent when the measurement value is between low-level and high-level threshold.   | Values depend on DPT selection.                             |
| <b>Send high level alarm<sup>6</sup></b>         | This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.<br><br>If this parameter is set to “ <b>Yes</b> ” another parameter will appear so the user can enter the value.                    | <b>No</b><br>Yes  |
| <b>-&gt; Send high level value<sup>9</sup></b>   | The value to be sent when the measurement value is higher than low-level threshold.  | Values depend on DPT selection.                             |
| <b>Send alarm<sup>5</sup></b>                    | This parameter determines whether and when the value will be sent via an object.<br><br><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission. | Disable<br><b>On change</b><br>Cyclic<br>On change & cyclic |

|                                 |   |                                       |
|---------------------------------|---|---------------------------------------|
|                                 | <p><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.</p> <p><b>On change and cyclic:</b> The value is sent both on change and cyclic.</p> |                                       |
| -> Send cycle time <sup>4</sup> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams                                    | 00:00:01 ... 00:00:10<br>... 18:12:15 |

<sup>1</sup>This parameter is only visible when the parameter “Send sensor fault” is set to “Cyclic” or “On change & cyclic” or “Always”.

<sup>2</sup>This parameter is only visible when the parameter “Filter type” is set to “Median” or “Low pass”.

<sup>3</sup>This parameter is only visible when the parameter “Send value” is set to “On change” or “On change & cyclic”.

<sup>4</sup>This parameter is only visible when the parameter “Send value” is set to “Cyclic” or “On change & cyclic”.

<sup>5</sup>This parameter is only visible when the parameter “Additional function” is set to “Send alarm” or “Send bit” or “Send byte” or “Send scene” or “Send percentage”. If the low threshold value is higher than the high threshold value and current value is exceed (high threshold) or dropped below (low threshold) the values, just low-level alarm value is sent over “Additional Value” object.

<sup>6</sup>This parameter is only visible when the parameter “Additional function” is set to “Send bit” or “Send byte” or “Send scene” or “Send percentage”.

<sup>7</sup>This parameter is only visible when the parameter “Send bit > Send low-level alarm” is set to “Yes”.

<sup>8</sup>This parameter is only visible when the parameter “Send bit > Send normal-level alarm” is set to “Yes”.

<sup>9</sup>This parameter is only visible when the parameter “Send bit > Send high-level alarm” is set to “Yes”.

### 4.5.5. External X

This section describes how to configure the parameters for the external sensors of the iSwitch+. If external input's type is selected as analog, it is considered as a sensor. Therefore, the end-users can be configured the parameters below measurement channel. Temperature and brightness sensor can be connected to external inputs.

|                      |                               |   |
|----------------------|-------------------------------|---|
| General              | Measurement name              | <input type="text"/>  |
| + Push Buttons       | Measurement type              | temperature   |
| + External Inputs    | Activate measurement          | <input type="radio"/> no <input checked="" type="radio"/> yes |
| + Leds               | Send sensor fault             | on change   |
| - Measurements       | Filter type                   | median  |
| Temperature Internal | Filter weight                 | medium  |
| Humidity Internal    | Sampling rate                 | 00:00:10 hh:mm:ss   |
| AirQuality Internal  | Adjustment factor             | 100 %   |
| Brightness Internal  | Update via calibration object | <input checked="" type="radio"/> no <input type="radio"/> yes |
| <b>External 1</b>    | Adjustment ofset              | 0 x0.1K   |
| External 2           | Send value                    | on change   |
| + Calculations       | Send changed by               | 1K  |
| + Room Controller    | Additional function           | none  |

Fig. 30: External X Page

## 4.5.5.1. Parameters List

| PARAMETERS                      | DESCRIPTION   | VALUES  |
|---------------------------------|---|---|
| Measurement name                | This parameter is used to type a Measurement name. The name can be consisting of 40 characters.   | <b>40 Bytes allowed</b>                                     |
| Activate measurement            | This parameter is used to enable or disable the measurement.  | <b>No</b><br>Yes  |
| Activate measurement: Yes       |   |   |
| Send sensor fault               | <p>This parameter determines whether and when the value will be sent via an object.</p> <p><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission.</p> <p><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.</p> <p><b>On change and cyclic:</b> The value is sent both on change and cyclic.</p>   | Disable<br><b>On change</b><br>Cyclic<br>On change & cyclic |
| -> Send cycle time <sup>1</sup> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams.   | 00:00:01 ... <b>00:10:00</b><br>... 18:12:15                |
| Filter type                     | <p>This parameter is determined the type of sensor noise filter.</p> <p><b>Median:</b> This filter calculates an average with a series of measured values before sending on the bus.</p> <p><b>Low pass:</b> This filter calculates a value via <u>1st order IIR filter</u> before sending on the bus.</p>  | None<br><b>Median</b><br>Low pass                           |
| -> Filter weight <sup>2</sup>   | <p>The parameter is determined the coefficient of the filter.</p> <p><b>If median filter is selected;</b></p> <p><b>Low</b> = average value every <b>5</b> measurements;<br/> <b>Medium</b> = average value every <b>15</b> measurements;<br/> <b>High</b> = average value every <b>25</b> measurements.</p> <p><b>If low pass filter is selected;</b></p> <p><b>Low</b> = output value relies on new measurement;<br/> <b>Medium</b> = output value relies on new and previous measurements equally.</p> | Low<br><b>Medium</b><br>High                                |

|  |  |  |
|--|--|--|
|  | <b>High</b> = output value relies on the previous measurements more  |  |
| <b>Sampling rate</b>                     | The parameter is determined the sampling time of the sensor.<br><br>For example, sampling rate is selected as 00:00:10, the sensor value is updated per 10 seconds.  | 00:00:01 ... 00:00:10<br>... 18:12:15  |
| <b>Adjustment factor</b>                 | This parameter determines the calibration factor. This parameter can be changed on runtime via group object.<br><br>In this case, the value measured by the sensor is multiplied by 0.01 of the set adjustment factor.<br><br>Adjustment factor value can be calculated by this formula:<br><br>Adjustment factor = (The real value that is read from external sensor / device value that is measured internally) × 100                          | 0...100...65535  |
| <b>Update via calibration object</b>     | If this parameter is set to “ <b>Yes</b> ”, sensor calibration is carried out either via an object.  | <b>No</b><br><br>Yes   |
| <b>Adjustment offset</b>                 | This parameter is used to determine the calibration value of the sensor.   | -200...0...200   |
| <b>Send value</b>                        | This parameter determines whether and when the value will be sent via an object.<br><br><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission.<br><br><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.<br><br><b>On change and cyclic:</b> The value is sent both on change and cyclic. | Disable<br><br>On change<br><br>Cyclic<br><br>On change & cyclic                       |
| <b>-&gt; Send changed by<sup>3</sup></b> | This parameter determines the minimum variation for the sensor value to send the object.   | 0.1K, 0.2K, 0.3K, 0.5K,<br>1K, 1.5K, 2K, 2.5K, 3K,<br>3.5K, 4K, 4.5K, 5K,<br>7.5K, 10K |
| <b>-&gt; Send cycle time<sup>4</sup></b> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams   | 00:00:01 ... 00:00:10<br>... 18:12:15  |

|  |   |   |
|--|---|---|
| <b>Additional function</b>                       | <p>This parameter is used to determine the additional function of sensor measurement besides sending its value.</p> <p>If “Alarm function” is selected, low-level alarm and high-level alarm can be transmitted to bus via an object. Otherwise, a specific value can be transmitted via object with specific type.</p> | <p>None</p> <p>Send alarm</p> <p>Send bit</p> <p>Send byte</p> <p>Send Scene</p> <p>Send Percentage</p> |
| <b>Low level threshold<sup>5</sup></b>           | <p>This parameter determines the low-level value of the additional function. The low threshold must be less than the high threshold.</p>  | -300...0...700  |
| <b>High level threshold<sup>5</sup></b>          | <p>This parameter determines the high-level value of the additional function. The high threshold must be higher than the low threshold.</p>   | -300...0...700  |
| <b>Threshold hysteresis<sup>5</sup></b>          | <p>This parameter determines the hysteresis value of the additional function.</p>   | -200...0...200  |
| <b>Send low level alarm<sup>6</sup></b>          | <p>This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.</p> <p>If this parameter is set to “<b>Yes</b>” another parameter will appear so the user can enter the value.</p>  | <p><b>No</b></p> <p>Yes</p>   |
| <b>-&gt; Send low level value<sup>7</sup></b>    | <p>The value to be sent when the measurement value is lower than low-level threshold.</p>   | Values depend on DPT selection.   |
| <b>Send normal level alarm<sup>6</sup></b>       | <p>This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.</p> <p>If this parameter is set to “<b>Yes</b>” another parameter will appear so the user can enter the value.</p>  | <p><b>No</b></p> <p>Yes</p>   |
| <b>-&gt; Send normal level value<sup>8</sup></b> | <p>The value to be sent when the measurement value is between low-level and high-level threshold.</p>   | Values depend on DPT selection.   |
| <b>Send high level alarm<sup>6</sup></b>         | <p>This parameter is available if “Additional function” is set as send 1 bit, scene number, percentage or 1 byte.</p> <p>If this parameter is set to “<b>Yes</b>” another parameter will appear so the user can enter the value.</p>  | <p><b>No</b></p> <p>Yes</p>   |
| <b>-&gt; Send high level value<sup>9</sup></b>   | <p>The value to be sent when the measurement value is higher than low-level threshold.</p>  | Values depend on DPT selection.   |
| <b>Send alarm<sup>5</sup></b>                    | <p>This parameter determines whether and when the value will be sent via an object.</p>   | <p>Disable</p> <p>On change</p>   |

|                                 |   |   |
|---------------------------------|---|---|
|                                 | <p><b>On change:</b> “On change” means that the value is sent if the measured value has changed by at least the configured value since the last transmission.</p> <p><b>Cyclic:</b> “Cyclic” means that the measured value is transmitted cyclically at the selected time.</p> <p><b>On change and cyclic:</b> The value is sent both on change and cyclic.</p> | <p>Cyclic</p> <p>On change &amp; cyclic</p> |
| -> Send cycle time <sup>4</sup> | This parameter is visible if the cyclical transmission is active. The send cycle time describes the time used between two cyclically transmitted telegrams  | 00:00:01 ... 00:00:10<br>... 18:12:15       |

<sup>1</sup>This parameter is only visible when the parameter “Send sensor fault” is set to “Cyclic” or “On change & cyclic” or “Always”.

<sup>2</sup>This parameter is only visible when the parameter “Filter type” is set to “Median” or “Low pass”.

<sup>3</sup>This parameter is only visible when the parameter “Send value” is set to “On change” or “On change & cyclic”.

<sup>4</sup>This parameter is only visible when the parameter “Send value” is set to “Cyclic” or “On change & cyclic”.

<sup>5</sup>This parameter is only visible when the parameter “Additional function” is set to “Send alarm” or “Send bit” or “Send byte” or “Send scene” or “Send percentage”. If the low threshold value is higher than the high threshold value and current value is exceed (high threshold) or dropped below (low threshold) the values, just low-level alarm value is sent over “Additional Value” object.

<sup>6</sup>This parameter is only visible when the parameter “Additional function” is set to “Send bit” or “Send byte” or “Send scene” or “Send percentage”.

<sup>7</sup>This parameter is only visible when the parameter “Send bit > Send low-level alarm” is set to “Yes”.

<sup>8</sup>This parameter is only visible when the parameter “Send bit > Send normal-level alarm” is set to “Yes”.

<sup>9</sup>This parameter is only visible when the parameter “Send bit > Send high-level alarm” is set to “Yes”.

## 4.6. Calculations

Calculation functions that are produced the weighted sensor values for special cases. To optimize or correct the sensor regulation in special cases (in large rooms, in presence of strong asymmetry of the sensor distribution, when the installation of the device is in a position not suitable, etc.), the device can use a weighted average between up to 4 sensor values (internal, external 1, external 2 and KNX object). The weighted rates can be in the range of 0 to 255 for each sensor. This means that each input value can be multiplied by in the range of 0 – 255.

Additionally, the alarm function is enabled via a parameter. This feature provides to send alarm value if the calculated value is out of the range of the threshold values.

### 4.6.1. Calculation X

This section describes how to configure the parameters for the Calculation X channels of the iSwitch+.




Fig. 31: Calculation X Page

Up to 7 sensor such as temperature, humidity, brightness, proximity, air quality, air pressure, wind speed, can be selected for calculation data type. Each selection has its own parameter configuration screen. Proximity, air pressure and wind speed data type can be used via just “KNX probe” source.

Calculation name:

Calculation data type:

| Source   | Internal                            | External 1                          | External 2                          | KNX Probe                           |
|----------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|
| Activate | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Weight   | 100 %                               | 100 %                               | 100 %                               | 100 %                               |

KNX probe calibration offset:  x0.1K

KNX probe surveillance time:  min (0 = disable)

Send changed by:

Send cycle time:  hh:mm:ss (0 = cyclic disable)

Send alarm:  no  yes

Alarm low threshold:  x0.1K

Alarm high threshold:  x0.1K

Fig. 32: Calculation for Temperature Page

The calculated value can periodically be sent on the bus with a specified transmission interval, and whenever a specified variation occurs. If KNX probe is selected as source, “KNX probe calibration offset” and “KNX probe surveillance time” parameter is visible. “KNX probe calibration offset” is used to calibrate the received value. “KNX probe surveillance time” parameter is used to determine the surveillance time for the KNX probe. If KNX probe value can’t be received per set time, an alarm object is sent to warn the source device.

To optimize or correct the sensor regulation in special cases (in large rooms, in presence of strong asymmetry of the sensor distribution, when the installation of the device is in a position not suitable, etc.), the device can then use a weighted average between up to 4 sensor values (internal, external 1, external 2 and KNX object).

## 4.6.1.1. Parameters List

| PARAMETERS  | DESCRIPTION   | VALUES   |
|---|---|--|
| <b>Calculation name</b>                               | This parameter is used to type a Led name. The name can be consisting of 40 characters.   | <b>40 bytes allowed</b>  |
| <b>Calculation data type</b>                          | This parameter is used to determine the data type to be taken into account for calculation.   | <b>None</b><br>Temperature<br>Humidity<br>Brightness<br>Proximity<br>Air quality<br>Air pressure<br>Wind speed |
| <b>Internal Activate</b>                              | This parameter is used to determine the activation of internal sensor for calculation.<br><br>If this parameter is checked, the internal sensor is taken into account for calculation.  | <b>Checked</b><br>Unchecked  |
| <b>-&gt; Internal Weight<sup>1</sup></b>              | This parameter is used to determine the weight coefficient of internal sensor for calculation.  | 0...100...255  |
| <b>External X Activate</b>                            | This parameter is used to determine the activation of external input for calculation.<br><br>If this parameter is checked, the external input is taken into account for calculation.    | <b>Checked</b><br>Unchecked  |
| <b>-&gt; External X Weight<sup>2</sup></b>            | This parameter is used to determine the weight coefficient of external input for calculation.   | 0...100...255  |
| <b>KNX Probe Activate</b>                             | This parameter is used to determine the activation of KNX probe object for calculation.<br><br>If this parameter is checked, the KNX probe value is taken into account for calculation. | <b>Checked</b><br>Unchecked  |
| <b>-&gt; KNX Probe Weight<sup>3</sup></b>             | This parameter is used to determine the weight coefficient of KNX probe value for calculation.  | 0...100...255  |
| <b>-&gt; KNX probe calibration offset<sup>3</sup></b> | This parameter is used to determine the calibration value is received from the KNX Probe temperature object.  | Values depend on DPT selection.  |
| <b>-&gt;KNX probe surveillance time<sup>3</sup></b>   | This parameter is used to determine the surveillance time for the KNX probe. If this parameter is   | <b>0...255</b>   |

|   |   |                                       |
|---|---|---------------------------------------|
|   | <p>configured higher than 0, "Probe Surveillance" object will be visible.</p> <p>E.g., if this parameter is configured as 10. Every 10 min the received value from KNX is taken into account for calculation.</p> |                                       |
| <b>Send changed by</b>                        | This parameter determines the minimum variation value for the output of calculation object to send a value.   | Values depend on DPT selection.       |
| <b>Send cycle time</b>                        | This parameter determines the time of control value to be sent periodically.  | 00:00:01 ... 00:00:00<br>... 18:12:15 |
| <b>Send alarm</b>                             | This parameter is used to enable the alarm objects to define a threshold value for alarm information.   | <b>No</b><br>Yes                      |
| <b>-&gt; Alarm low threshold<sup>4</sup></b>  | This parameter determines the calculation object's low threshold value.   | Values depend on DPT selection.       |
| <b>-&gt; Alarm high threshold<sup>4</sup></b> | This parameter determines the calculation object's high threshold value.  | Values depend on DPT selection.       |

<sup>1</sup>This parameter is only visible when the parameter "Internal Activate" is set to "Checked".

<sup>2</sup>This parameter is only visible when the parameter "External X Activate" is set to "Checked".

<sup>3</sup>This parameter is only visible when the parameter "KNX Probe Activate" is set to "Checked".

<sup>4</sup>This parameter is only visible when the parameter "Send alarm" is set to "Yes".

## 4.7. Room Controller Page

All configurations related to air conditioning control on the iSwitch+ are described in the sections of this chapter. This parameter page will be shown when it is enabled in the “General” parameter page section. The information about the “General” parameter configuration section is described after the theoretical control type expressions that are given below.

- 2 points/Proportional fan controller that can be used by main and additional heating/cooling systems.
- Thermostat weekly program.
- Energy saving function for thermostat functions.
- Temperature limitation for thermostat functions.

### 4.7.1. Control Types Theoretical Explanations

The room controller device can be used for only heating, only cooling or heating and cooling. If the room controller is in heating and cooling mode, the transition from heating to cooling or vice versa can occur automatically. The thermostat measures the actual temperature of the ambient air and continuously compares it to the set temperature, and the controller automatically calculates whether to send a control signal for heating or cooling. The control algorithm based on the difference between the desired setpoint temperature values and the measured actual temperature values processes a command value that can be either percentage or ON / OFF. The command, periodically or depending on the event, is transmitted to a KNX actuator device via a bus line with communication objects.

#### 4.7.1.1. 2-Points Control

This control algorithm, also known as ON / OFF, is the most classic and popular one. The algorithm follows a hysteresis cycle, allowing the system to switch ON / OFF. Hence, 2 switching levels are considered for switching.




Fig. 33: 2 – Points Control Hysteresis Cycle

## Heating mode

When the measured temperature is lower than the difference between the setpoint and the hysteresis value ( $T_{\text{setpoint}} - \Delta T_{\text{hysteresis}}$ ), the device activates the heating system by sending the KNX command to the actuator that controls the heating system via connected to a related group address. When the measured temperature reaches the setpoint temperature, the device sends a related command and deactivates the heating system. In this way, there are 2 decision thresholds to activate and deactivate the heating system. The first one is the temperature at which the device activates the system ( $T_{\text{setpoint}} - \Delta T_{\text{hysteresis}}$ ), and the second one is the temperature at which the device deactivates the heating system ( $T_{\text{setpoint}}$ ).

## Cooling mode

When the measured temperature is higher than the difference between the setpoint and the hysteresis value ( $T_{\text{setpoint}} + \Delta T_{\text{hysteresis}}$ ), the device activates the heating system by sending the KNX command to the actuator that controls the cooling system via connected to a related group address. When the measured temperature reaches the setpoint temperature, the device sends a related command and deactivates the cooling system. In this way, there are 2 decision thresholds to activate and deactivate the cooling system. The first one is the temperature at which the device activates the system ( $T_{\text{setpoint}} + \Delta T_{\text{hysteresis}}$ ), and the second one is the temperature at which the device deactivates the heating system ( $T_{\text{setpoint}}$ ).

There are 2 different parameters for heating and cooling hysteresis values in the ETS programme. Values differ depending on the system type.

### 4.7.1.2. Continuous (PI) Control

Proportional – Integral control (PI control) is explained by the relationship shown below:

$$\mathbf{control\ variable}(t) = Kp \times \mathbf{error}(t) + Ki \times \int_0^t \mathbf{error}(t) dt$$

whereby:

$$\mathbf{error}(t) = (\text{Setpoint} - \text{Measured temperature}) \text{ in heating}$$

$$\mathbf{error}(t) = (\text{Measured temperature} - \text{Setpoint}) \text{ in cooling}$$

$$Kp = \text{proportional constant}$$

$$Ki = \text{integral constant}$$

The control variable contains integral and proportional ( $Ki$  and  $Kp$ ) constants to eliminate errors. In practice, intuitively generated values are generally used.

Ex 1:

$$\mathbf{Proportional\ band\ BP\ [K]} = 100 / Kp \qquad \mathbf{Integral\ time\ Ti\ [min]} = Kp / Ki$$

The proportional band is the error value that determines the maximum deflection output as 100%.

For example, a regulator with a proportional band of 5 K provides a 100% control output when the Setpoint = 20°C and the measured temperature is ≤ 15°C in heating; in the cooling conduction mode, it provides a 100% control output when the Setpoint = 24°C and the measured temperature is ≥ 29°C. As shown in the figure, a regulator with a small proportional band tends to provide higher values of the control variable for small errors than a regulator with a higher proportional band.




Fig. 34: Continuous PI Control Proportional Band Widths

The integral time is the time required to repeat the value of the control variable of a purely proportional regulator when the error remains constant in time.

Ex 2:

For example, with a purely proportional controller in heating and with a value of proportional band of 4 K, if the setpoint is = 20°C and the measured temperature is = 18°C, the control variable assumes the value of 50%. With an integral time = 60 minutes, if the error remains constant, the control variable will take the value = 100% after 1 hour, i.e., a contribution equal to the value given by only proportional contribution will be added to the control variable.

In heating and air conditioning systems, a purely proportional controller is not able to guarantee the achievement of the setpoint. You should always introduce an integrated action for achieving the Setpoint: that is why the integral action is also called automatic reset.

### 4.7.1.3. PWM (PI) Control

The PWM (Pulse Width Modulation) proportional-integral controller allows the digital output to be set to ON and OFF by sampling an analogue control variable within a specified period. The controller runs periodically through a cycle and keeps its output ON for each period in proportion to the value of the control variable. As shown in the below figure, by varying the ratio between the “ON” time and the “OFF” time, the average activation time of the output changes, and as a result, the average heating or cooling power supplied by the room changes.

The cycle time for the control value for the PWM signal calculated from the PI controller's control value is specified. Depending on the control value, the selected cycle time is divided into an ON and OFF signal. Therefore, a control value output of 50 % with a PWM cycle of 12 min signifies an ON phase of 6 min. and an OFF phase of 6 min.




Fig. 35: PWM Control Sampling

This type of control is well suited for use with ON / OFF actuators, such as electrothermal actuators and drives for zone valves, which are less expensive than proportional actuators.

A distinctive advantage of this type of control is that it eliminates the inertia of the system: it allows significant energy savings because unnecessary interventions on the system introduced by the 2-point control with hysteresis are avoided and only the power is required to compensate for the losses.

Every time the changes the desired temperature setpoint is, the cycle time is interrupted, the control output is reprocessed and the PWM restarts with a new cycle: this allows the system to reach its steady state more quickly.


| Terminal Type          | Proportional Ban [K] | Integral Time [min] | Cycle Period [min] |
|------------------------|----------------------|---------------------|--------------------|
| Radiators              | 5                    | 150                 | 15-20              |
| Electrical heaters     | 4                    | 100                 | 15-20              |
| Fan-coil               | 4                    | 90                  | 15-20              |
| Floor radiant panels   | 5                    | 240                 | 15-20              |
| Ceiling radiant panels | 5                    | 100                 | 15-20              |

Table 5: Guidelines for choosing the proper parameters of a PMW PI controller

Guidelines for choosing the proper parameters of a PMW Proportional-Integral controller:

- Cycle time: for low-inertial systems such as heating and air conditioning systems, short cycle times must be chosen (10-15 minutes) to avoid oscillations of the room temperature.
- Narrow proportional band: wide and continuous oscillations of the room temperature, short setpoint settling time.
- Wide proportional band: small or no oscillations of the room temperature, long setpoint settling time.
- Short integral time: short setpoint settling time, continuous oscillations of the room temperature.
- Long integral time: long setpoint settling time, no oscillations of the room temperature.

## 4.7.2. Thermostat



**Fig. 36:** Room Controller Thermostat Configuration Section

### 4.7.2.1. Parameters List

| PARAMETERS             | DESCRIPTION  | VALUES                   |
|------------------------|--|--------------------------|
| <b>Thermostat name</b> | This parameter is used to type a Thermostat name. The name can be consisting of 40 characters. | <b>40 Bytes allowed</b>  |
| <b>Thermostat</b>      | This parameter is used to control the thermostat features.                                     | <b>Disable</b><br>Enable |

### 4.7.3. Thermostat - General

The thermostat function can be selected as the “master” controller or “slave” controller in the configuration settings in this section. When the selection is made as to the “master” controller, configuration sections and the communication objects are opened to define the thermostat functions. When the selection is made as to the “slave” controller, some configuration sections related to the thermostat functions are disabled. The slave controller must be connected to the master controller with the KNX communication object as it will operate as a dependent controller with commutations object. In thermostat slave mode, setpoint adjustment, thermostat activation control, heating/cooling switchover and operation mode control can be made. Also, LCD can be used as fan indicator in slave operation or fan controller isn’t used for thermostat.




Fig. 37: Room Controller Thermostat General Configuration Section

## 4.7.3.1. Parameters List

| PARAMETER  | DESCRIPTION  | VALUES   |
|--|--|--|
| <b>Thermostat mode</b>                           | The thermostat function's operating type is determined with this parameter.  | <b>Master</b><br>Slave   |
| <b>Temperature source</b>                        | This parameter determines the temperature source of room controller.<br><br>If thermostat temperature value is higher/lower than the setpoints of the protection mode's setpoint max/min limit values, the active operation mode is changed as Protection mode. After that the end-users can change the operation mode again.  | <b>Internal temperature</b><br>Temperature object<br>Calculation 1...6 |
| <b>Room controller mode<sup>1</sup></b>          | Room controller mode is determined with this parameter.  | <b>Heating</b><br>Cooling<br>Heating & Cooling                         |
| <b>HVAC mode after reset<sup>1</sup></b>         | This parameter determines the operating mode of the room controller after a reset occurs.<br><br><b>Ex:</b> When a power failure occurs.   | <b>Previous value</b><br>Comfort<br>Standby<br>Economy<br>Protection   |
| <b>Command value object<sup>2</sup></b>          | The object types of temperature command values for heating and cooling mode are determined with this parameter.  | <b>Common</b><br>Separated   |
| <b>Switch-over heating / cooling<sup>2</sup></b> | This parameter determines how the heating/cooling transition is made.<br><br>If heating/cooling switch-over mode isn't Automatic, the user can be configured heating or cooling setpoint.<br><br>If heating/cooling switch-over mode is Automatic, the user can't be configured that the cooling setpoint is higher than the heating setpoint. In automatic mode the cooling setpoint is equal the heating setpoint at least. If an input value that is higher than heating setpoint, is received over "Cooling [Operation Mode] Setpoint Temperature" object, received telegram is ignored. | <b>Via communication object</b><br>Automatic                           |

|  |   |  |
|--|---|--|
| <b>Room controller mode after reset<sup>3</sup></b>  | This parameter determines the room controller mode of the room controller after a reset occurs.<br><br><b>Ex:</b> When a power failure occurs.  | Heating<br>Cooling<br><b>Previous mode</b> |
| <b>Temp Unit</b>                                     | The temperature unit type to be used by thermostat objects is defined by this parameter.  | <b>Celsius</b><br>Fahrenheit               |
| <b>Manual setpoint type</b>                          | The desired temperature value can be controlled with individual or dependent setpoints by this parameter.<br><br><b>Individual setpoint:</b> The input value must be the desired setpoint.<br><br><b>Dependent setpoint:</b> The input value must be the difference of desired setpoint according to base setpoint. | <b>Individual</b><br>Dependent             |
| <b>Temperature limitation</b>                        | This parameter enables temperature limitation function of thermostat.   | <b>Disable</b><br>Enable                   |
| <b>Fan control used for room control<sup>1</sup></b> | This parameter determines the fan controls that are used inside or outside of the thermostat function.<br><br>If the it is selected to use outside of the thermostat function, just the fan states will be displayed on the device as fan indicators.   | <b>Disable</b><br>Enable                   |
| <b>Weekly program</b>                                | This parameter enables weekly program of thermostat.  | <b>Disable</b><br>Enable                   |

<sup>1</sup>This parameter is only visible when the parameter “Thermostat mode” is set to “Master”.

<sup>2</sup>This parameter is only visible when the parameter “Room controller mode” is set to “Heating / cooling”.

<sup>3</sup>This parameter is only visible when the parameter “Switch-over heating/cooling” is set to “Via object”.

### 4.7.4. Thermostat - Heating

The device’s operation principle of the heating feature is as follows: When the measured temperature is lower than the setpoint temperature, the device activates the heating system by sending a KNX command to the actuator that controls the heating system via connected to the related group address. When the measured temperature reaches the setpoint temperature, the device sends a related command and deactivates the heating system. The heating feature can be controlled with different types of configuration settings. These configuration settings are as follows;

Selection of the “Heating 2 – Points Control” parameter, 1-bit / 1-byte on/off control can be selected.

Selection of the “Heating PWM Control” parameter, 1-bit / 1-byte on/off control can be selected.

Selection of the “Heating Continuous Control” parameter, 1-byte proportional-integral control.

#### 4.7.4.1. Heating 2 – Points Control

When the measured temperature is lower than the difference between the setpoint and the hysteresis value ( $T_{\text{setpoint}} - \Delta T_{\text{hysteresis}}$ ), the device activates the heating system by sending a KNX command to the actuator that controls the heating system via connected to a related group address. When the measured temperature reaches the setpoint temperature, the device sends a related command and deactivates the heating system. In this way, there are 2 decision thresholds to activate and deactivate the heating system. The first one is the temperature at which the device activates the system ( $T_{\text{setpoint}} - \Delta T_{\text{hysteresis}}$ ), and the second one is the temperature at which the device deactivates the heating system ( $T_{\text{setpoint}}$ ).




Fig. 38: Heating 2-Points Control Configuration

## 4.7.4.2. Parameters List

| PARAMETER                        | DESCRIPTION   | VALUES                          |
|----------------------------------|---|---------------------------------|
| Heating control type             | This parameter determines the heating control type.   | 2 – points<br>PWM<br>Continuous |
| Hysteresis                       | This parameter determines the hysteresis value.   | 0.1K...2.0K                     |
| Object data type                 | This parameter is used to determine data type of control value object.                              | 0-1 (1 bit)<br>0-100% (1 byte)  |
| Invert control value             | This parameter is used to invert control output.  | No<br>Yes                       |
| Periodic sending time            | This parameter is used to periodically send the commands to the bus line.                           | 00:00:00 ... 18:12:15           |
| Control value requirement object | This parameter is used to send status information about the controller value of the heating system. | No<br>Yes                       |
| Additional heating system        | This parameter activates the additional heating system.   | No<br>Yes                       |

### 4.7.4.3. Heating PWM Control

The PWM (Pulse Width Modulation) proportional-integral controller allows the digital output to be set to ON and OFF by sampling an analogue control variable within a specified period. The controller runs periodically through a cycle and keeps its output ON for each period in proportion to the value of the control variable. By varying the ratio between the “ON” time and the “OFF” time of the heating system, the average activation time of the output changes, and as a result, the average heating power supplied by the room changes.

|   |  |
|---|--|
| <ul style="list-style-type: none"> <li>General</li> <li>+ Push Buttons</li> <li>+ External Inputs</li> <li>+ Leds</li> <li>+ Measurements</li> <li>+ Calculations</li> <li>- Room Controller</li> <li>- Thermostat             <ul style="list-style-type: none"> <li>General</li> <li style="background-color: #e0e0e0;">Heating</li> <li>Cooling</li> <li>Setpoints</li> <li>Temperature Limitation</li> <li>Energy Saving</li> <li>Fan Controller</li> <li>Weekly Program</li> </ul> </li> </ul> | <p>Heating control type <span style="float: right;">▼</span><br/>PWM</p> <hr/> <p>Type of heating system <span style="float: right;">▼</span><br/>warm water heating</p> <p>Proportional band 5.0K</p> <p>Integral time 150 min</p> <p>Control value minimum limit <span style="float: right;">▼</span><br/>0%</p> <p>Control value maximum limit <span style="float: right;">▼</span><br/>100%</p> <p>PWM cycle time <span style="float: right;">min</span><br/>15</p> <hr/> <p>Object data type <input checked="" type="radio"/> 0-1 (1 bit) <input type="radio"/> 0-100% (1 byte)</p> <p>Invert control value <input checked="" type="radio"/> no <input type="radio"/> yes</p> <p>Periodic sending time <input type="text" value="00:00:00"/> hh:mm:ss (0 = cyclic disable)</p> <p>Control value requirement object <input checked="" type="radio"/> no <input type="radio"/> yes</p> <hr/> <p>Additional heating system <input checked="" type="radio"/> no <input type="radio"/> yes</p> |
|---|--|

Fig. 39: Heating PWM Control Configuration

## 4.7.4.4. Parameters List

| PARAMETER                        | DESCRIPTION   | VALUES   |
|----------------------------------|---|--|
| Type of heating system           | This parameter determines the heating system to be controlled.                                      | <b>Warm water heating</b><br>Electric heating<br>Floor heating<br>Split unit<br>Fan coil<br>User defined |
| Proportional band (K)            | This parameter determines the proportional band.  | <b>5.0K</b> (0.5K...10.0K)   |
| Integral time (min)              | This parameter determines the integral time.  | <b>150</b> (0...255)   |
| Control value minimum (%)        | This parameter determines the output object's minimum control value.                                | <b>0%</b> (0%, 5%, 10%, 15%, 20%, 25%, 30%)  |
| Control value maximum (%)        | This parameter determines the output object's maximum control value.                                | <b>100%</b> (70%, 75%, 80%, 85%, 90%, %95, 100%)   |
| PWM cycle time (min)             | This parameter determines the PWM cycle time.   | <b>1...255</b>   |
| Object data type                 | This parameter is used to determine data type of control value object.                              | <b>0-1 (1 bit)</b><br>0-100% (1 byte)  |
| Invert control value             | This parameter is used to invert control output.  | <b>No</b><br>Yes   |
| Periodic sending time            | This parameter is used to periodically send the commands to the bus line.                           | <b>00:00:00 ... 18:12:15</b>   |
| Control value requirement object | This parameter is used to send status information about the controller value of the heating system. | <b>No</b><br>Yes   |

### 4.7.4.5. Heating Continuous Control

Proportional – Integral control (PI control) is explained by the relationship shown below:

$$control\ variable(t) = Kp \times error(t) + Ki \times \int_0^t error(t) dt$$

whereby:

$$error(t) = (Setpoint - Measured\ temperature) \text{ in heating}$$

$$error(t) = (Measured\ temperature - Setpoint) \text{ in cooling}$$

$$Kp = \text{proportional constant}$$

$$Ki = \text{integral constant}$$

The control variable contains integral and proportional ( $Ki$  and  $Kp$ ) constants to eliminate errors. In practice, intuitively generated values are generally used.

Ex 1:

$$Proportional\ band\ BP [K] = \frac{100}{Kp}$$

$$Integral\ time\ Ti [min] = Kp / Ki$$

The proportional band is the error value that determines the maximum deflection output as 100%.




Fig. 40: Heating Continuous Control Configuration

## 4.7.4.6. Parameters List

| PARAMETER                                | DESCRIPTION   | VALUES   |
|--|---|--|
| Type of heating system                   | This parameter determines the heating system to be controlled.                                      | <b>Warm water heating</b><br>Electric heating<br>Floor heating<br>Split unit<br>Fan coil<br>User defined |
| Proportional band (K)                    | This parameter determines the proportional band.  | <b>5.0K</b> (0.5K ... 10.0K)   |
| Integral time (min)                      | This parameter determines the integral time.  | <b>150</b> (0 ... 255)   |
| Control value minimum (%)                | This parameter determines the output object's minimum control value.                                | <b>0%</b> (0%, 5%, 10%, 15%, 20%, 25%, 30%)  |
| Control value maximum (%)                | This parameter determines the output object's maximum control value.                                | <b>100%</b> (70%, 75%, 80%, 85%, 90%, 95%, 100%)   |
| Minimum oscillation of value to send (%) | This parameter determines the minimum oscillation value for the output object to send a value.      | <b>3</b> (0...100)   |
| Periodic sending time                    | This parameter is used to periodically send the commands to the bus line.                           | <b>00:00:00 ... 18:12:15</b>   |
| Control value requirement object         | This parameter is used to send status information about the controller value of the heating system. | <b>No</b><br>Yes   |

### 4.7.3.7. Additional Heating System

All types of heating controls (2-points, PWM and continuous control) have additional heating system options. The additional heating system works in all control types with the same characteristics. The system activates itself according to the offset configuration. If  $(T_{\text{setpoint}} - \Delta T_{\text{offset}})$  is lower than the ambient room temperature, the additional heating system will be activated according to controller type.




Fig. 41: Additional Heating System Configuration

In additional heating control, 2 - Points and PI Continuous controller heat the room until the difference between  $(T_{\text{setpoint}} - T_{\text{room}})$  is equal to “Additional setpoint offset” parameter.




Fig. 42: 2 - Points Hysteresis Cycle for Additional Heating Control




Fig. 43: PI Continuous Graph for Additional Heating Control

## 4.7.3.7. Parameters List

| PARAMETER  | DESCRIPTION   | VALUES   |
|--|---|--|
| <b>Additional heating system</b>                 | This parameter activates the additional heating system.   | <b>No</b><br>Yes   |
| <b>Additional setpoint offset</b>                | This parameter determines the difference between the setpoint temperature value and the additional heating system's setpoint temperature value. | <b>0.5K ... 5.0K (°C)</b><br><b>0.9K ... 9.0K (°F)</b>   |
| <b>Additional heating control type</b>           | This parameter determines the additional heating system's control object type.  | <b>2 – points</b><br>PWM<br>Continuous   |
| <b>Additional heating control type: 2-points</b> |   |  |
| <b>Hysteresis Value</b>                          | This parameter determines the hysteresis value.   | <b>0.1K...2.0K (°C)</b><br><b>0.18K...3.6K (°F)</b>  |
| <b>Object type</b>                               | This parameter is used to determine the data type of the control value object.  | <b>0-1 (1 bit)</b><br>0-100% (1 byte)  |
| <b>Invert control value</b>                      | This parameter is used to invert control output.  | <b>No</b><br>Yes   |
| <b>Periodic sending time</b>                     | This parameter determines the time of control value to be sent periodically.  | <b>00:00:00 ... 18:12:15</b>   |
| <b>Control value requirement object</b>          | This parameter is used to send status information about the controller value of the additional heating system.                                  | <b>No</b><br>Yes   |
| <b>Additional heating control type: PWM</b>      |   |  |
| <b>Type of additional heating system</b>         | This parameter determines the heating system to be controlled.  | <b>Warm water heating</b><br>Electric heating<br>Floor heating<br>Split unit<br>Fan coil<br>User defined |

|   |  |  |
|---|--|--|
| <b>Proportional band</b>                | This parameter determines the proportional band.   | 0.5K... <b>5.0K</b> ... 10.0K (°C)<br>0.9K... <b>9.0K</b> ... 18.0K (°F) |
| <b>Integral time</b>                    | This parameter determines the integral time.   | 0 ... <b>90</b> ... 255  |
| <b>Control value minimum limit</b>      | This parameter determines the output object's minimum control value.   | <b>0%</b> , 5%, 10%, 15%, 20%, 25%, 30%)                                 |
| <b>Control value maximum limit</b>      | This parameter determines the output object's maximum control value.   | 70%, 75%, 80%, 85%, 90%, %95, <b>100%</b>                                |
| <b>PWM cycle time (min)</b>             | This parameter determines the PWM cycle time.  | 1...255  |
| <b>Object data type</b>                 | This parameter is used to determine data type of control value object.   | <b>0-1 (1 bit)</b><br>0-100% (1 byte)                                    |
| <b>Invert control value</b>             | This parameter is used to invert control output.   | <b>No</b><br>Yes   |
| <b>Periodic sending time</b>            | This parameter is used to periodically send the commands to the bus line.                                      | <b>00:00:00</b> ... 18:12:15   |
| <b>Control value requirement object</b> | This parameter is used to send status information about the controller value of the additional heating system. | <b>No</b><br>Yes   |

**Additional heating control type: Continuous**

|  |  |  |
|--|--|--|
| <b>Type of additional heating system</b> | This parameter determines the heating system to be controlled.       | Warm water heating<br>Electric heating<br>Floor heating<br>Split unit<br><b>Fan coil</b><br>User defined |
| <b>Proportional band</b>                 | This parameter determines the proportional band.                     | 0.5K... <b>5.0K</b> ... 10.0K (°C)<br>0.9K... <b>9.0K</b> ... 18.0K (°F)                                 |
| <b>Integral time</b>                     | This parameter determines the integral time.                         | 0 ... <b>90</b> ... 255  |
| <b>Control value minimum limit</b>       | This parameter determines the output object's minimum control value. | <b>0%</b> (0%, 5%, 10%, 15%, 20%, 25%, 30%)  |
| <b>Control value maximum limit</b>       | This parameter determines the output object's maximum control value. | <b>100%</b> (70%, 75%, 80%, 85%, 90%, %95, 100%)   |

|   |  |                              |
|---|--|------------------------------|
| <b>Minimum oscillation of value to send</b> | This parameter determines the minimum oscillation value for the output object to send a value.                 | <b>1 ... 100</b>             |
| <b>Periodic sending time</b>                | This parameter is used to periodically send the commands to the bus line.                                      | <b>00:00:00 ... 18:12:15</b> |
| <b>Control value requirement object</b>     | This parameter is used to send status information about the controller value of the additional heating system. | <b>No</b><br><b>Yes</b>      |

### 4.7.5. Thermostat - Cooling

The device’s operation principle of cooling feature is as follows: When the measured temperature is higher than the setpoint temperature, the device activates the cooling system by sending a KNX command to the actuator that controls the cooling system via connection to the related group address. When the measured temperature reaches the setpoint temperature, the device sends a related command and deactivates the cooling system. The cooling feature can be controlled with different types of configuration settings. These configuration settings are as follows;

Selection of the “Cooling 2 – Points Control” parameter, 1-bit / 1-byte on/off control can be selected.

Selection of the “Cooling Pwm Control” parameter, 1-bit / 1-byte on/off control can be selected.

Selection of the “Cooling Continuous Control” parameter, 1-byte proportional-integral control.

#### 4.7.5.1. Cooling 2 – Points Control

When the measured temperature is higher than the difference between the setpoint and the hysteresis value ( $T_{\text{setpoint}} + \Delta T_{\text{hysteresis}}$ ), the device activates the cooling system by sending a KNX command to the actuator that controls the cooling system via connected to a related group address. When the measured temperature reaches the setpoint temperature, the device sends a related command and deactivates the cooling system. In this way, there are 2 decision thresholds to activate and deactivate the cooling system. The first one is the temperature at which the device activates the cooling system ( $T_{\text{setpoint}} + \Delta T_{\text{hysteresis}}$ ), and the second one is the temperature at which the device deactivates the cooling system ( $T_{\text{setpoint}}$ ).




Fig. 44: Cooling 2-Points Control Configuration

## 4.7.5.2. Parameters List

| PARAMETER                               | DESCRIPTION   | VALUES  |
|---|---|---|
| <b>Cooling control type</b>             | This parameter determines the cooling control type.   | <b>2 – points</b><br>PWM<br>Continuous              |
| <b>Hysteresis</b>                       | This parameter determines the hysteresis value.   | <b>0.1K...2.0K (°C)</b><br><b>0.18K...3.6K (°F)</b> |
| <b>Invert control value</b>             | This parameter is used to invert control output.  | <b>No</b><br>Yes                                    |
| <b>Periodic sending time</b>            | This parameter is used to periodically send the commands to the bus line.                           | <b>00:00:00 ... 18:12:15</b>                        |
| <b>Control value requirement object</b> | This parameter is used to send status information about the controller value of the cooling system. | <b>No</b><br>Yes                                    |
| <b>Additional cooling system</b>        | This parameter activates the additional cooling system.   | <b>No</b><br>Yes                                    |

### 4.7.5.3. Cooling PWM Control

The PWM (Pulse Width Modulation) proportional-integral controller allows the digital output to be set to On and Off by sampling an analogue control variable within a specified time. The controller runs periodically through a cycle and keeps its output ON for each period in proportion to the value of the control variable. By varying the ratio between the “ON” time and the “OFF” time of the heating system, the average activation time of the output changes, and as a result, the average heating power supplied by the room changes.

|                   |                                  |  |
|-------------------|----------------------------------|--|
| General           | Cooling control type             | PWM  |
| + Push Buttons    | Type of cooling system           | cool ceiling   |
| + External Inputs | Proportional band                | 5.0K   |
| + Leds            | Integral time                    | 240 min  |
| + Measurements    | Control value minimum limit      | 0%   |
| + Calculations    | Control value maximum limit      | 100%   |
| - Room Controller | PWM cycle time                   | 1 min  |
| - Thermostat      | Object data type                 | <input checked="" type="radio"/> 0-1 (1 bit) <input type="radio"/> 0-100% (1 byte) |
| General           | Invert control value             | <input checked="" type="radio"/> no <input type="radio"/> yes                      |
| Cooling           | Periodic sending time            | 00:00:00 hh:mm:ss (0 = cyclic disable)   |
| Setpoints         | Control value requirement object | <input checked="" type="radio"/> no <input type="radio"/> yes                      |
| Energy Saving     | Additional cooling system        | <input checked="" type="radio"/> no <input type="radio"/> yes                      |
| LCD               |                                  |  |

Fig. 45: Cooling PWM Control Configuration

## 4.7.5.4. Parameters List

| PARAMETER                        | DESCRIPTION   | VALUES   |
|----------------------------------|---|--|
| Type of cooling system           | This parameter determines the cooling system to be controlled.                                      | <b>Cool ceiling</b><br>Split unit<br>Fan coil<br>User defined            |
| Proportional band (K)            | This parameter determines the proportional band.  | 0.5K... <b>4.0K</b> ... 10.0K (°C)<br>0.9K... <b>7.2K</b> ... 18.0K (°F) |
| Integral time (min)              | This parameter determines the integral time.  | 0... <b>90</b> ...255  |
| Control value minimum (%)        | This parameter determines the output object's minimum control value.                                | <b>0%</b> (0%, 5%, 10%, 15%, 20%, 25%, 30%)                              |
| Control value maximum (%)        | This parameter determines the output object's maximum control value.                                | <b>100%</b> (70%, 75%, 80%, 85%, 90%, %95, 100%)                         |
| PWM cycle time (min)             | This parameter determines the PWM cycle time.   | 1...255  |
| Object data type                 | This parameter is used to determine data type of control value object.                              | <b>0-1 (1 bit)</b><br>0-100% (1 byte)                                    |
| Invert control value             | This parameter is used to invert control output.  | <b>No</b><br>Yes   |
| Periodic sending time            | This parameter is used to periodically send the commands to the bus line.                           | <b>00:00:00</b> ... 18:12:15   |
| Control value requirement object | This parameter is used to send status information about the controller value of the cooling system. | <b>No</b><br>Yes   |
| Additional cooling system        | This parameter activates the additional cooling system.   | <b>No</b><br>Yes   |

### 4.7.5.5. Cooling Continuous Control

Proportional – Integral control (PI control) is explained by the relationship shown below:

$$control\ variable(t) = Kp \times error(t) + Ki \times \int_0^t error(t) dt$$

whereby:

$$error(t) = (Setpoint - Measured\ temperature) \text{ in heating}$$

$$error(t) = (Measured\ temperature - Setpoint) \text{ in cooling}$$

$$Kp = \text{proportional constant}$$

$$Ki = \text{integral constant}$$

The control variable contains integral and proportional ( $Ki$  and  $Kp$ ) constants to eliminate errors. In practice, intuitively generated values are generally used.

Ex 1:

$$Proportional\ band\ BP [K] = \frac{100}{Kp}$$

$$Integral\ time\ Ti [min] = \frac{Kp}{Ki}$$

The proportional band is the error value that determines the maximum deflection output as 100%.




Fig. 46: Cooling Continuous Control Configuration

## 4.7.5.6. Parameters List

| PARAMETER                                | DESCRIPTION   | VALUES   |
|--|---|--|
| Type of cooling system                   | This parameter determines the cooling system to be controlled.                                      | <b>Cool ceiling</b><br>Split unit<br>Fan coil<br>User defined            |
| Proportional band (K)                    | This parameter determines the proportional band.  | 0.5K... <b>5.0K</b> ... 10.0K (°C)<br>0.9K... <b>9.0K</b> ... 18.0K (°F) |
| Integral time (min)                      | This parameter determines the integral time.  | 0 ... <b>90</b> ... 255  |
| Control value minimum (%)                | This parameter determines the output object's minimum control value.                                | <b>0%</b> (0%, 5%, 10%, 15%, 20%, 25%, 30%)                              |
| Control value maximum (%)                | This parameter determines the output object's maximum control value.                                | <b>100%</b> (70%, 75%, 80%, 85%, 90%, 95%, 100%)                         |
| Minimum oscillation of value to send (%) | This parameter determines the minimum oscillation value for the output object to send a value.      | <b>1</b> ... 100   |
| Periodic sending time                    | This parameter is used to periodically send the commands to the bus line.                           | <b>00:00:00</b> ... 18:12:15   |
| Control value requirement object         | This parameter is used to send status information about the controller value of the cooling system. | <b>No</b><br>Yes   |

### 4.7.5.7. Additional Cooling System

All types of cooling controls (2-points, PWM and continuous control) have additional cooling system options. The additional cooling system works in all control types with the same characteristics. The system activates itself according to the offset configuration. If  $(T_{\text{setpoint}} + \Delta T_{\text{offset}})$  is higher than the ambient room temperature, the additional cooling system will be activated according to controller type.




Fig. 47: Additional Cooling System Configuration

In additional cooling control, 2 - Points and PI Continuous controller cool the room until the difference between  $(T_{\text{room}} - T_{\text{setpoint}})$  is equal to “Additional setpoint offset” parameter.




Fig. 48: 2 – Points Hysteresis Cycle for Additional Cooling Control




Fig. 49: PI Continuous Graph for Additional Cooling Control

## 4.7.5.8. Parameters List


| PARAMETER  | DESCRIPTION   | VALUES   |
|--|---|--|
| <b>Additional setpoint offset</b>                | This parameter determines the difference between the setpoint temperature value and the additional cooling system's setpoint temperature value. | <b>0.5K ... 5.0K</b> (°C)<br><b>0.9K ... 9.0K</b> (°F)                   |
| <b>Additional cooling control type</b>           | This parameter determines the additional cooling system's control object type.  | <b>2 – points</b><br>PWM<br>Continuous                                   |
| <b>Additional cooling control type: 2-points</b> |   |  |
| <b>Hysteresis Value</b>                          | This parameter determines the hysteresis value.   | <b>0.1K...2.0K</b> (°C)<br><b>0.18K...3.6K</b> (°F)                      |
| <b>Object type</b>                               | This parameter determines the additional cooling system's object type.  | <b>0-2 (1 bit)</b><br>0-100% (1 byte)                                    |
| <b>Invert control value</b>                      | This parameter is used to invert control output.  | <b>No</b><br>Yes   |
| <b>Periodic sending time</b>                     | This parameter determines the time of control value to be sent periodically.  | <b>00:00:00 ... 18:12:15</b>   |
| <b>Control value requirement object</b>          | This parameter is used to send status information about the controller value of the additional cooling system.                                  | <b>No</b><br>Yes   |
| <b>Additional cooling control type: PWM</b>      |   |  |
| <b>Type of additional cooling system</b>         | This parameter determines the cooling system to be controlled.  | <b>Cool ceiling</b><br>Split unit<br>Fan coil<br>User defined            |
| <b>Proportional band</b>                         | This parameter determines the proportional band.  | <b>0.5K... 5.0K ... 10.0K</b> (°C)<br><b>0.9K... 9.0K ... 18.0K</b> (°F) |
| <b>Integral time</b>                             | This parameter determines the integral time.  | <b>0 ... 240 ... 255</b>   |
| <b>Control value minimum limit</b>               | This parameter determines the output object's minimum control value.  | <b>0%, 5%, 10%, 15%, 20%, 25%, 30%</b>                                   |

|  |  |  |
|--|--|--|
| <b>Control value maximum limit</b>                 | This parameter determines the output object's maximum control value.   | 70%, 75%, 80%, 85%, 90%, %95, <b>100%</b>                                |
| <b>PWM cycle time (min)</b>                        | This parameter determines the PWM cycle time.  | 1...255  |
| <b>Object data type</b>                            | This parameter is used to determine data type of control value object.   | <b>0-2 (1 bit)</b><br>0-100% (1 byte)                                    |
| <b>Invert control value</b>                        | It is used to invert control output.   | <b>No</b><br>Yes   |
| <b>Periodic sending time</b>                       | This parameter is used to periodically send the commands to the bus line.                                      | <b>00:00:00 ... 18:12:15</b>   |
| <b>Control value requirement object</b>            | This parameter is used to send status information about the controller value of the additional cooling system. | <b>No</b><br>Yes   |
| <b>Additional cooling control type: Continuous</b> |  |  |
| <b>Type of additional cooling system</b>           | This parameter determines the cooling system to be controlled.   | Cool ceiling<br>Split unit<br><b>Fan coil</b><br>User defined            |
| <b>Proportional band</b>                           | This parameter determines the proportional band.   | 0.5K... <b>5.0K</b> ... 10.0K (°C)<br>0.9K... <b>9.0K</b> ... 18.0K (°F) |
| <b>Integral time</b>                               | This parameter determines the integral time.   | 0 ... <b>240</b> ... 255   |
| <b>Control value minimum limit</b>                 | This parameter determines the output object's minimum control value.   | <b>0%</b> , 5%, 10%, 15%, 20%, 25%, 30%                                  |
| <b>Control value maximum limit</b>                 | This parameter determines the output object's maximum control value.   | 70%, 75%, 80%, 85%, 90%, %95, <b>100%</b>                                |
| <b>Minimum oscillation of value to send</b>        | This parameter determines the minimum oscillation value for the output object to send a value.                 | <b>1</b> ... 100   |
| <b>Periodic sending time</b>                       | This parameter is used to periodically send the commands to the bus line.                                      | <b>00:00:00 ... 18:12:15</b>   |
| <b>Control value requirement object</b>            | This parameter is used to send status information about the controller value of the additional cooling system. | <b>No</b><br>Yes   |

### 4.7.6. Thermostat - Heating & Cooling

Heating & Cooling mode is generally used when there are 2 different heating and cooling sources or only 1 source that has both heating and cooling ability together. If the heating/cooling sources are different, the command value object parameter should be selected as “2 separated objects”. However, if heating and cooling are obtained from the same source, the command value object parameter should be selected as “1 common object”. Additionally, in this mode, the distinction is made whether the switch-over between heating and cooling is to be affected automatically or in a controlled way through the communication object.

**In the automatic switch-over option:** for the heating, the controller will turn on the heating when the room temperature has fallen below a preset dead band limit. As soon as the room temperature is exceeding the heating setpoint, the control will turn off the heating in the heating & cooling mode. For the cooling, the controller will turn on the cooling system when the room temperature has exceeded a preset dead band limit. As soon as the room temperature is reaching above the cooling setpoint, the control will turn off the cooling system in the heating & cooling mode.



**Fig. 50:** Automatic Heating & Cooling Mode Switch

For a proper behavior of the automatic switch function, the setpoint of the Cooling mode is required to be higher than that of the Heating mode.

**In via communication object option:** In this option, there is no dead band concept compared to the automatic option. The main difference between automatic and communication object options; the mode switch-over between modes is made manually.

## 4.7.6.1. Parameters List

In heating & cooling mode, cooling configurations and heating configurations can be made separately mentioned before. In this section, only extra parameters for this mode are described below.

| PARAMETER                               | DESCRIPTION   | VALUES   |
|---|---|--|
| <b>Thermostat mode</b>                  | The thermostat mode's operating type is determined with this parameter.   | <b>Master</b><br>Slave   |
| <b>Temperature source</b>               | This parameter determines whether the temperature source is external or internal.                               | <b>Internal temperature</b><br>Temperature object<br>Calculation 1...6 |
| <b>Room controller mode</b>             | Room controller mode is determined with this parameter.   | <b>Heating</b><br>Cooling<br>Heating & Cooling                         |
| <b>Command value object</b>             | The object types of temperature command values for heating and cooling mode are determined with this parameter. | <b>Common</b><br>Separated   |
| <b>Switch-over heating/cooling</b>      | This parameter determines how the heating/cooling transition is made.   | Via object<br><b>Automatic</b>   |
| <b>Room controller mode after reset</b> | This parameter determines the room controller mode after the device restarts.                                   | <b>Previous mode</b><br>Heating<br>Cooling                             |

### 4.7.7. Thermostat - Set Points

Temperature setpoints for heating or cooling modes are configured in this section. The operation modes such as comfort, standby, night and frost protection of “heating”, “cooling” and “heating & cooling” modes can be separately specified from this section. The temperature setpoint value can be configured to send to the KNX bus line with 4 different settings such as “Disable”, “Periodically”, “On change” and “Periodically and on change”. Besides, how much the maximum bandwidth setting will be configured for that increasing or decreasing the temperature value manually can be determined. Moreover, it is possible to set which setpoint values will be used when there is a power failure.




Fig. 51: Set Points Configuration

**Note:** If Heating/Cooling automatic mode is used HVAC mode setpoints must be in the range of manual setpoint. Otherwise, shifts in setpoints may occur in automatic heating-cooling transitions.

**Note:** Heating and Cooling setpoints limited with 10°C to 40°C for Comfort, Standby and Economy modes, 0°C to 15.5°C for frost protection mode and 25°C to 45°C for heat protection mode. User can change setpoint temperature bases with this ranges. If an attempt is made to apply a setpoint base other than the limits from the setpoint base objects, the limit value becomes valid.

## 4.7.7.1. Parameters List

| PARAMETER                                | DESCRIPTION  | VALUES  |
|--|--|---|
| <b>Sending of setpoint</b>               | <p>This parameter allows sending the setpoint temperature value information.</p> <p><b>On change:</b> The Temperature value information is sent when the setpoint temperature value changes by 1 K.</p> <p><b>Periodically:</b> The Temperature value information is sent periodically.</p> <p><b>Periodically and on change:</b> The Temperature value information is sent periodically or when the setpoint temperature value changed 1 K.</p> | <p>Disable</p> <p><b>On change</b></p> <p>Cyclic</p> <p>On change &amp; cyclic</p>    |
| <b>Setpoint sending time<sup>1</sup></b> | This parameter determines the time of the setpoint temperature value to be sent periodically.  |   |
| <b>Manual setpoint range</b>             | This parameter configures the maximum and minimum limit values for the setpoint temperature value.   | <p>±1.0 ... <b>±3.0</b> ... ±10.0 (°C)</p> <p>±1.8 ... <b>±5.4</b> ... ±22.5 (°F)</p> |
| <b>Manual setpoint step</b>              | This parameter configures the maximum and minimum limit values for the setpoint temperature value.   | <p>0.1K ... <b>0.5K</b> ... 3.5K (°C)</p> <p>0.18K ... <b>0.9K</b> ... 6.3K (°F)</p>  |
| <b>Manual setpoint reset after</b>       | This parameter determines the time of value to be sent setpoint reset after.   | <b>00:00:00</b> ... 18:12:15  |
| <b>Manual setpoint after reset</b>       | <p>This parameter determines the behavior of the manual setpoint's value after device reset.</p> <p><b>Reset manual setpoint:</b> The manual setpoint is reset after device reset.</p> <p><b>Keep manual setpoint:</b> The manual setpoint is continued after device reset.</p>  | <p>Reset manual setpoint</p> <p><b>Keep manual setpoint</b></p>                       |
| <b>HVAC mode change behavior</b>         | <p>This parameter determines the behavior of the manual setpoint's value after receiving the new set mode.</p> <p><b>Reset manual setpoint:</b> The manual setpoint is reset after the new setting mode is received with this option.</p>  | <p>Reset manual setpoint</p> <p><b>Keep manual setpoint</b></p>                       |

|   |   |  |
|---|---|--|
|   | <p><b>Keep manual setpoint:</b> The manual setpoint is continued after the new setting mode is received with this option.</p>   |  |
| <b>Setpoint after reset</b>               | This parameter determines the setpoint temperature after a reset for any reason, such as power failure.   | <p>Parameter value</p> <p><b>Previous value</b></p>                              |
| <b>Setpoint type</b>                      | <p>The desired temperature value can be controlled with individual or dependent setpoints by this parameter.</p> <p>If dependent mode is selected the setpoints of comfort and protect can be configured as individual setpoint. Standby and economy mode's setpoints can be configured as dependent setpoint.</p> <p>Even dependent mode is selected, all of the operation mode's setpoints can be change via object separately. So, if the comfort's setpoint is changed economy or standby's setpoints aren't updated according to comfort setpoint.</p> | <p><b>Individual</b></p> <p>Dependent</p>  |
| <b>Change setpoint via objects</b>        | With this parameter, setpoint objects for all operation mode are visible.   | <p><b>No</b></p> <p>Yes</p>  |
| <b>Comfort Mode Activate</b>              | <p>This parameter is used to determine the activation of comfort mode.</p> <p>If this parameter is checked, comfort mode can be useable.</p>  | <p><b>Checked</b></p> <p>Unchecked</p>   |
| <b>Comfort Mode Heating Setpoint (°C)</b> | The desired temperature value for comfort mode is configured with this parameter.   | <p>10.0 ... <b>21.0</b> ... 40 (°C)</p> <p>50.0 ... <b>69.8</b> ... 104 (°F)</p> |
| <b>Comfort Mode Cooling Setpoint (°C)</b> | The desired temperature value for comfort mode is configured with this parameter.   | <p>10.0 ... <b>21.0</b> ... 40 (°C)</p> <p>50.0 ... <b>69.8</b> ... 104 (°F)</p> |
| <b>Standby Mode Activate</b>              | <p>This parameter is used to determine the activation of standby mode.</p> <p>If this parameter is checked, standby mode can be useable.</p>  | <p><b>Checked</b></p> <p>Unchecked</p>   |
| <b>Standby Mode Heating Setpoint (°C)</b> | The desired temperature value of heating for standby mode is configured with this parameter.  | <p>10.0 ... <b>19.0</b> ... 40 (°C)</p> <p>50.0 ... <b>66.2</b> ... 104 (°F)</p> |
| <b>Standby Mode Cooling Setpoint (°C)</b> | The desired temperature value for standby mode is configured with this parameter.   | <p>10.0 ... <b>25.0</b> ... 40 (°C)</p> <p>50.0 ... <b>77.0</b> ... 104 (°F)</p> |

|  |   |   |
|--|---|---|
| <b>Economy Mode Activate</b>                 | This parameter is used to determine the activation of economy mode.<br><br>If this parameter is checked, economy mode can be useable.       | <b>Checked</b><br><br>Unchecked                                       |
| <b>Economy Mode Heating Setpoint (°C)</b>    | The desired temperature value of heating for economy mode is configured with this parameter.  | 10.0 ... <b>15.0</b> ... 40 (°C)<br>50.0 ... <b>59.0</b> ... 104 (°F) |
| <b>Economy Mode Cooling Setpoint (°C)</b>    | The desired temperature value of cooling for economy mode is configured with this parameter   | 10.0 ... <b>27.0</b> ... 40 (°C)<br>50.0 ... <b>80.6</b> ... 104 (°F) |
| <b>Protection Mode Activate</b>              | This parameter is used to determine the activation of protection mode.<br><br>If this parameter is checked, protection mode can be useable. | <b>Checked</b><br><br>Unchecked                                       |
| <b>Protection Mode Heating Setpoint (°C)</b> | The desired temperature value of heating for protection mode is configured with this parameter.   | 0.0 ... <b>7.0</b> ... 15.5 (°C)<br>32.0... <b>44.6</b> ... 59.9 (°F) |
| <b>Protection Mode Heating Setpoint (°C)</b> | The desired temperature value of cooling for protection mode is configured with this parameter  | 25.0... <b>35.0</b> ...45.0 (°C)<br>77.0... <b>95.0</b> ...113.0 (°F) |

\*1 This parameter is only visible when the parameter "Sending of setpoint" is set to "Periodically" or "periodically and on change".

### 4.7.8. Thermostat – Temperature Limitation

Using the limit temperature, the controller's control value for this stage can be set to 0 on reaching a parameterized temperature. In this way, exceeding (heating) or dropping below (cooling) this temperature can be prevented. An example of the usage of the limit temperature is floor heating, where exceeding a specific temperature must be prevented to protect the material of the floor.




Fig. 52: Temperature Limitation Configuration

## 4.7.8.1. Parameters List

| PARAMETER   | DESCRIPTION   | VALUES   |
|---|---|--|
| <b>Heating Controller Limitation Activate</b>                 | This parameter is used to activate limit temperature for heating controller.  | <b>No</b><br>Yes   |
| <b>Heating Controller Limitation Activate: Yes</b>            |   |  |
| <b>Temperature Source</b>                                     | This parameter is used to determine the source of temperature for limitation function.<br><br>It is not suitable to use the same temperature sensor for the measurement of the room temperature and for the measurement of the limit temperature.                     | Internal temperature<br><b>Temperature object</b><br>Calculation 1...6 |
| <b>Temperature Limit</b>                                      | This parameter is used to determine the limit temperature that is not allowed to be exceeded (heating). If the temperature reaches this value, the control value is immediately set to 0.   | 1... <b>30</b> ...60 (°C)<br>32... <b>86</b> ...140 (°F)               |
| <b>Temperature Limit Hysteresis</b>                           | This parameter is used to determine the hysteresis on the limit temperature specifies the value by which the limit temperature must be dropped below again (heating) before the controller becomes active again.  | 0.5K ... <b>1K</b> ... 5K (°C)<br>0.9K ... <b>1.8K</b> ... 9K (°F)     |
| <b>Integral on temperature limitation<sup>1</sup></b>         | This parameter is used to decide what is to happen to the I-proportion on reaching the limit temperature.<br><br><b>Freeze:</b> Keeps the current accumulated error caused by I-proportion.<br><br><b>Reset:</b> Resets the accumulated error caused by I-proportion. | <b>Freeze</b><br>Reset   |
| <b>Additional Heating Controller Limitation Activate</b>      | This parameter is used to activate limit temperature for additional heating controller.   | <b>No</b><br>Yes   |
| <b>Additional Heating Controller Limitation Activate: Yes</b> |   |  |
| <b>Temperature Source</b>                                     | This parameter is used to determine the source of temperature for limitation function.<br><br>It is not suitable to use the same temperature sensor for the measurement of the room temperature and for the measurement of the limit temperature.                     | Internal temperature<br><b>Temperature object</b><br>Calculation 1...6 |
| <b>Temperature Limit</b>                                      | This parameter is used to determine the hysteresis on the limit temperature specifies the value by which the limit temperature must be dropped below again  | 1... <b>30</b> ...60 (°C)<br>32... <b>86</b> ...140 (°F)               |

|  |   |  |
|--|---|--|
|  | (heating) before the controller becomes active again.   |  |
| <b>Temperature Limit Hysteresis</b>                      | This parameter is used to determine the hysteresis on the limit temperature specifies the value by which the limit temperature must be dropped below again (heating) before the controller becomes active again.  | 0.5K ... <b>1K</b> ... 5K (°C)<br>0.9K ... <b>1.8K</b> ... 9K (°F)     |
| <b>Integral on temperature limitation<sup>2</sup></b>    | This parameter is used to decide what is to happen to the I-proportion on reaching the limit temperature.<br><br><b>Freeze:</b> Keeps the current accumulated error caused by I-proportion.<br><br><b>Reset:</b> Resets the accumulated error caused by I-proportion. | <b>Freeze</b><br>Reset   |
| <b>Cooling Controller Limitation Activate</b>            | This parameter is used to activate limit temperature for cooling controller.  | <b>No</b><br>Yes   |
| <b>Cooling Controller Limitation Activate: Yes</b>       |   |  |
| <b>Temperature Source</b>                                | This parameter is used to determine the source of temperature for limitation function.<br><br>It is not suitable to use the same temperature sensor for the measurement of the room temperature and for the measurement of the limit temperature.                     | Internal temperature<br><b>Temperature object</b><br>Calculation 1...6 |
| <b>Temperature Limit</b>                                 | This parameter is used to determine the limit temperature that is not allowed to be dropped below (cooling). If the temperature reaches this value, the control value is immediately set to 0.  | 1... <b>10</b> ...60 (°C)<br>32... <b>50</b> ...140 (°F)               |
| <b>Temperature Limit Hysteresis</b>                      | This parameter is used to determine the hysteresis on the limit temperature specifies the value by which the limit temperature must be exceeded (cooling) before the controller becomes active again.   | 0.5K ... <b>1K</b> ... 5K (°C)<br>0.9K ... <b>1.8K</b> ... 9K (°F)     |
| <b>Integral on temperature limitation<sup>3</sup></b>    | This parameter is used to decide what is to happen to the I-proportion on reaching the limit temperature.<br><br><b>Freeze:</b> Keeps the current accumulated error caused by I-proportion.<br><br><b>Reset:</b> Resets the accumulated error caused by I-proportion. | <b>Freeze</b><br>Reset   |
| <b>Additional Cooling Controller Limitation Activate</b> | This parameter is used to activate limit temperature for additional cooling controller.   | <b>No</b><br>Yes   |

| Additional Cooling Controller Limitation Activate: Yes |  |   |
|--|--|---|
| <b>Temperature Source</b>                              | <p>This parameter is used to determine the source of temperature for limitation function.</p> <p>It is not suitable to use the same temperature sensor for the measurement of the room temperature and for the measurement of the limit temperature.</p>                     | <p>Internal temperature</p> <p><b>Temperature object</b></p> <p>Calculation 1...6</p> |
| <b>Temperature Limit</b>                               | <p>This parameter is used to determine the limit temperature that is not allowed to be dropped below (cooling). If the temperature reaches this value, the control value is immediately set to 0.</p>  | <p>1... <b>10</b> ...60 (°C)</p> <p>32... <b>50</b> ...140 (°F)</p>                   |
| <b>Temperature Limit Hysteresis</b>                    | <p>This parameter is used to determine the hysteresis on the limit temperature specifies the value by which the limit temperature must be exceeded (cooling) before the controller becomes active again.</p>   | <p>0.5K ... <b>1K</b> ... 5K (°C)</p> <p>0.9K ... <b>1.8K</b> ... 9K (°F)</p>         |
| <b>Integral on temperature limitation<sup>4</sup></b>  | <p>This parameter is used to decide what is to happen to the I-proportion on reaching the limit temperature.</p> <p><b>Freeze:</b> Keeps the current accumulated error caused by I-proportion.</p> <p><b>Reset:</b> Resets the accumulated error caused by I-proportion.</p> | <p><b>Freeze</b></p> <p>Reset</p>   |

<sup>\*1</sup> This parameter is only visible when heating controller type is set to "PWM" or "continuous".

<sup>\*2</sup> This parameter is only visible when additional heating controller type is set to "PWM" or "continuous".

<sup>\*3</sup> This parameter is only visible when cooling controller type is set to "PWM" or "continuous".

<sup>\*4</sup> This parameter is only visible when additional cooling controller type is set to "PWM" or "continuous".

### 4.7.9. Thermostat – Energy Saving

In order to realize energy-saving functions, **window contacts** (to detect the opening of windows or doors), **presence and movement sensors** and **card holders** can be used.

The Energy saving folder includes:

- Window contacts
- Presence sensors
- Card holder

The screenshot shows the configuration interface for the Energy Saving folder. On the left is a navigation menu with categories: General, Push Buttons, External Inputs, Leds, Measurements, Calculations, Room Controller, Thermostat (General, Heating, Cooling, Setpoints), Energy Saving (selected), and LCD. The main area is titled 'Energy Saving' and contains three configuration sections:

- Window Contact:**
  - Activate:  no  yes
  - Source table:
 

| Source | External 1 | External 2 | Object 1                            | Object 2                 |
|--------|------------|------------|-------------------------------------|--------------------------|
| Source | Disabled   | Disabled   | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
  - Invert inputs: invert none
  - Logic operation: AND
  - Activation delay: 00:00:10 h:mm:ss
- Presence Input:**
  - Activate:  no  yes
  - Source table:
 

| Source | External 1 | External 2 | Object 1                 | Object 2                            |
|--------|------------|------------|--------------------------|-------------------------------------|
| Source | Disabled   | Disabled   | <input type="checkbox"/> | <input checked="" type="checkbox"/> |
  - Invert inputs: invert none
  - Logic operation: OR
  - Function: comfort extension and limitation
  - Limitation mode:  comfort - standby  comfort - economy
  - Activation delay: 00:00:10 h:mm:ss
- Card Holder:**
  - Activate:  no  yes
  - Source table:
 

| Source | External 1 | External 2 | Object 1                            | Object 2                            |
|--------|------------|------------|-------------------------------------|-------------------------------------|
| Source | Disabled   | Disabled   | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
  - Invert inputs: invert both
  - Logic operation: OR
  - Card inserted mode: comfort
  - Activation delay: 00:00:10 h:mm:ss
  - Card removed mode: standby
  - Deactivation delay: 00:00:10 h:mm:ss

Fig. 53: Energy Saving Configuration

## 4.7.9.1. Window Contacts

In order to realize energy-saving functions, window contacts (to detect the opening of windows or doors) can be used. The device can acquire the status of a contact by means of an external(digital) input or receive the status of two objects connected to different KNX devices (binary inputs, pushbutton interfaces). When a window opens, the device automatically switches to Protection operating mode; when it closes, the device automatically returns to the previous operating mode. When acquiring more than one signal, they can be combined in logical OR, AND or XOR according to the “Logic operation” parameter.

When an open window is detected, the operating mode is forced into building protection and remains forced until all windows are closed. The application program features an activation time parameter for opening delay to discriminate between an occasional, short opening and a long opening, which justifies the energy saving mode recall.

After activation delay the operation mode is changed. Also, if fan control is enabled for the current thermostat control, the fan mode is set “Auto”. The operation mode, fan level and fan mode cannot be updated via KNX bus. Window contact function has the highest priority between thermostat energy saving functions. Also, has absolute priority over the operating mode forced by the weekly program and over the HVAC mode forced by supervisor through the communication object HVAC Forced mode in DPT 20.102

If the operation mode input object is received a telegram, operation mode’s icon flashes on the LCD for the end-users to indicate “energy saving” activated. And if the fan level or fan mode input object is received a telegram, locked icon flashes on the LCD for the end-users to indicate that this function is locked because of energy saving. These cases continue until the window contact input object is received a telegram or the external input is triggered for deactivation the energy saving.

## 4.7.9.2. Parameters List

| PARAMETER                              | DESCRIPTION  | VALUES  |
|--|--|---|
| <b>Window Contact Activate</b>         | This parameter is used to enable window contact function for thermostat energy saving. Two 1-bit objects are visible when it is enabled. | <b>No</b><br>Yes  |
| <b>Window Contact Activate: Yes</b>    |  |   |
| <b>External X Source</b>               | If this parameter is checked, the External X input is selected as a trigger for the window contact function to be activated.             | <b>Disabled</b><br>Checked<br>Unchecked                 |
| <b>Object X Source</b>                 | If this parameter is checked, the Object X is selected as a trigger for the window contact function to be activated.                     | <b>Checked</b><br>Unchecked                             |
| <b>-&gt; Invert inputs<sup>1</sup></b> | This parameter determines how to use the input objects.  | <b>Invert none</b><br>Invert input 1 / 2<br>Invert both |
| <b>Logic operation</b>                 | This parameter is used to combine the inputs with logical operations.  | <b>OR</b><br>AND<br>XOR                                 |
| <b>Activation delay</b>                | This parameter is used to determine activation delay time. The energy saving function is delayed for the specified time.                 | 00:00:00... <b>00:00:10</b><br>...18.12.15              |

<sup>1</sup>This parameter is only visible when the parameter "Object X Source" is set to "Checked".

## 4.7.9.3. Presence Input

Presence input function includes a set of optional features, oriented to energy saving, which become available when the device is configured as integrated controller. This function is **only active if the actual operating mode is set to comfort**.

Generally speaking, if a human presence is detected and limited to the occupancy period, the comfort operating mode can be extended; vice versa, if no presence is detected, the comfort operating mode can be limited, because no longer necessary.

If one of the presence inputs objects or the external input selected as presence input, is received a telegram, it is triggered for activation. When acquiring more than one signal, they can be combined in logical OR, AND or XOR according to the “Logic operation” parameter.

In case a forced HVAC mode is used by supervisor through the communication object HVAC forced mode in DPT 20.102, the forced operating mode has a higher priority compared to the mode foreseen by the presence input function, so it will prevail.

In case the energy saving function is carried out through window contacts, the system switches to building protection mode when detecting an open window. Window contact function has a higher priority compared to both the forced mode and the mode foreseen by the presence input function.

There are three presence input function modes: **comfort extension**, **comfort limitation** and a combination of these two modes called **comfort extension and limitation**.

Comfort extension:

If during this time, a presence is detected, the operating mode remains comfort except for even if the operating mode is forced by the user or the weekly program function shifts to economy or standby. However, if the operation mode is set to protection, energy saving mode is interrupted until when the operation mode is comfort again while the presence input is still active. In this case, or if the operation mode input object is received a telegram except for “comfort” and “protection”, the telegram is saved to use after comfort extension.

If the operation mode input object is received a telegram, the operation mode’s icon flashes on the LCD for the end-users to indicate “energy saving” activated. If the fan level or fan mode input object is received a telegram, the locked icon flashes on the LCD for the end-users to indicate that this function is locked because of energy saving.

Comfort limitation:

If one of the presence input objects is set or the digital input selected as presence input is triggered for deactivation (the end-users left the room) and the operation mode is not forced, after the function active time, the operation mode is set from “Comfort” to the mode which is determined via “Limitation mode” parameter until the presence input object is set or the digital input selected as presence input is triggered for activation (the end-users entered the room). If the operation mode is set to protection, energy saving mode is interrupted until when the operation mode is comfort again while the presence input is still inactive.

Comfort extension and comfort limitation:

This mode is a combination of comfort extension and comfort limitation modes.

## 4.7.9.4 Parameters List

| PARAMETER                                | DESCRIPTION  | VALUES   |
|--|--|--|
| <b>Presence Input Activate</b>           | This parameter is used to enable presence input function for thermostat energy saving. Two 1-bit objects are visible when it is enabled. | <b>No</b><br>Yes   |
| <b>Presence Input Activate: Yes</b>      |  |  |
| <b>External X Source</b>                 | If this parameter is checked, the External X input is selected as a trigger for the presence input function to be activated.             | <b>Disabled</b><br>Checked<br>Unchecked  |
| <b>Object X Source</b>                   | If this parameter is checked, the Object X is selected as a trigger for the presence input function to be activated.                     | <b>Checked</b><br>Unchecked  |
| <b>-&gt; Invert inputs<sup>1</sup></b>   | This parameter determines how to use the input objects.  | <b>Invert none</b><br>Invert input 1 / 2<br>Invert both                            |
| <b>Logic operation</b>                   | This parameter is used to combine the inputs with logical operations.  | <b>OR</b><br>AND<br>XOR  |
| <b>Activation delay</b>                  | This parameter is used to determine activation delay time. The energy saving function is delayed for the specified time.                 | 00:00:00... <b>00:00:10</b><br>...18.12.15   |
| <b>Function</b>                          | This parameter is used to determine how to use the energy saving function for presence input.  | <b>Comfort extension</b><br>Comfort limitation<br>Comfort extension and limitation |
| <b>-&gt; Limitation mode<sup>2</sup></b> | It is used to determine the operation modes which will be set for the energy saving function in comfort limitation mode.                 | <b>Comfort – standby</b><br>Comfort - economy                                      |

<sup>1</sup>This parameter is only visible when the parameter “Object X Source” is set to “Checked”.

<sup>2</sup>This parameter is only visible when the parameter “Function” is set to “Comfort limitation” or “Comfort extension and limitation”.

## 4.7.9.5. Card Holder

If the card holder input object is set or the digital input selected as card holder input is triggered for activation (the end-users entered the room with card) and comfort extension mode is not active and the operation mode is not forced, then the operation mode is set as the mode via “Card insertion HVAC mode” parameter after the function active time via “Activation delay on card insertion” parameter.

Otherwise, if card holder input object is set or the digital input selected as card holder input is triggered for deactivation (the end-users left the room with card) and comfort extension mode is not active and the operation mode is not forced, then the operation mode is set as the mode via “Card removal HVAC mode” parameter after the function active time via “Activation delay on card removal” parameter.

When acquiring more than one signal, they can be combined in logical OR, AND or XOR according to the “Logic operation” parameter.

Card holder function has the lowest priority between thermostat energy saving functions.

## 4.7.9.6 Parameters List

| PARAMETER                              | DESCRIPTION   | VALUES   |
|--|---|--|
| <b>Card Holder Activate</b>            | This parameter is used to enable card holder function for thermostat energy saving. Two 1-bit objects are visible when it is enabled. | <b>No</b><br>Yes   |
| <b>Card Holder Activate: Yes</b>       |   |  |
| <b>External X Source</b>               | If this parameter is checked, the External X input is selected as a trigger for card holder function to be activated.                 | <b>Disabled</b><br>Checked<br>Unchecked                    |
| <b>Object X Source</b>                 | If this parameter is checked, the Object X is selected as a trigger for the card holder function to be activated.                     | <b>Checked</b><br>Unchecked                                |
| <b>-&gt; Invert inputs<sup>1</sup></b> | This parameter determines how to use the input objects.   | <b>Invert none</b><br>Invert input 1 / 2<br>Invert both    |
| <b>Logic operation</b>                 | This parameter is used to combine the inputs with logical operations.   | <b>OR</b><br>AND<br>XOR                                    |
| <b>Card inserted mode</b>              | This parameter is used to determine the operation mode which is set, when card insertion.   | Auto<br><b>Comfort</b><br>Standby<br>Economy<br>Protection |
| <b>Activation delay</b>                | This parameter is used to determine the activation delay time for card insertion.   | 00:00:00... <b>00:00:10</b><br>...18.12.15                 |
| <b>Card removed mode</b>               | This parameter is used to determine the operation mode which is set, when card removal.   | Auto<br>Comfort<br><b>Standby</b><br>Economy<br>Protection |
| <b>Deactivation delay</b>              | This parameter is used to determine the activation delay time for card removal.   | 00:00:00... <b>00:00:10</b><br>...18.12.15                 |

<sup>1</sup>This parameter is only visible when the parameter "Object X Source" is set to "Checked".

### 4.7.10. Thermostat – Fan Controller

If the parameter “Fan control used for room control” is set to “Enabled” from the “General” parameter page, the configuration page that is related to fan controller is now opened as “Fan Controller” under the “Room Controller” parameter page instead of the “LCD” parameter page.

The configuration settings in this section are configured such as, the selection of the fan speed level of the device to be used, the fan speed transitions in regard to the percentage value to be changed, the fan controller type selection, delay time for starting and delay time for stopping the fan and other arrangements related to fan control.

#### 4.7.10.1. Fan 2-Points Control

This type of fan control is similar to the 2 points control with hysteresis: the fan speed is activated/deactivated according to the difference between the desired temperature and the measured temperature. The relevant difference with the 2 points algorithm with hysteresis is that, in this case, there is not a single stage on which the hysteresis loop is executed, by setting the thresholds for switching on and off of the speed, but five stages may exist.

|                     | Level 1 | Level 2 | Level 3 | Level 4 | Level 5 |
|---------------------|---------|---------|---------|---------|---------|
| Fan Level Threshold | 0.5K    | 1.0K    | 1.5K    | 2.0K    | 3.0K    |

|         | Fan Heating Mode | Fan Cooling Mode |
|---------|------------------|------------------|
| Level 1 | 1                | 1                |
| Level 2 | 20               | 20               |
| Level 3 | 50               | 50               |
| Level 4 | 70               | 70               |
| Level 5 | 90               | 90               |

Fig. 54: Fan Controller 2-Points Control Configuration

This means that a speed level corresponds to each stage and when the difference between the measured temperature and the desired temperature causes the activation of a further speed.




Fig. 55: Fan Controller 2-Points Control Cycle for Heating

The figure in the above graph refers to the speed control of the fan with three operating stages as regards the heating. Looking at the graph, it has to be noted that for each stage there is a hysteresis loop, as well as at any speed are assigned two thresholds which determine the activation and deactivation. The thresholds are determined by the values set in the application program and can be summarized as follows:

- Speed 1 (1st stage) – The speed is turned ON when the value of the room temperature is lower than the value ( $T_{set} - \text{Threshold Speed1} - \text{hysteresis}$ ) and turned OFF when the room temperature value reaches the value ( $T_{set} - \text{Threshold Speed1}$ ); the first speed is also switched OFF when a higher speed must be turned ON. The default value for the parameter Threshold Speed1 = 0 K.
- Speed 2 (2nd stage) – The speed is turned ON when the value of the room temperature is lower than the value ( $T_{set} - \text{Threshold Speed2} - \text{hysteresis}$ ) and turned OFF when the room temperature value reaches the value ( $T_{set} - \text{Threshold Speed 2}$ ); the second speed is also switched OFF when Speed 3 must be turned ON.
- Speed 3 (3rd stage) – The speed is turned ON when the value of the room temperature is lower than the value ( $T_{set} - \text{Threshold Speed3} - \text{hysteresis}$ ) and turned OFF when the room temperature value reaches the value ( $T_{set} - \text{Threshold Speed 3}$ ).
- Speed 4 (4rd stage) – The speed is turned ON when the value of the room temperature is lower than the value ( $T_{set} - \text{Threshold Speed 4} - \text{hysteresis}$ ) and turned OFF when the room temperature value reaches the value ( $T_{set} - \text{Threshold Speed 4}$ ).

- Speed 5 (5rd stage) – The speed is turned ON when the value of the room temperature is lower than the value ( $T_{set} - \text{Threshold Speed 5} - \text{hysteresis}$ ) and turned OFF when the room temperature value reaches the value ( $T_{set} - \text{Threshold Speed 5}$ ).




Fig. 56: Fan Controller 2-Points Control Cycle for Cooling

The figure in the above graph refers to the speed control of the fan with three operating stages as regards the cooling. Looking at the graph, it has to be noted that for each stage there is a hysteresis loop, as well as at any speed are assigned two thresholds which determine the activation and deactivation. The thresholds are determined by the values set in the application program and can be summarized as follows:

- Speed 1 (1st stage) – The speed is turned ON when the value of the room temperature is higher than the value ( $T_{set} + \text{Threshold Speed1} + \text{hysteresis}$ ) and turned OFF when the room temperature value reaches the value ( $T_{set} + \text{Threshold Speed1}$ ); the first speed is also switched OFF when a higher speed must be turned ON. The default value for the parameter Threshold Speed1 = 0 K.
- Speed 2 (2nd stage) – The speed is turned ON when the value of the room temperature is higher than the value ( $T_{set} + \text{Threshold Speed2} + \text{hysteresis}$ ) and turned OFF when the room temperature value reaches the value ( $T_{set} + \text{Threshold Speed2}$ ); the second speed is also switched OFF when Speed 3 must be turned ON.
- Speed 3 (3rd stage) – The speed is turned ON when the value of the room temperature is higher than the value ( $T_{set} + \text{Threshold Speed3} + \text{hysteresis}$ ) and turned OFF when the room temperature value reaches the value ( $T_{set} + \text{Threshold Speed3}$ ).
- Speed 4 (4rd stage) – The speed is turned ON when the value of the room temperature is higher than the value ( $T_{set} + \text{Threshold Speed 4} + \text{hysteresis}$ ) and turned OFF when the room temperature value reaches the value ( $T_{set} + \text{Threshold Speed 4}$ )
- Speed 5 (5rd stage) – The speed is turned ON when the value of the room temperature is higher than the value ( $T_{set} + \text{Threshold Speed 5} + \text{hysteresis}$ ) and turned OFF when the room temperature value reaches the value ( $T_{set} + \text{Threshold Speed 5}$ )

If “Fan level 1-byte data type” is selected as “Enumerated”, what fan speed calculated according to above graph, is sent over 1 byte object. For example; If fan speed was calculated as speed 2, 2 is sent over fan speed object.

If “Fan level 1-byte data type” is selected as “Scaling”, fan level scaling value is sent according to fan level limits table. For example; if “Fan level 2 threshold value” is 40% and fan speed was calculated as speed 2, %40 value is sent over fan speed object.

### 4.7.10.2. Fan Proportional Control

Proportional – Integral control (PI control) is explained by the relationship shown below:

$$control\ variable(t) = Kp \times error(t)$$

whereby:

$$error(t) = (Setpoint - Measured\ temperature)\ in\ heating$$

$$error(t) = (Measured\ temperature - Setpoint)\ in\ cooling$$

$$Kp = proportional\ constant$$

The screenshot displays the configuration page for a Fan Controller. On the left is a navigation menu with categories like General, Push Buttons, External Inputs, Leds, Measurements, Calculations, Room Controller, Thermostat, and LCD. The 'Fan Controller' section is selected. The main area contains the following settings:

- Number of fan level:** 5
- Fan Channels:** A table with columns for Channel, Heating, Additional Heating, Cooling, and Additional Cooling. The 'Activate' row has checkmarks in the Heating and Cooling columns.
- Fan level control type:** 1 byte
- Fan level 1-byte data type:** scaling (selected)
- Fan level periodic sending time:** 00:00:00
- Fan mode control object:** 0:manual / 1:auto (selected)
- Fan Controller:**
  - Fan control type:** proportional (selected)
  - Fan speed hysteresis:** 5 %
  - Proportional band:** 5.0K
- Fan Level Limits:** A table with columns for Level, Fan Heating Mode, and Fan Cooling Mode.
 

|         | Fan Heating Mode |   | Fan Cooling Mode |   |
|---------|------------------|---|------------------|---|
| Level 1 | 1                | % | 1                | % |
| Level 2 | 20               | % | 20               | % |
| Level 3 | 50               | % | 50               | % |
| Level 4 | 70               | % | 70               | % |
| Level 5 | 90               | % | 90               | % |
- Fan start delay time:** 00:00:00
- Fan stop delay time:** 00:00:00
- Fan off level control:** no (selected)
- Fan manual step object:** disable
- Fan manual reset action:** no action
- Fan level after reset:** previous value

Fig. 57: Fan Controller Proportional Control Configuration

The control variable contains proportional ( $Kp$ ) constants to eliminate errors. In practice, intuitively generated values are generally used.

$$\text{Proportional band BP [K]} = 100 / Kp$$

The proportional band is the error value that determines the maximum deflection output as 100%.

For example, a regulator with a proportional band of 5 K provides a 100% control output when the Setpoint = 20°C and the measured temperature is ≤ 15°C in heating; in the cooling conduction mode, it provides a 100% control output when the Setpoint = 24°C and the measured temperature is ≥ 29°C. As shown in the figure, a regulator with a small proportional band tends to provide higher values of the control variable for small errors than a regulator with a higher proportional band.




Fig. 58: Fan Controller Proportional Control

The control output is compared to the limit value of fan speed. The fan speed is assigned according to whether the limit values is exceeded or below.

For example, fan level limits are assigned subsequently as 1, 20, 50, 70 and 90 for heating or cooling mode. Assume that the current working mode is Heating and the fan proportional controller generates %65 control value. The control value is compared to fan level limits and as seen the %65 control value is higher than the limits value of levels 1, 2 and 3. So, the fan level is assigned to Level 3.

**Note:** Fan controller have feedback objects for syncing with controlled device. These objects are not for changing fan level but showing actual value of controlled device. For changing fan level manually manual fan level objects should be used.

### 4.7.10.3. Parameters List

| PARAMETER                                   | DESCRIPTION  | VALUES   |
|---|--|--|
| Number of fan level                         | The number of fan levels is determined with this parameter.  | 1...5  |
| Channel Heating Activate                    | This parameter allows the fan controls to work with the heating system.<br><br>If the heating system is checked, the fan can't connect to the additional heating system at the same time.  | Checked<br>Unchecked                           |
| Channel Additional Heating Activate         | This parameter allows the fan controls to work with the additional heating system.<br><br>If the additional heating system is checked, the fan can't connect to the heating system at the same time.   | Checked<br>Unchecked                           |
| Channel Cooling Activate                    | This parameter allows the fan controls to work with the cooling system.<br><br>If the cooling system is checked, the fan can't connect to the additional cooling system at the same time.  | Checked<br>Unchecked                           |
| Channel Additional Cooling Activate         | This parameter allows the fan controls to work with the cooling system.<br><br>If the additional cooling system is checked, the fan can't connect to the cooling system at the same time.  | Checked<br>Unchecked                           |
| Fan level control object                    | This parameter allows the control of the fan speed with 1-bit individual or 1 byte or 1 bit /1 byte object.  | 1 bit<br>1 byte<br>1 bit / 1 byte              |
| -> Fan level control data type <sup>1</sup> | This parameter is used to determine with which data type the fan level is sent to the bus.<br><br><b>Enumerated:</b> 0~5 value is sent.<br><br><b>Scaling:</b> The percentage equivalent of the fan level value in the fan level limits table. | Enumerated<br>Scaling                          |
| Fan level periodic sending time             | This parameter determines the time of the fan level value to be sent periodically.   | 00:00:00...18:12:15                            |
| Fan mode control object                     | Manual or automatic fan speed control is selected with this parameter.   | 1: manual / 0: auto<br><br>0: manual / 1: auto |

|  |  |   |
|--|--|---|
| <b>Fan control type</b>                        | This parameter determines the fan controller type.   | <b>2-points</b><br>Proportional   |
| <b>-&gt; Fan speed hysteresis<sup>2</sup></b>  | This parameter determines the fan speed hysteresis value at which switchover to the next fan speed occurs.<br><br>Using hysteresis avoids continual switching between the fan speeds caused by fluctuating input signals around the limit value.   | Values depend on fan controller type  |
| <b>-&gt; Fan Level X Threshold<sup>2</sup></b> | This parameter determines the fan level X threshold value.   | 0.5K...5.0K (°C)<br>0.9K... 18.0K (°F)  |
| <b>-&gt; Proportional band<sup>3</sup></b>     | This parameter determines the proportional band of the fan controller.   | 0.5K... <b>5K</b> ...10.0K (°C)<br>0.9K... <b>9K</b> ...18.0K (°F)  |
| <b>Fan Heating Mode Level [1...5]</b>          | The lower limit value of the 1...5 speed is determined with this parameter.  | 1...100   |
| <b>Fan Cooling Mode Level X</b>                | The lower limit value of the 1...5 speed is determined with this parameter.  | 1...100   |
| <b>Fan start delay time</b>                    | This parameter is used to determine the delay time for switching to a higher fan speed than zero.  | <b>00:00:00</b> ...18:12:15   |
| <b>Fan stop delay time</b>                     | This parameter is used to determine the delay time for switching to zero fan speed.  | <b>00:00:00</b> ...18:12:15   |
| <b>Fan off level control</b>                   | This parameter is used to enable fan off level control.  | <b>No</b><br>Yes  |
| <b>-&gt; Fan off level<sup>4</sup></b>         | This parameter determines the speed of the fan off state.  | Values depend on number of fan level.   |
| <b>Fan manual step object</b>                  | This parameter allows the control of the fan speed with 1 – bit object   | <b>Disable</b><br>Increase/decrease (1.007)<br>Up/down (1.008)  |
| <b>Fan manual reset action</b>                 | This parameter is used to determine what the action is after the value of controller that is connected to fan, is zero in fan manual mode.<br><br><b>No action:</b> Do nothing, continue to work.<br><br><b>Reset current fan level, hold manual level:</b> Current manual fan level resets but the previous manual level saves in memory. When the controller value is higher than zero again or manual fan level is changed with | No action<br><br><b>Reset current fan level, hold manual level</b><br><br>Reset current fan level, reset manual level |

|                              |   |  |
|------------------------------|---|--|
|                              | <p>the object or thermostat extension of the push button, the manual fan level begins with the value in memory.</p> <p><b>Reset current fan level, reset manual level:</b> Manual fan levels that are current and saved in memory, reset.</p> |  |
| <b>Fan level after reset</b> | The desired fan level after a power failure is determined with this object.   | <p><b>Previous value</b></p> <p>Off</p> <p>Level 1...5</p> <p>Auto</p> |

\*1 This parameter is only visible when the parameter "Fan level control object" is set to "1 byte" or "1 bit / 1 byte".

\*2 This parameter is only visible when the parameter "Fan control type" is set to "2-points".

\*3 This parameter is only visible when the parameter "Fan control type" is set to "Proportional".

\*4 This parameter is only visible when the parameter "Fan off level control" is set to "Yes".

### 4.7.11. Thermostat – Weekly Program

Weekly Thermostat Program can be configured over the device. The weekly program works with if HVAC mode is Auto.

If HVAC mode is set over object as Auto but the “Thermostat Time” object hasn’t been received yet and until the “Thermostat Time” object is received, weekly program doesn’t work. During the weekly program runs, the users can change the HVAC mode anytime.

If “Weekly program” parameter is selected as “enable” and “Thermostat Time” object was received, thermostat runs according to weekly program table. If weekly program is active, but any time zone isn’t configured, Auto HVAC mode is ended and the HVAC mode switches Comfort mode.

If Auto HVAC mode is activated, the active HVAC mode’s icon flashes on the LCD for the end-users to indicate “Week Program” is activated.

| General               | Weekly Program | Monday | Tuesday | Wednesday | Thursday | Friday | Saturday | Sunday |
|-----------------------|----------------|--------|---------|-----------|----------|--------|----------|--------|
| + Push Buttons        | Zone 1 Mode    | none ▾ | none ▾  | none ▾    | none ▾   | none ▾ | none ▾   | none ▾ |
| + External Inputs     | Zone 2 Mode    | none ▾ | none ▾  | none ▾    | none ▾   | none ▾ | none ▾   | none ▾ |
| + Leds                | Zone 3 Mode    | none ▾ | none ▾  | none ▾    | none ▾   | none ▾ | none ▾   | none ▾ |
| + Measurements        | Zone 4 Mode    | none ▾ | none ▾  | none ▾    | none ▾   | none ▾ | none ▾   | none ▾ |
| + Calculations        |                |        |         |           |          |        |          |        |
| - Room Controller     |                |        |         |           |          |        |          |        |
| - Thermostat          |                |        |         |           |          |        |          |        |
| General               |                |        |         |           |          |        |          |        |
| Heating               |                |        |         |           |          |        |          |        |
| Cooling               |                |        |         |           |          |        |          |        |
| Setpoints             |                |        |         |           |          |        |          |        |
| Energy Saving         |                |        |         |           |          |        |          |        |
| <b>Weekly Program</b> |                |        |         |           |          |        |          |        |
| LCD                   |                |        |         |           |          |        |          |        |

**Fig. 59:** Weekly Program Configuration

## 4.7.11.1. Parameters List

| PARAMETER                          | DESCRIPTION  | VALUES   |
|------------------------------------|--|--|
| <b>Zone X Mode</b>                 | This parameter is used to determine which HVAC mode will be active according to selected day, hour and minute. | <b>None</b><br>Comfort<br>Standby<br>Economy<br>Protection |
| <b>=&gt; Zone X Hour</b>           | This parameter is used to determine the hour that the HVAC mode will be active.                                | <b>0 ... 23</b>  |
| <b>=&gt; Zone X Minute</b>         | This parameter is used to determine the minute that the HVAC mode will be active.                              | <b>0 ... 59</b>  |
| <b>Auto switch-over HVAC modes</b> | If this parameter is enabled, HVAC mode is changed according to the weekly program table.                      | <b>Disable</b><br>Enable                                   |

## 4.8. LCD Page

There is an LCD located in the middle of the device, vertically positioned, 40 x 90 mm (G x Y) sized and configurable backlight intensity. The configuration settings made with the ETS software and the symbols of the following controls can be displayed on the screen.

- Informs the users via LCD icons on error and emergency situations.
- Displays the values (room temperature, temperature setpoint, humidity, concentration of CO2, outdoor temperature) depending on the configuration done with ETS.
- LCD backlight control via brightness sensor.

| Symbol  | Meaning   | Symbol  | Meaning   |
|---|---|---|---|
|    | Temperature (°C or °F), relative humidity (percentage %) and CO2 concentration. |    | Heating (When the symbol is steady, it indicates that the device is in heating mode. If the heating system is active the heating symbol flashes.) |
|    | Fan Control (Automatic fan mode option and up to 5 fan levels control option.)  |    | Cooling (When the symbol is steady, it indicates that the device is in cooling mode. If the cooling system is active the cooling symbol flashes.) |
|  | Internal temperature information  |  | Economy mode  |
|  | External temperature information  |  | Protection mode   |
|  | Setpoint temperature information  |  | Comfort mode  |
|  | Alarm indicator   |  | Standby mode  |
|  | Locked indicator  |  | ON / OFF indicator  |

Table 6: Symbols that can be activated on the LCD screen

| Error Code | Cause  |
|------------|--|
| E0.1       | Integrated temperature sensor fault          |
| E0.2       | Integrated humidity sensor fault             |
| E0.3       | Integrated air quality sensor fault          |
| E0.4       | Integrated brightness sensor fault           |
| E0.5       | External input - 1 sensor fault              |
| E0.6       | External input - 2 sensor fault              |
| E1.1       | Temperature sensor displayed value overflow  |
| E1.2       | Humidity sensor displayed value overflow     |
| E1.3       | Air quality sensor displayed value overflow  |
| E1.8       | Outdoor temperature displayed value overflow |

Table 7: Displayable Error Codes

### 4.8.1. General

This parameter can be used to adjust the brightness level of the display, to show the actual temperature, the outside temperature, the relative humidity, and the air quality level, to configure switching time between them, to show whether the horizontal lines will appear on the display, to control the display on/off status information.

LCD screen is used for room controller to show ambient room temperature, setpoint temperature, ambient humidity, ambient air quality, active HVAC mode, active control mode (heating/cooling) etc.

Fig. 60: LCD General Configuration Section

Also, if fan controller is not used for the room controller or thermostat mode is slave, LCD screen can be used as fan indicator. If LCD is used as fan indicator mode, additional parameters are visible to display the values properly.

Fig. 61: LCD Fan Indicator Parameters

## 4.8.1.1. Parameters List

| PARAMETER   | DESCRIPTION   | VALUES  |
|---|---|---|
| Enable  | This parameter is used to control the LCD features.   | No<br>Yes   |
| Illumination  | The illumination of the display is controlled with this parameter.<br><b>Always off:</b> LCD illumination is always off.<br><b>Always on:</b> LCD illumination is always on.<br><b>Auto switch down brightness:</b> The display is turned off or switches to a new illumination level after the set time (1...255 sec) elapsed.<br><b>Ambient brightness:</b> Adjustment the LCD brightness based on ambient brightness sensor. | Always off<br><b>Always on</b><br>Auto switch down brightness<br>Ambient brightness         |
| -> Brightness (%) <sup>1</sup>                        | The brightness of the LCD is configured with this parameter. This parameter can be updated via "LCD Brightness" object.   | 10 ... 100  |
| -> Time for switch down brightness (sec) <sup>2</sup> | The brightness time of the LCD is configured with this parameter.   | 1 ... 10 ... 255  |
| -> Brightness after time (%) <sup>2</sup>             | The brightness of the LCD screen is determined after the time defined by this parameter is over.  | 10 ... 20 ... 100   |
| -> Brightness min (%) <sup>3</sup>                    | The minimum brightness of the LCD is configured with this parameter.  | 10 ... 20 ... 100   |
| -> Brightness max (%) <sup>3</sup>                    | The maximum brightness of the LCD is configured with this parameter.  | 10 ... 100  |
| Temperature unit                                      | The temperature unit type to be displayed is defined by this parameter.   | <b>Celcius</b><br>Fahrenheit  |
| Display multiple values                               | It is determined with this parameter whether the setpoint temperature, air quality, humidity, outdoor temperature information will appear in the main display, and then switch between them automatically.  | No<br>Yes   |
| -> Displayed value <sup>4</sup>                       | The value to be displayed on the screen is selected with this parameter.<br><i>If this parameter selected as None, nothing is displayed on value digit segments.</i>  | <b>Actual temperature</b><br>Setpoint temperature<br>Outdoor temperature<br>Humidity Sensor |

|  |  |   |
|--|--|---|
|  |  | Air quality                             |
| -> Room Temp Activate <sup>5</sup>               | The value to be displayed on the screen is selected with this parameter.   | Unchecked<br><b>Checked</b>             |
| -> Setpoint Temp Activate <sup>5</sup>           | Whether the setpoint temperature is displayed on the LCD screen is determined with this parameter.   | <b>Unchecked</b><br>Checked             |
| -> Outdoor Temp Activate <sup>5</sup>            | Whether the outdoor temperature is displayed on the LCD screen is determined by this parameter.  | <b>Unchecked</b><br>Checked             |
| -> Humidity Activate <sup>5</sup>                | Whether the humidity is displayed on the LCD screen is determined by this parameter.   | <b>Unchecked</b><br>Checked             |
| -> Air quality Activate <sup>5</sup>             | Whether the air quality is displayed on the LCD screen is determined by this parameter.  | <b>Unchecked</b><br>Checked             |
| -> Time between values <sup>5</sup>              | With this parameter, the switching time of the value on the main screen is determined.   | 1 ... 5 ... 255                         |
| Display horizontal lines                         | Whether the horizontal separating lines are displayed on the LCD screen is determined with this parameter.   | <b>Disabled</b><br>Enabled              |
| Display On / Off indicator                       | Whether the On / Off indicator is displayed on the LCD screen is determined with this parameter.   | <b>Disabled</b><br>Enabled              |
| -> On off indicator controlled by <sup>6</sup>   | This parameter is used to determine who to be controlled the on/off indicator.<br><br><b>Thermostat:</b> Shows the status of room controller.<br><br><b>Object:</b> Shows the value of object. | <b>Thermostat</b><br>Object             |
| -> On off indicator object polarity <sup>7</sup> | The On / Off indicator's operation mode is determined with this parameter.   | <b>0: Off / 1: On</b><br>1: Off / 0: On |
| Fan indicator                                    | This parameter is used to determine that LCD is used as a fan indicator. If fan control is used for the room controller, LCD can't be used as fan indicator.                                   | <b>Disabled</b><br>Enabled              |

<sup>1</sup> This parameter is only visible when the parameter "Illumination" is set to "Always on" or "Auto switch down brightness".

<sup>2</sup> This parameter is only visible when the parameter "Illumination" is set to "Auto switch down brightness".

<sup>3</sup> This parameter is only visible when the parameter "Illumination" is set to "Ambient brightness".

<sup>4</sup> This parameter is only visible when the parameter "Display multiple values" is set to "No".

<sup>5</sup> This parameter is only visible when the parameter "Display multiple values" is set to "Yes".

<sup>6</sup> This parameter is only visible when the parameter "Display on off indicator" is set to "Yes".

<sup>7</sup> This parameter is only visible when the parameter "On off indicator controlled by" is set to "Object".

## 5. ETS Objects List & Descriptions

The iSwitch+ KNX Room Controllers can communicate via the KNX bus line. In this section, the group objects of the iSwitch+ KNX Room Controllers are described, which of these group objects are visible and capable of being linked with group addresses are explained in sub-sections.

| No                            | Name     | Function                       | DTP Type | Length   | Flags |   |   |   |   |
|-------------------------------|----------|--------------------------------|----------|----------|-------|---|---|---|---|
|                               |          |                                |          |          | C     | R | W | T | U |
| 1                             | General  | In operation                   | 1.002    | 1 bit    | X     |   |   | X |   |
| 2                             | General  | Navigation Led                 | 1.001    | 1 bit    | X     |   | X |   |   |
| 3                             | General  | Error Identification           | 16.000   | 14 bytes | X     |   |   | X |   |
| 10,18,26,34,42,50,58,66,74,82 | Button X | Disable                        | 1.003    | 1 bit    | X     |   | X |   |   |
| 11,19,27,35,43,51,59,67,75,83 | Button X | Status                         | 1.003    | 1 bit    | X     | X |   | X |   |
| 12,20,28,36,44,52,60,68,76,84 | Button X | Switch                         | 1.001    | 1 bit    | X     | X | X | X | X |
|                               |          | Shutter UP/DOWN                | 1.008    | 1 bit    | X     |   | X | X |   |
|                               |          | Forced Operation – Switch      | 2.001    | 2 bits   | X     |   |   | X |   |
|                               |          | Forced Operation – Percent     | 5.001    | 1 byte   | X     |   |   | X |   |
|                               |          | Forced Operation – Decimal     | 5.005    | 1 byte   | X     |   |   | X |   |
|                               |          | Forced Operation – Scene       | 17.001   | 1 byte   | X     |   |   | X |   |
|                               |          | Forced Operation – Colour      | 7.600    | 2 bytes  | X     |   |   | X |   |
|                               |          | Forced Operation – Temperature | 9.001    | 2 bytes  | X     |   |   | X |   |
|                               |          | Forced Operation – Brightness  | 9.004    | 2 bytes  | X     |   |   | X |   |
|                               |          | Forced Operation – RGB         | 232.600  | 3 bytes  | X     |   |   | X |   |
|                               |          | Scene                          | 18.001   | 1 byte   | X     |   |   | X |   |
|                               |          | Mode Selection                 | 20.102   | 1 byte   | X     |   | X | X |   |
|                               |          | Sequence                       | 1.001    | 1 bit    | X     | X |   | X |   |
|                               |          |                                | 5.010    | 1 byte   | X     | X |   | X |   |
|                               |          |                                | 5.001    | 1 byte   | X     | X |   | X |   |
|                               |          |                                | 20.102   | 1 byte   | X     | X |   | X |   |
|                               |          | Sequence A                     | 1.001    | 1 bit    | X     | X |   | X |   |
|                               |          | Sequence A (0...255)           | 5.010    | 1 byte   | X     | X |   | X |   |
|                               |          | Sequence A (0...100%)          | 5.001    | 1 byte   | X     | X |   | X |   |
|                               |          | Sequence A HVAC                | 20.102   | 1 byte   | X     | X |   | X |   |
|                               |          | Counter value                  | 5.010    | 1 byte   | X     | X |   | X |   |
|                               |          |                                | 7.001    | 2 bytes  | X     | X |   | X |   |
|                               |          |                                | 12.001   | 4 bytes  | X     | X |   | X |   |
|                               |          | RGB Colour                     | 232.600  | 3 bytes  | X     | X | X | X | X |
|                               |          | RGB – Red Colour               | 5.010    | 1 byte   | X     | X | X | X | X |

|                               |          |                                 |         |         |   |   |   |   |   |
|-------------------------------|----------|---------------------------------|---------|---------|---|---|---|---|---|
|                               |          | RGBW Colour                     | 251.600 | 6 bytes | X | X | X | X | X |
|                               |          | RGBW – Red Colour               | 5.010   | 1 byte  | X | X | X | X | X |
|                               |          | Thermostat Enable/Disable – A   | 1.003   | 1 bit   | X | X |   | X |   |
|                               |          | Thermostat Heat Cool Switch – A | 1.100   | 1 bit   | X | X |   | X |   |
|                               |          | Thermostat HVAC Mode Switch – A | 20.102  | 1 byte  | X | X |   | X |   |
|                               |          | Thermostat Setpoint – A         | 9.001   | 2 bytes | X | X |   | X |   |
|                               |          | Thermostat Fan Level – A        | 5.100   | 1 byte  | X | X |   | X |   |
|                               |          | Thermostat Fan Mode – A         | 1.003   | 1 bit   | X | X |   | X |   |
| 13,21,29,37,45,53,61,69,77,85 | Button X | RGB – Green Colour              | 5.010   | 1 byte  | X | X | X | X | X |
|                               |          | RGBW – Green Colour             | 5.010   | 1 byte  | X | X | X | X | X |
|                               |          | Thermostat Status Fb – A        | 1.003   | 1 bit   | X |   | X |   | X |
|                               |          | Thermostat Heat Cool Fb – A     | 1.100   | 1 bit   | X |   | X |   | X |
|                               |          | Thermostat HVAC Mode Fb – A     | 20.102  | 1 byte  | X |   | X |   | X |
|                               |          | Thermostat Setpoint Fb – A      | 9.001   | 2 bytes | X |   | X |   | X |
|                               |          | Thermostat Fan Level Fb – A     | 5.100   | 1 byte  | X |   | X |   | X |
|                               |          | Thermostat Fan Mode Fb – A      | 1.003   | 1 bit   | X |   | X |   | X |
| 14,22,30,38,46,54,62,70,78,86 | Button X | Switch - long                   | 1.001   | 1 bit   | X | X | X | X | X |
|                               |          | Dimming                         | 3.007   | 4 bits  | X |   |   | X |   |
|                               |          | STOP / Lamella Adjustment       | 1.007   | 1 bit   | X |   | X | X |   |
|                               |          | Forced Operation – Switch       | 2.001   | 2 bits  | X |   |   | X |   |
|                               |          | Forced Operation – Percent      | 5.001   | 1 byte  | X |   |   | X |   |
|                               |          | Forced Operation – Decimal      | 5.005   | 1 byte  | X |   |   | X |   |
|                               |          | Forced Operation – Scene        | 17.001  | 1 byte  | X |   |   | X |   |
|                               |          | Forced Operation – Colour       | 7.600   | 2 bytes | X |   |   | X |   |
|                               |          | Forced Operation – Temperature  | 9.001   | 2 bytes | X |   |   | X |   |
|                               |          | Forced Operation – Brightness   | 9.004   | 2 bytes | X |   |   | X |   |
|                               |          | Forced operation – RGB          | 232.600 | 3 bytes | X |   |   | X |   |
|                               |          | Scene Store                     | 1.003   | 1 bit   | X | X | X |   |   |
|                               |          | HVAC-Mode State                 | 20.102  | 1 byte  | X |   | X | X | X |
|                               |          | Sequence B                      | 1.001   | 1 bit   | X | X |   | X |   |
|                               |          | Sequence B (0...255)            | 5.010   | 1 byte  | X | X |   | X |   |
|                               |          | Sequence B (0...100%)           | 5.001   | 1 byte  | X | X |   | X |   |
|                               |          | Sequence B HVAC                 | 20.102  | 1 byte  | X | X |   | X |   |
|                               |          | Reset Counter                   | 1.001   | 1 bit   | X |   | X |   |   |
|                               |          | RGB – Blue Colour               | 5.010   | 1 byte  | X | X | X | X | X |
|                               |          | RGBW – Blue Colour              | 5.010   | 1 byte  | X | X | X | X | X |

|                                   |          |                                 |         |         |   |   |   |   |   |  |
|-----------------------------------|----------|---------------------------------|---------|---------|---|---|---|---|---|--|
|                                   |          | Thermostat Enable/Disable – B   | 1.003   | 1 bit   | X | X |   | X |   |  |
|                                   |          | Thermostat Heat Cool Switch – B | 1.100   | 1 bit   | X | X |   | X |   |  |
|                                   |          | Thermostat HVAC Mode Switch – B | 20.102  | 1 byte  | X | X |   | X |   |  |
|                                   |          | Thermostat Setpoint – B         | 9.001   | 2 bytes | X | X |   | X |   |  |
|                                   |          | Thermostat Fan Level – B        | 5.100   | 1 byte  | X | X |   | X |   |  |
|                                   |          | Thermostat Fan Mode – B         | 1.003   | 1 bit   | X | X |   | X |   |  |
| 15,23,31,39,47,<br>55,63,71,79,87 | Button X | RGBW – White Colour             | 5.010   | 1 byte  | X | X | X | X | X |  |
|                                   |          | Thermostat Status Fb – B        | 1.003   | 1 bit   | X |   | X |   | X |  |
|                                   |          | Thermostat Heat Cool Fb – B     | 1.100   | 1 bit   | X |   | X |   | X |  |
|                                   |          | Thermostat HVAC Mode Fb – B     | 20.102  | 1 byte  | X |   | X |   | X |  |
|                                   |          | Thermostat Setpoint Fb – B      | 9.001   | 2 bytes | X |   | X |   | X |  |
|                                   |          | Thermostat Fan Level Fb – B     | 5.100   | 1 byte  | X |   | X |   | X |  |
|                                   |          | Thermostat Fan Mode Fb – B      | 1.003   | 1 bit   | X |   | X |   | X |  |
| 16,24,32,40,48,<br>56,64,72,80,88 | Button X | Upper Limit Position            | 1.002   | 1 bit   | X |   | X |   |   |  |
|                                   |          | Sequence C                      | 1.001   | 1 bit   | X | X |   | X |   |  |
|                                   |          | Sequence C (0...255)            | 5.010   | 1 byte  | X | X |   | X |   |  |
|                                   |          | Sequence C (0...100%)           | 5.001   | 1 byte  | X | X |   | X |   |  |
|                                   |          | Sequence C HVAC                 | 20.102  | 1 byte  | X | X |   | X |   |  |
|                                   |          | Overflow                        | 1.001   | 1 bit   | X |   |   | X |   |  |
|                                   |          |                                 | 5.010   | 1 byte  | X |   |   | X |   |  |
| 17,25,33,41,49,<br>57,65,73,81,89 | Button X | Lower Limit Position            | 1.002   | 1 bit   | X |   | X |   |   |  |
|                                   |          | Sequence D                      | 1.001   | 1 bit   | X | X |   | X |   |  |
|                                   |          | Sequence D (0...255)            | 5.010   | 1 byte  | X | X |   | X |   |  |
|                                   |          | Sequence D (0...100%)           | 5.001   | 1 byte  | X | X |   | X |   |  |
|                                   |          | Sequence D HVAC                 | 20.102  | 1 byte  | X | X |   | X |   |  |
| 90,98                             | Input X  | Disable                         | 1.003   | 1 bit   | X |   | X |   |   |  |
| 91,99                             | Input X  | Status                          | 1.001   | 1 bit   | X | X |   | X |   |  |
| 92,100                            | Input X  | Switch                          | 1.001   | 1 bit   | X | X | X | X | X |  |
|                                   |          | Shutter UP/DOWN                 | 1.008   | 1 bit   | X |   | X | X |   |  |
|                                   |          | Forced Operation – Switch       | 2.001   | 2 bit   | X |   |   | X |   |  |
|                                   |          | Forced Operation – Percent      | 5.001   | 1 byte  | X |   |   | X |   |  |
|                                   |          | Forced Operation – Decimal      | 5.005   | 1 byte  | X |   |   | X |   |  |
|                                   |          | Forced Operation – Scene        | 17.001  | 1 byte  | X |   |   | X |   |  |
|                                   |          | Forced Operation – Colour       | 7.600   | 2 bytes | X |   |   | X |   |  |
|                                   |          | Forced Operation – Temperature  | 9.001   | 2 bytes | X |   |   | X |   |  |
|                                   |          | Forced Operation – Brightness   | 9.004   | 2 bytes | X |   |   | X |   |  |
|                                   |          | Forced Operation – RGB          | 232.600 | 3 bytes | X |   |   | X |   |  |

|                          |         |                                 |         |         |   |   |   |   |   |
|--------------------------|---------|---------------------------------|---------|---------|---|---|---|---|---|
|                          |         | Scene                           | 18.001  | 1 byte  | X |   |   | X |   |
|                          |         | Mode selection                  | 20.102  | 1 byte  | X |   | X | X |   |
|                          |         | Sequence                        | 1.001   | 1 bit   | X | X |   | X |   |
|                          |         |                                 | 5.010   | 1 byte  | X | X |   | X |   |
|                          |         |                                 | 5.001   | 1 byte  | X | X |   | X |   |
|                          |         |                                 | 20.102  | 1 byte  | X | X |   | X |   |
|                          |         | Sequence A                      | 1.001   | 1 bit   | X | X |   | X |   |
|                          |         | Sequence A (0...255)            | 5.010   | 1 byte  | X | X |   | X |   |
|                          |         | Sequence A (0...100%)           | 5.001   | 1 byte  | X | X |   | X |   |
|                          |         | Sequence A HVAC                 | 20.102  | 1 byte  | X | X |   | X |   |
|                          |         | Counter value                   | 5.010   | 1 byte  | X | X |   | X |   |
|                          |         |                                 | 7.001   | 2 bytes | X | X |   | X |   |
|                          |         |                                 | 12.001  | 4 bytes | X | X |   | X |   |
|                          |         | RGB Colour                      | 232.600 | 3 bytes | X | X | X | X | X |
|                          |         | RGB – Red Colour                | 5.010   | 1 byte  | X | X | X | X | X |
|                          |         | RGBW Colour                     | 251.600 | 6 bytes | X | X | X | X | X |
|                          |         | RGBW – Red Colour               | 5.010   | 1 byte  | X | X | X | X | X |
|                          |         | Thermostat Enable/Disable – A   | 1.003   | 1 bit   | X | X |   | X |   |
|                          |         | Thermostat Heat Cool Switch – A | 1.100   | 1 bit   | X | X |   | X |   |
|                          |         | Thermostat HVAC Mode Switch – A | 20.102  | 1 byte  | X | X |   | X |   |
| Thermostat Setpoint – A  | 9.001   | 2 bytes                         | X       | X       |   | X |   |   |   |
|                          | 9.002   | 2 bytes                         | X       | X       |   | X |   |   |   |
| Thermostat Fan Level – A | 5.100   | 1 byte                          | X       | X       |   | X |   |   |   |
| Thermostat Fan Mode – A  | 1.003   | 1 bit                           | X       | X       |   | X |   |   |   |
| 93,101                   | Input X | RGB – Green Colour              | 5.010   | 1 byte  | X | X | X | X | X |
|                          |         | RGBW – Green Colour             | 5.010   | 1 byte  | X | X | X | X | X |
|                          |         | Thermostat Status Fb – A        | 1.003   | 1 bit   | X |   | X |   | X |
|                          |         | Thermostat Heat Cool Fb – A     | 1.100   | 1 bit   | X |   | X |   | X |
|                          |         | Thermostat HVAC Mode Fb – A     | 20.102  | 1 byte  | X |   | X |   | X |
|                          |         | Thermostat Setpoint Fb – A      | 9.001   | 2 bytes | X |   | X |   | X |
|                          |         | Thermostat Fan Level Fb – A     | 5.100   | 1 byte  | X |   | X |   | X |
|                          |         | Thermostat Fan Mode Fb – A      | 1.003   | 1 bit   | X |   | X |   | X |
| 94,102                   | Input X | Switch – Long                   | 1.001   | 1 bit   | X | X | X | X | X |
|                          |         | Dimming                         | 3.007   | 4 bits  | X |   |   | X |   |
|                          |         | STOP / Lamella Adjustment       | 1.007   | 1 bit   | X |   | X | X |   |
|                          |         | Forced operation – Switch       | 2.001   | 2 bits  | X |   |   | X |   |
|                          |         | Forced operation – Percent      | 5.001   | 1 byte  | X |   |   | X |   |
|                          |         | Forced operation – Decimal      | 5.005   | 1 byte  | X |   |   | X |   |

|                         |         |                                 |         |         |   |   |   |   |   |
|-------------------------|---------|---------------------------------|---------|---------|---|---|---|---|---|
|                         |         | Forced operation – Scene        | 17.001  | 1 byte  | X |   |   | X |   |
|                         |         | Forced operation – Colour       | 7.600   | 2 bytes | X |   |   | X |   |
|                         |         | Forced operation – Temperature  | 9.001   | 2 bytes | X |   |   | X |   |
|                         |         | Forced operation – Brightness   | 9.004   | 2 bytes | X |   |   | X |   |
|                         |         | Forced operation – RGB          | 232.600 | 3 bytes | X |   |   | X |   |
|                         |         | Scene Store                     | 1.003   | 1 bit   | X | X | X |   |   |
|                         |         | HVAC-Mode State                 | 20.102  | 1 byte  | X |   | X | X | X |
|                         |         | Sequence B                      | 1.001   | 1 bit   | X | X |   | X |   |
|                         |         | Sequence B (0...255)            | 5.010   | 1 byte  | X | X |   | X |   |
|                         |         | Sequence B (0...100%)           | 5.001   | 1 byte  | X | X |   | X |   |
|                         |         | Sequence B HVAC                 | 20.102  | 1 byte  | X | X |   | X |   |
|                         |         | Reset counter                   | 1.001   | 1 bit   | X |   | X |   |   |
|                         |         | RGB – Blue Colour               | 5.010   | 1 byte  | X | X | X | X | X |
|                         |         | RGBW – Blue Colour              | 5.010   | 1 byte  | X | X | X | X | X |
|                         |         | Thermostat Enable/Disable – B   | 1.003   | 1 bit   | X | X |   | X |   |
|                         |         | Thermostat Heat Cool Switch – B | 1.100   | 1 bit   | X | X |   | X |   |
|                         |         | Thermostat HVAC Mode Switch – B | 20.102  | 1 byte  | X | X |   | X |   |
|                         |         | Thermostat Setpoint – B         | 9.001   | 2 bytes | X | X |   | X |   |
|                         |         |                                 | 9.002   | 2 bytes | X | X |   | X |   |
|                         |         | Thermostat Fan Level – B        | 5.100   | 1 byte  | X | X |   | X |   |
| X                       | X       |                                 |         |         | X | X |   |   |   |
| Thermostat Fan Mode – B | 1.003   | 1 bit                           | X       | X       |   | X |   |   |   |
|                         |         |                                 | X       | X       | X | X |   |   |   |
| 95,103                  | Input X | RGBW – White                    | 5.010   | 1 byte  | X | X | X | X | X |
|                         |         | Thermostat Status Fb – B        | 1.003   | 1 bit   | X |   | X |   | X |
|                         |         | Thermostat Heat Cool Fb – B     | 1.100   | 1 bit   | X |   | X |   | X |
|                         |         | Thermostat HVAC Mode Fb – B     | 20.102  | 1 byte  | X |   | X |   | X |
|                         |         | Thermostat Setpoint Fb – B      | 9.001   | 2 bytes | X |   | X |   | X |
|                         |         | Thermostat Fan Level Fb – B     | 5.100   | 1 byte  | X |   | X |   | X |
|                         |         | Thermostat Fan Mode Fb – B      | 1.003   | 1 bit   | X |   | X |   | X |
| 96,104                  | Input X | Upper limit position            | 1.002   | 1 bit   | X |   | X |   |   |
|                         |         | Sequence C                      | 1.001   | 1 bit   | X | X |   | X |   |
|                         |         | Sequence C (0...255)            | 5.010   | 1 byte  | X | X |   | X |   |
|                         |         | Sequence C (0...100%)           | 5.001   | 1 byte  | X | X |   | X |   |
|                         |         | Sequence C HVAC                 | 20.102  | 1 byte  | X | X |   | X |   |
|                         |         | Overflow                        | 1.001   | 1 bit   | X |   |   | X |   |
|                         |         |                                 | 5.010   | 1 byte  | X |   |   | X |   |

|   |  |                               |        |         |   |   |   |   |   |
|---|--|-------------------------------|--------|---------|---|---|---|---|---|
| 97,105  | Input X                                | Lower limit position          | 1.002  | 1 bit   | X |   | X |   |   |
|   |  | Sequence D                    | 1.001  | 1 bit   | X | X |   | X |   |
|   |  | Sequence D (0...255)          | 5.010  | 1 byte  | X | X |   | X |   |
|   |  | Sequence D (0...100%)         | 5.001  | 1 byte  | X | X |   | X |   |
|   |  | Sequence D HVAC               | 20.102 | 1 byte  | X | X |   | X |   |
| 106,112,118,124,<br>130,136,142,148,<br>154,160 | Led X                                  | Disable                       | 1.003  | 1 bit   | X |   | X |   |   |
| 107,113,119,125,<br>131,137,143,149,<br>155,161 | Led X                                  | Status                        | 1.003  | 1 bit   | X | X |   | X |   |
| 108,114,120,126,<br>132,138,144,150,<br>156,162 | Led X                                  | Switch                        | 1.001  | 1 bit   | X |   | X |   | X |
| 109,115,121,127,<br>133,139,145,151,<br>157,163 | Led X                                  | Blink Trigger                 | 1.017  | 1 bit   | X |   | X |   |   |
| 166   | Measurement<br>Temperature<br>Internal | Disable                       | 1.003  | 1 bit   | X |   | X |   |   |
| 167   | Measurement<br>Temperature<br>Internal | Status                        | 1.003  | 1 bit   | X | X |   | X |   |
| 168   | Measurement<br>Temperature<br>Internal | Temperature Value             | 9.001  | 2 bytes | X | X |   | X |   |
| 169   | Measurement<br>Temperature<br>Internal | Temperature Calibration       | 9.001  | 2 bytes | X |   | X |   |   |
| 170   | Measurement<br>Temperature<br>Internal | Alarm - Fault                 | 1.005  | 1 bit   | X |   |   | X |   |
| 171   | Measurement<br>Temperature<br>Internal | Alarm – Low                   | 1.005  | 1 bit   | X |   |   | X |   |
| 172   | Measurement<br>Temperature<br>Internal | Alarm – High                  | 1.005  | 1 bit   | X |   |   | X |   |
| 173   | Measurement<br>Temperature<br>Internal | Additional Value - Bit        | 1.001  | 1 bit   | X |   |   | X |   |
|   |  | Additional Value - Byte       | 5.010  | 1 byte  | X |   |   | X |   |
|   |  | Additional Value - Scene      | 17.001 | 1 byte  | X |   |   | X |   |
|   |  | Additional Value - Percentage | 5.001  | 1 bit   | X |   |   | X |   |
| 174   | Measurement<br>Humidity<br>Internal    | Disable                       | 1.003  | 1 bit   | X |   | X |   |   |

|     |                                  |                               |        |         |   |   |   |   |  |
|-----|----------------------------------|-------------------------------|--------|---------|---|---|---|---|--|
| 175 | Measurement Humidity Internal    | Status                        | 1.003  | 1 bit   | X | X |   | X |  |
| 176 | Measurement Humidity Internal    | Humidity Value                | 9.007  | 2 bytes | X | X |   | X |  |
| 177 | Measurement Humidity Internal    | Humidity Calibration          | 9.007  | 2 bytes | X |   | X |   |  |
| 178 | Measurement Humidity Internal    | Alarm - Fault                 | 1.005  | 1 bit   | X |   |   | X |  |
| 179 | Measurement Humidity Internal    | Alarm - Low                   | 1.005  | 1 bit   | X |   |   | X |  |
| 180 | Measurement Humidity Internal    | Alarm - High                  | 1.005  | 1 bit   | X |   |   | X |  |
| 181 | Measurement Humidity Internal    | Additional Value - Bit        | 1.001  | 1 bit   | X |   |   | X |  |
|     |                                  | Additional Value - Byte       | 5.010  | 1 byte  | X |   |   | X |  |
|     |                                  | Additional Value - Scene      | 17.001 | 1 byte  | X |   |   | X |  |
|     |                                  | Additional Value - Percentage | 5.001  | 1 bit   | X |   |   | X |  |
| 182 | Measurement Air Quality Internal | Disable                       | 1.003  | 1 bit   | X |   | X |   |  |
| 183 | Measurement Air Quality Internal | Status                        | 1.003  | 1 bit   | X | X |   | X |  |
| 184 | Measurement Air Quality Internal | Air Quality Value             | 9.008  | 2 bytes | X | X |   | X |  |
| 185 | Measurement Air Quality Internal | Air Quality Calibration       | 9.008  | 2 bytes | X |   | X |   |  |
| 186 | Measurement Air Quality Internal | Alarm - Fault                 | 1.005  | 1 bit   | X |   |   | X |  |
| 187 | Measurement Air Quality Internal | Alarm - Low                   | 1.005  | 1 bit   | X |   |   | X |  |
| 188 | Measurement Air Quality Internal | Alarm - High                  | 1.005  | 1 bit   | X |   |   | X |  |
| 189 | Measurement Air Quality Internal | Additional Value - Bit        | 1.001  | 1 bit   | X |   |   | X |  |
|     |                                  | Additional Value - Byte       | 5.010  | 1 byte  | X |   |   | X |  |
|     |                                  | Additional Value - Scene      | 17.001 | 1 byte  | X |   |   | X |  |

|         |                                       |                                  |        |         |   |   |   |   |  |
|---------|---------------------------------------|----------------------------------|--------|---------|---|---|---|---|--|
|         |                                       | Additional Value - Percentage    | 5.001  | 1 bit   | X |   |   | X |  |
| 190     | Measurement<br>Brightness<br>Internal | Disable                          | 1.003  | 1 bit   | X |   | X |   |  |
| 191     | Measurement<br>Brightness<br>Internal | Status                           | 1.003  | 1 bit   | X | X |   | X |  |
| 192     | Measurement<br>Brightness<br>Internal | Brightness Value                 | 9.004  | 2 bytes | X | X |   | X |  |
| 193     | Measurement<br>Brightness<br>Internal | Brightness Calibration           | 9.004  | 2 bytes | X |   | X |   |  |
| 194     | Measurement<br>Brightness<br>Internal | Alarm - Fault                    | 1.005  | 1 bit   | X |   |   | X |  |
| 195     | Measurement<br>Brightness<br>Internal | Alarm - Low                      | 1.005  | 1 bit   | X |   |   | X |  |
| 196     | Measurement<br>Brightness<br>Internal | Alarm - High                     | 1.005  | 1 bit   | X |   |   | X |  |
| 197     | Measurement<br>Brightness<br>Internal | Additional Value - Bit           | 1.001  | 1 bit   | X |   |   | X |  |
|         |                                       | Additional Value - Byte          | 5.010  | 1 byte  | X |   |   | X |  |
|         |                                       | Additional Value - Scene         | 17.001 | 1 byte  | X |   |   | X |  |
|         |                                       | Additional Value - Percentage    | 5.001  | 1 bit   | X |   |   | X |  |
| 198     | Measurement<br>External X             | Disable                          | 1.003  | 1 bit   | X |   | X |   |  |
| 199     | Measurement<br>External X             | Status                           | 1.003  | 1 bit   | X | X |   | X |  |
| 200,218 | Measurement<br>External X             | Temperature Value                | 9.001  | 2 bytes | X | X |   | X |  |
|         |                                       | Brightness Value                 | 9.004  | 2 bytes | X | X |   | X |  |
| 201,219 | Measurement<br>External X             | Temperature Calibration<br>Value | 9.001  | 2 bytes | X |   | X |   |  |
|         |                                       | Brightness Calibration Value     | 9.004  | 2 bytes | X |   | X |   |  |
| 202,220 | Measurement<br>External X             | Alarm - Fault                    | 1.005  | 1 bit   | X |   |   | X |  |
| 203,221 | Measurement<br>External X             | Alarm - Low                      | 1.005  | 1 bit   | X |   |   | X |  |
| 204,222 | Measurement<br>External X             | Alarm - High                     | 1.005  | 1 bit   | X |   |   | X |  |
| 205,223 | Measurement<br>External X             | Additional Value - Bit           | 1.001  | 1 bit   | X |   |   | X |  |
|         |                                       | Additional Value - Byte          | 5.010  | 1 byte  | X |   |   | X |  |
|         |                                       | Additional Value - Scene         | 17.001 | 1 byte  | X |   |   | X |  |

|                             |               |                                       |        |         |   |   |   |   |  |
|-----------------------------|---------------|---------------------------------------|--------|---------|---|---|---|---|--|
|                             |               | Additional Value - Percentage         | 5.001  | 1 bit   | X |   |   | X |  |
| 214,222,230,238,<br>246,252 | Calculation X | Disable                               | 1.003  | 1 bit   | X |   | X |   |  |
| 215,223,231,239,<br>247,253 | Calculation X | Status                                | 1.003  | 1 bit   | X | X |   | X |  |
| 216,224,232,240,<br>248,254 | Calculation X | Probe Input Temperature               | 9.001  | 2 bytes | X |   | X |   |  |
|                             |               | Probe Input Humidity                  | 9.007  | 2 bytes | X |   | X |   |  |
|                             |               | Probe Input Brightness                | 9.004  | 2 bytes | X |   | X |   |  |
|                             |               | Probe Input Proximity                 | 7.011  | 2 bytes | X |   | X |   |  |
|                             |               | Probe Input Air Quality               | 9.008  | 2 bytes | X |   | X |   |  |
|                             |               | Probe Input Air Pressure              | 9.006  | 2 bytes | X |   | X |   |  |
|                             |               | Probe Input Wind Speed                | 9.005  | 2 bytes | X |   | X |   |  |
| 218,226,234,242,<br>250,256 | Calculation X | Output Temperature                    | 9.001  | 2 bytes | X | X |   | X |  |
|                             |               | Output Humidity                       | 9.007  | 2 bytes | X | X |   | X |  |
|                             |               | Output Brightness                     | 9.004  | 2 bytes | X | X |   | X |  |
|                             |               | Output Proximity                      | 7.011  | 2 bytes | X | X |   | X |  |
|                             |               | Output Air Quality                    | 9.008  | 2 bytes | X | X |   | X |  |
|                             |               | Output Air Pressure                   | 9.006  | 2 bytes | X | X |   | X |  |
|                             |               | Output Wind Speed                     | 9.005  | 2 bytes | X | X |   | X |  |
| 219,227,235,243,<br>251,257 | Calculation X | Alarm - Low                           | 1.005  | 1 bit   | X | X |   | X |  |
| 220,228,236,244,<br>252,258 | Calculation X | Alarm - High                          | 1.005  | 1 bit   | X | X |   | X |  |
| 262                         | Thermostat    | Thermostat Disabling                  | 1.003  | 1 bit   | X |   | X |   |  |
|                             |               | Thermostat Disabling                  | 1.003  | 1 bit   | X | X |   | X |  |
| 263                         | Thermostat    | Thermostat Status                     | 1.003  | 1 bit   | X | X |   | X |  |
|                             |               | Thermostat Status                     | 1.003  | 1 bit   | X |   | X |   |  |
| 266                         | Thermostat    | Thermostat Operation Mode             | 20.102 | 1 byte  | X |   | X |   |  |
|                             |               | Thermostat Operation Mode             | 20.102 | 1 byte  | X | X |   | X |  |
| 267                         | Thermostat    | Thermostat Operation Mode Forced      | 20.102 | 1 byte  | X |   | X |   |  |
| 268                         | Thermostat    | Thermostat Operation Mode Status      | 20.102 | 1 byte  | X | X |   | X |  |
|                             |               | Thermostat Operation Mode Feedback    | 20.102 | 1 byte  | X |   | X |   |  |
| 269                         | Thermostat    | Operation Mode [Comfort]              | 1.001  | 1 bit   | X |   | X |   |  |
| 270                         | Thermostat    | Operation Mode [Standby]              | 1.001  | 1 bit   | X |   | X |   |  |
| 271                         | Thermostat    | Operation Mode [Economy]              | 1.001  | 1 bit   | X |   | X |   |  |
| 272                         | Thermostat    | Operation Mode [Protection]           | 1.001  | 1 bit   | X |   | X |   |  |
| 273                         | Thermostat    | Thermostat Heating/Cooling Switchover | 1.100  | 1 bit   | X |   | X |   |  |
|                             |               | Thermostat Heating/Cooling Switchover | 1.100  | 1 bit   | X | X |   | X |  |

|     |            |   |       |        |   |   |   |   |  |
|-----|------------|---|-------|--------|---|---|---|---|--|
| 274 | Thermostat | Thermostat Heating/Cooling Status               | 1.100 | 1 bit  | X | X |   | X |  |
|     |            | Thermostat Heating/Cooling Feedback             | 1.100 | 1 bit  | X |   | X |   |  |
| 275 | Thermostat | Thermostat Heating Control Disabling            | 1.003 | 1 bit  | X |   | X |   |  |
| 276 | Thermostat | Thermostat Heating Control Running              | 1.002 | 1 bit  | X | X |   | X |  |
|     |            | Thermostat Heating Control Running              | 1.002 | 1 bit  | X |   | X |   |  |
| 277 | Thermostat | Thermostat Heating Value (1-bit)                | 1.001 | 1 bit  | X | X |   | X |  |
|     |            | Thermostat Heating Value (1-byte)               | 5.004 | 1 byte | X | X |   | X |  |
|     |            | Thermostat Heating/Cooling Value (1-bit)        | 1.001 | 1 bit  | X | X |   | X |  |
|     |            | Thermostat Heating/Cooling Value (1-byte)       | 5.004 | 1 byte | X | X |   | X |  |
| 278 | Thermostat | Thermostat Heating Value Request                | 1.016 | 1 bit  | X |   | X |   |  |
| 279 | Thermostat | Thermostat Cooling Control Disabling            | 1.003 | 1 bit  | X |   | X |   |  |
| 280 | Thermostat | Thermostat Cooling Control Running              | 1.002 | 1 bit  | X | X |   | X |  |
|     |            | Thermostat Cooling Control Running              | 1.002 | 1 bit  | X |   | X |   |  |
| 281 | Thermostat | Thermostat Cooling Value (1-bit)                | 1.001 | 1 bit  | X | X |   | X |  |
|     |            | Thermostat Cooling Value (1-byte)               | 5.004 | 1 byte | X | X |   | X |  |
| 282 | Thermostat | Thermostat Cooling Value Request                | 1.016 | 1 bit  | X |   | X |   |  |
| 283 | Thermostat | Thermostat Additional Heating Control Disabling | 1.003 | 1 bit  | X |   | X |   |  |
| 284 | Thermostat | Thermostat Additional Heating Control Running   | 1.002 | 1 bit  | X | X |   | X |  |
| 285 | Thermostat | Thermostat Additional Heating Value(1-Bit)      | 1.001 | 1 bit  | X | X |   | X |  |
|     |            | Thermostat Additional Heating Value(1-Byte)     | 5.004 | 1 byte | X | X |   | X |  |
| 286 | Thermostat | Thermostat Additional Heating Value Request     | 1.016 | 1 bit  | X | X |   | X |  |
| 287 | Thermostat | Thermostat Additional Cooling Control Disabling | 1.003 | 1 bit  | X |   | X |   |  |
| 288 | Thermostat | Thermostat Additional Cooling Control Running   | 1.002 | 1 bit  | X | X |   | X |  |

|     |            |  |       |         |   |   |   |   |
|-----|------------|--|-------|---------|---|---|---|---|
| 289 | Thermostat | Thermostat Additional Cooling Value (1-Bit)  | 1.001 | 1 bit   | X |   | X |   |
|     |            | Thermostat Additional Cooling Value (1-Byte) | 5.004 | 1 byte  | X |   | X |   |
| 290 | Thermostat | Thermostat Additional Cooling Value Request  | 1.017 | 1 bit   | X | X |   |   |
| 291 | Thermostat | Room Temperature Output - Celsius            | 9.001 | 2 bytes | X | X | X |   |
|     |            | Room Temperature Input - Celsius             | 9.001 | 2 bytes | X |   | X |   |
|     |            | Room Temperature Output - Fahrenheit         | 9.027 | 2 bytes | X | X |   | X |
|     |            | Room Temperature Input - Fahrenheit          | 9.027 | 2 bytes | X |   | X |   |
| 292 | Thermostat | Actual Setpoint Output                       | 9.001 | 2 bytes | X | X | X |   |
|     |            |  | 9.002 | 2 bytes | X | X | X |   |
|     |            |  | 9.027 | 2 bytes | X | X | X |   |
|     |            | Actual Setpoint Input                        | 9.001 | 2 bytes | X |   | X |   |
|     |            |  | 9.002 | 2 bytes | X |   | X |   |
|     |            |  | 9.027 | 2 bytes | X |   | X |   |
| 293 | Thermostat | Manual Setpoint Input                        | 9.001 | 2 bytes | X |   | X |   |
|     |            |  | 9.002 | 2 bytes | X |   | X |   |
|     |            |  | 9.027 | 2 bytes | X |   | X |   |
|     |            | Manual Setpoint Output                       | 9.001 | 2 bytes | X | X | X |   |
|     |            |  | 9.002 | 2 bytes | X | X | X |   |
|     |            |  | 9.027 | 2 bytes | X | X | X |   |
| 294 | Thermostat | Manual Setpoint Reset                        | 1.015 | 1 bit   | X | X |   |   |
| 295 | Thermostat | Heating Comfort Setpoint Temperature         | 9.001 | 2 bytes | X | X |   |   |
| 296 | Thermostat | Heating Standby Setpoint Temperature         | 9.001 | 2 bytes | X | X |   |   |
| 297 | Thermostat | Heating Economy Setpoint Temperature         | 9.001 | 2 bytes | X | X |   |   |
| 298 | Thermostat | Heating Protection Setpoint Temperature      | 9.001 | 2 bytes | X | X |   |   |
| 299 | Thermostat | Cooling Comfort Setpoint Temperature         | 9.001 | 2 bytes | X | X |   |   |
| 300 | Thermostat | Cooling Standby Setpoint Temperature         | 9.001 | 2 bytes | X | X |   |   |
| 301 | Thermostat | Cooling Economy Setpoint Temperature         | 9.001 | 2 bytes | X | X |   |   |
| 302 | Thermostat | Cooling Protection Setpoint Temperature      | 9.001 | 2 bytes | X | X |   |   |
| 303 | Thermostat | Fan Controller Disable                       | 1.003 | 1 bit   | X | X |   |   |

|     |            |   |       |         |   |   |   |   |   |
|-----|------------|---|-------|---------|---|---|---|---|---|
| 304 | Thermostat | Fan Controller Status                       | 1.003 | 1 bit   | X | X |   | X |   |
| 305 | Thermostat | Fan Controller Working Mode                 | 1.003 | 1 bit   | X |   | X |   |   |
| 306 | Thermostat | Fan Controller Working Mode Status          | 1.003 | 1 bit   | X | X |   | X |   |
| 307 | Thermostat | Fan Controller Proportional Output          | 5.001 | 1 byte  | X | X |   | X |   |
| 308 | Thermostat | Fan Controller Manual Step                  | 1.007 | 1 bit   | X |   | X |   |   |
|     |            | Fan Controller Manual Up/Down               | 1.008 | 1 bit   | X |   | X |   |   |
| 309 | Thermostat | Fan Controller Manual Stage                 | 5.100 | 1 byte  | X |   | X |   |   |
| 310 | Thermostat | Fan Controller Speed (1 Byte)               | 5.010 | 1 byte  | X | X |   | X |   |
| 311 | Thermostat | Fan Controller Speed Feedback (1 Byte)      | 5.010 | 1 byte  | X |   | X |   | X |
| 312 | Thermostat | Fan Level 1                                 | 1.001 | 1 bit   | X | X |   | X |   |
| 313 | Thermostat | Fan Level 2                                 | 1.001 | 1 bit   | X | X |   | X |   |
| 314 | Thermostat | Fan Level 3                                 | 1.001 | 1 bit   | X | X |   | X |   |
| 315 | Thermostat | Fan Level 4                                 | 1.001 | 1 bit   | X | X |   | X |   |
| 316 | Thermostat | Fan Level 5                                 | 1.001 | 1 bit   | X | X |   | X |   |
| 317 | Thermostat | Fan Level 1 Feedback Input                  | 1.001 | 1 bit   | X |   | X |   | X |
| 318 | Thermostat | Fan Level 2 Feedback Input                  | 1.001 | 1 bit   | X |   | X |   | X |
| 319 | Thermostat | Fan Level 3 Feedback Input                  | 1.001 | 1 bit   | X |   | X |   | X |
| 320 | Thermostat | Fan Level 4 Feedback Input                  | 1.001 | 1 bit   | X |   | X |   | X |
| 321 | Thermostat | Fan Level 5 Feedback Input                  | 1.001 | 1 bit   | X |   | X |   | X |
| 322 | Thermostat | Energy Saving – Window Contact 1            | 1.001 | 1 bit   | X |   | X |   |   |
| 323 | Thermostat | Energy Saving – Window Contact 2            | 1.001 | 1 bit   | X |   | X |   |   |
| 324 | Thermostat | Energy Saving – Presence Input 1            | 1.001 | 1 bit   | X |   | X |   |   |
| 325 | Thermostat | Energy Saving – Presence Input 2            | 1.001 | 1 bit   | X |   | X |   |   |
| 326 | Thermostat | Energy Saving – Card Holder 1               | 1.001 | 1 bit   | X |   | X |   |   |
| 327 | Thermostat | Energy Saving – Card Holder 2               | 1.001 | 1 bit   | X |   | X |   |   |
| 328 | Thermostat | Temperature Limit Heating Source            | 9.001 | 2 bytes | X |   | X |   |   |
|     |            |   | 9.027 | 2 bytes | X |   | X |   |   |
| 329 | Thermostat | Temperature Limit Cooling Source            | 9.001 | 2 bytes | X |   | X |   |   |
|     |            |   | 9.027 | 2 bytes | X |   | X |   |   |
| 330 | Thermostat | Temperature Limit Additional Heating Source | 9.001 | 2 bytes | X |   | X |   |   |
|     |            |   | 9.027 | 2 bytes | X |   | X |   |   |
| 331 | Thermostat |   | 9.001 | 2 bytes | X |   | X |   |   |

|     |            |   |        |         |   |  |   |  |   |
|-----|------------|---|--------|---------|---|--|---|--|---|
|     |            | Temperature Limit Additional Cooling Source | 9.027  | 2 bytes | X |  | X |  |   |
| 332 | Thermostat | Time  | 10.001 | 3 bytes | X |  | X |  |   |
| 333 | LCD        | Brightness                                  | 5.001  | 1 byte  | X |  | X |  | X |
| 334 | LCD        | Indicator On/Off                            | 1.001  | 1 bit   | X |  | X |  | X |
| 336 | LCD        | Outdoor Temperature                         | 9.001  | 2 bytes | X |  | X |  | X |
| 337 | LCD        | Fan Indicator Status                        | 1.003  | 1 bit   | X |  | X |  | X |
| 338 | LCD        | Fan Indicator Auto/Manual                   | 1.003  | 1 bit   | X |  | X |  | X |
| 339 | LCD        | Fan Indicator Level (1-byte)                | 5.100  | 1 byte  | X |  | X |  | X |
| 340 | LCD        | Fan Indicator Level 1                       | 1.001  | 1 bit   | X |  | X |  | X |
| 341 | LCD        | Fan Indicator Level 2                       | 1.001  | 1 bit   | X |  | X |  | X |
| 342 | LCD        | Fan Indicator Level 3                       | 1.001  | 1 bit   | X |  | X |  | X |
| 343 | LCD        | Fan Indicator Level 4                       | 1.001  | 1 bit   | X |  | X |  | X |
| 344 | LCD        | Fan Indicator Level 5                       | 1.001  | 1 bit   | X |  | X |  | X |

## 5.1. General Objects

This section describes the "general" group objects and their properties. General group objects, as the name suggests, indicate the general characteristics of the iSwitch+.

| Object Number | Object Name | Function     | Type  | Flags |
|---------------|-------------|--------------|-------|-------|
| 1             | General     | In operation | 1 bit | CT    |

This object is used to monitor the presence of the device on the KNX bus line regularly. However, monitoring telegrams can be sent cyclically on the KNX bus line.

DPT: 1.002 (boolean)

|   |         |                |       |    |
|---|---------|----------------|-------|----|
| 2 | General | Navigation LED | 1 bit | CW |
|---|---------|----------------|-------|----|

The navigation LED is controlled by this object.

DPT: 1.001 (switch)

|   |         |                      |       |    |
|---|---------|----------------------|-------|----|
| 3 | General | Error Identification | 1 bit | CT |
|---|---------|----------------------|-------|----|

This object is used to send an error message to indicate the error type if an error occurs.

DPT: 16.000 (Character String (ASCII))

## 5.2. Button Objects

In this section, Button X objects are described in the table below. In the first column name of the object, in the second column function name, the third column data type and fourth column the objects flags, information is given.

X: 1...8, Button Up, Button Down

| Object Number                          | Object Name | Function | Type  | Flags |
|--|-------------|----------|-------|-------|
| 10, 18, 26, 34, 42, 50, 58, 66, 74, 82 | Button X    | Disable  | 1 bit | CW    |

This object is used to set the iSwitch+ button X status. "Enabled" or "Disabled" telegram is received via this object.

For example, it will be disabled when an "Enabled" telegram is received from the KNX bus line, and when a "Disabled" telegram is received, the button X will continue working.

DPT: 1.003 (enable)

|  |          |        |       |     |
|--|----------|--------|-------|-----|
| 11, 19, 27, 35, 43, 51, 59, 67, 75, 83 | Button X | Status | 1 bit | CRT |
|--|----------|--------|-------|-----|

This object is used to watch button X status. "Enabled" or "Disabled" telegram is transmitted to KNX bus via this object when input X status is changed over device.

DPT: 1.003 (enable)

|  |          |        |       |       |
|--|----------|--------|-------|-------|
| 12, 20, 28, 36, 44, 52, 60, 68, 76, 84 | Button X | Switch | 1 bit | CRWTU |
|--|----------|--------|-------|-------|

This communication object changes in functionality depending on the selected input function. In accordance with the parameter setting, this communication object can be switched by actuation of the input to ON, OFF or TOGGLE.

DPT: 1.001 (switch)

|  |          |                 |       |     |
|--|----------|-----------------|-------|-----|
| 12, 20, 28, 36, 44, 52, 60, 68, 76, 84 | Button X | Shutter UP/Down | 1 bit | CWT |
|--|----------|-----------------|-------|-----|

This communication object changes in functionality depending on the selected input function. This communication object sends a shutter motion telegram UP or DOWN on the bus. By receiving telegrams, the device also recognizes movement telegrams of another sensor, e.g. parallel operation.

DPT: 1.008 (up/down)

|   |          |                  |  |    |
|---|----------|------------------|--|----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Forced Operation | 2 bit / 1<br>byte / 2<br>bytes/ 3<br>bytes | CT |
|---|----------|------------------|--|----|

This communication object changes in functionality depending on the selected input function. This communication object sends a value on the bus with short operation when opening or closing of the contact. Depending on the configuration, the data type of this object changes. forced, percent value, decimal value, Scene number, temperature value, brightness value and percent value (RGB) can be performed on this object.

DPT: According to parameter selection

|   |          |       |        |    |
|---|----------|-------|--------|----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Scene | 1 byte | CT |
|---|----------|-------|--------|----|

This communication object stores the value of the active scene number (1 - 64).

DPT: 18.001 (scene control)

|   |          |                |        |     |
|---|----------|----------------|--------|-----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Mode Selection | 1 byte | CWT |
|---|----------|----------------|--------|-----|

This object keeps the active HVAC state that can be toggled through press events.

Note: There can be up to 4 different HVAC state (comfort, standby, economy, building protection) selected and each press event toggles through the HVAC states that are set as available in the parameter list.

DPT: 20.102 (HVAC mode)

|   |          |          |                   |     |
|---|----------|----------|-------------------|-----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Sequence | 1 bit / 1<br>byte | CRT |
|---|----------|----------|-------------------|-----|

This object keeps the current command that can be toggled through press events. Used for "Single Object" parameter selection.

**Note:** Each state (State A, B, C, D) holds a different value with adjustable data length. Each press event puts the next available state's data to the "Sequence" object.

DPT: According to parameter selection

|   |          |            |                   |     |
|---|----------|------------|-------------------|-----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Sequence A | 1 bit / 1<br>byte | CRT |
|---|----------|------------|-------------------|-----|

This object keeps the current command that can be toggled through press events. Used for "Multiple Object" parameter selection.

Note: Each object (Object A, B, C, D) holds a different value with adjustable data length. Each press event puts the next available state's data to the "Sequence X" object and whichever object is holds the current state is sent to bus with its data.

DPT: According to parameter selection

|   |          |               |                                  |     |
|---|----------|---------------|----------------------------------|-----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Counter value | 1 byte / 2<br>bytes / 4<br>bytes | CRT |
|---|----------|---------------|----------------------------------|-----|

This object keeps the current value of the press counter.

DPT: According to parameter selection

|   |          |                             |                     |       |
|---|----------|-----------------------------|---------------------|-------|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | RGB Red Colour / RGB Colour | 1 byte / 3<br>bytes | CRWTU |
|---|----------|-----------------------------|---------------------|-------|

This object either keeps the 1-Byte Red value of the RGB, or keeps the entire 3-Byte RGB value. Decision is made in the parameter list as either “1 object of 3 bytes” or 3 objects of 1 byte”.

DPT: 5.010 (counter pulses) / 232.600 (RGB value)

|   |          |                              |                    |       |
|---|----------|------------------------------|--------------------|-------|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | RGBW Red Colour/ RGBW Colour | 6 bytes/<br>1 byte | CRWTU |
|---|----------|------------------------------|--------------------|-------|

If the “object type” is set to “1 object”, this object keeps the 6-Byte RGBW value, but, if the “object type” is set to “4 objects”, this object keeps the 1-Byte Red value of the RGBW.

DPT: 251.600 (RGBW value) / 5.010 (counter pulses)

|   |          |                               |       |     |
|---|----------|-------------------------------|-------|-----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Thermostat Enable/Disable - A | 1 bit | CRT |
|---|----------|-------------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. Thermostat status is controlled via this object.

DPT: 1.003 (enable)

|   |          |                                 |       |     |
|---|----------|---------------------------------|-------|-----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Thermostat Heat Cool Switch - A | 1 bit | CRT |
|---|----------|---------------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. Heating/cooling mode changeover is controlled via this object.

DPT: 1.100 (cooling/heating)

|   |          |                                 |        |     |
|---|----------|---------------------------------|--------|-----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Thermostat HVAC Mode Switch - A | 1 byte | CRT |
|---|----------|---------------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat. The HVAC operating mode is controlled via this object.

DPT: 20.102 (HVAC mode)

|   |          |                         |         |     |
|---|----------|-------------------------|---------|-----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Thermostat Setpoint - A | 2 bytes | CRT |
|---|----------|-------------------------|---------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The setpoint temperature is controlled via this object.

DPT: 9.001 (temperature °C)

|   |          |                          |        |     |
|---|----------|--------------------------|--------|-----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Thermostat Fan Level - A | 1 byte | CRT |
|---|----------|--------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The fan speed is controlled via this object.

DPT: 5.100 (switch)

|   |          |                         |       |     |
|---|----------|-------------------------|-------|-----|
| 12, 20, 28, 36, 44,<br>52, 60, 68, 76, 84 | Button X | Thermostat Fan Mode - A | 1 bit | CRT |
|---|----------|-------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The fan auto/manual working mode is controlled via this object.

DPT: 1.003 (enable)

|   |          |                  |        |       |
|---|----------|------------------|--------|-------|
| 13, 21, 29, 37, 45,<br>53, 61, 69, 77, 85 | Button X | RGB Green Colour | 1 byte | CRWTU |
|---|----------|------------------|--------|-------|

This object keeps the 1-Byte green value of RGB if “3 objects of 1 Byte” option is selected in the parameter list.

DPT: 5.010 (counter pulses)

|   |          |                   |        |       |
|---|----------|-------------------|--------|-------|
| 13, 21, 29, 37, 45,<br>53, 61, 69, 77, 85 | Button X | RGBW Green Colour | 1 byte | CRWTU |
|---|----------|-------------------|--------|-------|

If the “object type” is set to “4 objects”, this object keeps the 1-Byte Green value of the RGBW.

DPT: 5.010 (counter pulses)

|   |          |                          |       |     |
|---|----------|--------------------------|-------|-----|
| 13, 21, 29, 37, 45,<br>53, 61, 69, 77, 85 | Button X | Thermostat Status Fb - A | 1 bit | CWU |
|---|----------|--------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The thermostat status is watched via this object.

DPT: 1.003 (enable)

|   |          |                             |       |     |
|---|----------|-----------------------------|-------|-----|
| 13, 21, 29, 37, 45,<br>53, 61, 69, 77, 85 | Button X | Thermostat Heat Cool Fb - A | 1 bit | CWU |
|---|----------|-----------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The heating/cooling mode is watched via this object.

DPT: 1.100 (cooling/heating)

|   |          |                        |        |     |
|---|----------|------------------------|--------|-----|
| 13, 21, 29, 37, 45,<br>53, 61, 69, 77, 85 | Button X | Thermostat HVAC Fb - A | 1 byte | CWU |
|---|----------|------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The HVAC operating mode is watched via this object.

DPT: 20.102 (HVAC mode)

|   |          |                            |         |     |
|---|----------|----------------------------|---------|-----|
| 13, 21, 29, 37, 45,<br>53, 61, 69, 77, 85 | Button X | Thermostat Setpoint Fb - A | 2 bytes | CWU |
|---|----------|----------------------------|---------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The setpoint temperature is watched via this object.

DPT: 9.001 (temperature (°C))

|   |          |                             |        |     |
|---|----------|-----------------------------|--------|-----|
| 13, 21, 29, 37, 45,<br>53, 61, 69, 77, 85 | Button X | Thermostat Fan Level Fb - A | 1 byte | CWU |
|---|----------|-----------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The fan speed is watched via this object.

DPT: 1.003 (enable)

|   |          |                            |       |     |
|---|----------|----------------------------|-------|-----|
| 13, 21, 29, 37, 45,<br>53, 61, 69, 77, 85 | Button X | Thermostat Fan Mode Fb - A | 1 bit | CWU |
|---|----------|----------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The fan auto/manual working mode is watched via this object.

DPT: 1.003 (enable)

|   |          |               |       |       |
|---|----------|---------------|-------|-------|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Switch - Long | 1 bit | CRWTU |
|---|----------|---------------|-------|-------|

This communication object changes in functionality depending on the selected input function. In accordance with the parameter setting, this communication object can be switched by actuation of the input to ON, OFF or TOGGLE.

DPT: 1.001 (switch)

|   |          |         |        |    |
|---|----------|---------|--------|----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Dimming | 4 bits | CT |
|---|----------|---------|--------|----|

This communication object changes in functionality depending on the selected input function. In accordance with the parameter setting, A long operation at the input has the effect that BRIGHTER or DARKER dim telegrams are sent via this communication object on the bus. A STOP telegram is sent and the cyclic sending of dim telegrams is stopped at the end of actuation with START-STOP-DIMMING.

DPT: 3.007 (dimming control)

|   |          |                           |       |    |
|---|----------|---------------------------|-------|----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | STOP / Lamella Adjustment | 1 bit | CT |
|---|----------|---------------------------|-------|----|

This communication object changes in functionality depending on the selected input function. This communication object sends a STOP telegram or slat adjustment.

DPT: 1.007 (step)

|   |          |                         |  |    |
|---|----------|-------------------------|--|----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Forced Operation - Long | 2 bit / 1<br>byte / 2<br>bytes/ 3<br>bytes | CT |
|---|----------|-------------------------|--|----|

This communication object changes in functionality depending on the selected input function. This communication object sends a value on the bus with short operation when opening or closing of the contact. Depending on the configuration, the data type of this object changes. forced, percent value, decimal value, Scene number, temperature value, brightness value and percent value (RGB) can be performed on this object.

DPT: According to parameter selection

|   |          |             |       |     |
|---|----------|-------------|-------|-----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Scene Store | 1 bit | CRW |
|---|----------|-------------|-------|-----|

This communication object, when active, decides whether to call or store the preset 8-bit scene number in the parameter list. When the store scene object is enabled the preset scene number is stored, but, when disabled preset scene number is called to be active.

DPT: 1.003 (enable)

|   |          |                 |        |      |
|---|----------|-----------------|--------|------|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | HVAC-Mode State | 1 byte | CWTU |
|---|----------|-----------------|--------|------|

This object takes the HVAC state changed via the bus.

Note: Whenever this object is updated from the bus, the HVAC state that this object holds will be considered as the valid HVAC state and press events will act as if the last HVAC state is what this object is updated with.

DPT: 20.102 (HVAC mode)

|   |          |            |                   |     |
|---|----------|------------|-------------------|-----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Sequence B | 1 bit / 1<br>byte | CRT |
|---|----------|------------|-------------------|-----|

This object keeps the current command that can be toggled through press events. Used for “Multiple Object” parameter selection.

Note: Each object (Object A, B, C, D) holds a different value with adjustable data length. Each press event puts the next available state’s data to the “Sequence X” object and whichever object is holds the current state is sent to bus with its data.

DPT: According to parameter selection

|   |          |               |       |    |
|---|----------|---------------|-------|----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Reset Counter | 1 bit | CW |
|---|----------|---------------|-------|----|

This object is used to reset the counter value to preset start value that can be set from parameter list.

DPT: According to parameter selection

|   |          |                 |        |       |
|---|----------|-----------------|--------|-------|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | RGB Blue Colour | 1 byte | CRWTU |
|---|----------|-----------------|--------|-------|

This object keeps the 1-Byte blue value of RGB if “3 objects of 1 Byte” option is selected in the parameter list.

DPT: 5.010 (counter pulses)

|   |          |                  |        |       |
|---|----------|------------------|--------|-------|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | RGBW Blue Colour | 1 byte | CRWTU |
|---|----------|------------------|--------|-------|

If the “object type” is set to “4 objects”, this object keeps the 1-Byte Blue value of the RGBW.

DPT: 5.010 (counter pulses)

|   |          |                               |       |     |
|---|----------|-------------------------------|-------|-----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Thermostat Enable/Disable – B | 1 bit | CRT |
|---|----------|-------------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The thermostat status is controlled via this object.

DPT: 1.003 (enable)

|   |          |                                 |       |     |
|---|----------|---------------------------------|-------|-----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Thermostat Heat Cool Switch – B | 1 bit | CRT |
|---|----------|---------------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. Heating/cooling mode changeover is controlled via this object.

DPT: 1.100 (cooling/heating)

|   |          |                                 |        |     |
|---|----------|---------------------------------|--------|-----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Thermostat HVAC Mode Switch – B | 1 byte | CRT |
|---|----------|---------------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The HVAC operating mode is controlled via this object.

DPT: 20.102 (HVAC mode)

|   |          |                         |         |     |
|---|----------|-------------------------|---------|-----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Thermostat Setpoint – B | 2 bytes | CRT |
|---|----------|-------------------------|---------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The setpoint temperature is controlled via this object.

DPT: 9.001 (temperature °C)

|   |          |                          |        |     |
|---|----------|--------------------------|--------|-----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Thermostat Fan Level – B | 1 byte | CRT |
|---|----------|--------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The fan speed is controlled via this object.

DPT: 5.100 (switch)

|   |          |                         |       |     |
|---|----------|-------------------------|-------|-----|
| 14, 22, 30, 38, 46,<br>54, 62, 70, 78, 86 | Button X | Thermostat Fan Mode – B | 1 bit | CRT |
|---|----------|-------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The fan auto/manual working mode is controlled via this object.

DPT: 1.003 (enable)

|   |          |                   |        |       |
|---|----------|-------------------|--------|-------|
| 15, 23, 31, 39, 47,<br>55, 63, 71, 79, 87 | Button X | RGBW White Colour | 1 byte | CRWTU |
|---|----------|-------------------|--------|-------|

If the “object type” is set to “4 objects”, this object keeps the 1-Byte White value of the RGBW.

**Note:** White value is the colour temperature.

DPT: 5.010 (counter pulses)

|   |          |                          |       |     |
|---|----------|--------------------------|-------|-----|
| 15, 23, 31, 39, 47,<br>55, 63, 71, 79, 87 | Button X | Thermostat Status Fb – B | 1 bit | CWU |
|---|----------|--------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The thermostat status is watched via this object.

DPT: 1.003 (enable)

|   |          |                             |       |     |
|---|----------|-----------------------------|-------|-----|
| 15, 23, 31, 39, 47,<br>55, 63, 71, 79, 87 | Button X | Thermostat Heat Cool Fb – B | 1 bit | CWU |
|---|----------|-----------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The heating/cooling mode is watched via this object.

DPT: 1.100 (cooling/heating)

|   |          |                        |        |     |
|---|----------|------------------------|--------|-----|
| 15, 23, 31, 39, 47,<br>55, 63, 71, 79, 87 | Button X | Thermostat HVAC Fb – B | 1 byte | CWU |
|---|----------|------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat. The HVAC operating mode is watched via this object.

DPT: 20.102 (HVAC mode)

|   |          |                            |         |     |
|---|----------|----------------------------|---------|-----|
| 15, 23, 31, 39, 47,<br>55, 63, 71, 79, 87 | Button X | Thermostat Setpoint Fb – B | 2 bytes | CWU |
|---|----------|----------------------------|---------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The setpoint temperature is watched via this object.

DPT: 9.001 (temperature (°C))

|   |          |                             |        |     |
|---|----------|-----------------------------|--------|-----|
| 15, 23, 31, 39, 47,<br>55, 63, 71, 79, 87 | Button X | Thermostat Fan Level Fb – B | 1 byte | CWU |
|---|----------|-----------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The fan speed is watched via this object.

DPT: 1.003 (enable)

|   |          |                            |       |     |
|---|----------|----------------------------|-------|-----|
| 15, 23, 31, 39, 47,<br>55, 63, 71, 79, 87 | Button X | Thermostat Fan Mode Fb - B | 1 bit | CWU |
|---|----------|----------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The fan auto/manual working mode is watched via this object.

DPT: 1.003 (enable)

|   |          |                      |       |    |
|---|----------|----------------------|-------|----|
| 16, 24, 32, 40, 48,<br>56, 64, 72, 80, 88 | Button X | Upper Limit Position | 1 bit | CW |
|---|----------|----------------------|-------|----|

This object is used for the shutter actuator indicates if it is in the lower limit position (“shutter/blind closed”). The object is intended for a 1-button operation. ‘0’ is no lower limit operation, ‘1’ lower end operation.

DPT: 1.002 (boolean)

|   |          |            |                   |     |
|---|----------|------------|-------------------|-----|
| 16, 24, 32, 40, 48,<br>56, 64, 72, 80, 88 | Button X | Sequence C | 1 bit / 1<br>byte | CRT |
|---|----------|------------|-------------------|-----|

This object keeps the current command that can be toggled through press events. Used for “Multiple Object” parameter selection.

Note: Each object (Object A, B, C, D) holds a different value with adjustable data length. Each press event puts the next available state’s data to the “Sequence X” object and whichever object is holds the current state is sent to bus with its data.

DPT: According to parameter selection

|   |          |          |                   |      |
|---|----------|----------|-------------------|------|
| 16, 24, 32, 40, 48,<br>56, 64, 72, 80, 88 | Button X | Overflow | 1 bit / 1<br>byte | CRWT |
|---|----------|----------|-------------------|------|

This object is sent to bus with the preset value from the parameter list when the counter value exceeds the preset end value of the counter.

DPT: 1.001 (switch) / 5.010 (counter pulses)

|   |          |                      |       |    |
|---|----------|----------------------|-------|----|
| 17, 25, 33, 41, 49,<br>57, 65, 73, 81, 89 | Button X | Lower Limit Position | 1 bit | CW |
|---|----------|----------------------|-------|----|

This object is used for the shutter actuator indicates if it is in the lower limit position (“shutter/blind closed”). The object is intended for a 1-button operation. ‘0’ is no lower limit operation, ‘1’ lower end operation.

DPT: 1.002 (boolean)

|   |          |            |                   |     |
|---|----------|------------|-------------------|-----|
| 17, 25, 33, 41, 49,<br>57, 65, 73, 81, 89 | Button X | Sequence D | 1 bit / 1<br>byte | CRT |
|---|----------|------------|-------------------|-----|

This object keeps the current command that can be toggled through press events. Used for “Multiple Object” parameter selection.

Note: Each object (Object A, B, C, D) holds a different value with adjustable data length. Each press event puts the next available state’s data to the “Sequence X” object and whichever object is holds the current state is sent to bus with its data.

DPT: According to parameter selection

## 5.3. Input Objects

In this section, Input X objects are described in the table below. In the first column name of the object, in the second column function name, the third column data type and fourth column the objects flags, information is given.

X: 1 / 2

| Object Number | Object Name | Function | Type  | Flags |
|---------------|-------------|----------|-------|-------|
| 90, 98        | Input X     | Disable  | 1 bit | CW    |

This object is used to set the iSwitch+ external input X status. “Enabled” or “Disabled” telegram is received via this object.

For example, it will be disabled when an “Enabled” telegram is received from the KNX bus line, and when a “Disabled” telegram is received, the external input X will continue working.

DPT: 1.003 (enable)

|        |         |        |       |     |
|--------|---------|--------|-------|-----|
| 91, 99 | Input X | Status | 1 bit | CRT |
|--------|---------|--------|-------|-----|

This object is used to watch input X status. “Enabled” or “Disabled” telegram is transmitted to KNX bus via this object when input X status is changed over device.

DPT: 1.001 (switch)

|         |         |        |       |       |
|---------|---------|--------|-------|-------|
| 92, 100 | Input X | Switch | 1 bit | CRWTU |
|---------|---------|--------|-------|-------|

This communication object changes in functionality depending on the selected input function. In accordance with the parameter setting, this communication object can be switched by actuation of the input to ON, OFF or TOGGLE.

DPT: 1.001 (switch)

|         |         |                 |       |     |
|---------|---------|-----------------|-------|-----|
| 92, 100 | Input X | Shutter UP/Down | 1 bit | CWT |
|---------|---------|-----------------|-------|-----|

This communication object changes in functionality depending on the selected input function. This communication object sends a shutter motion telegram UP or DOWN on the bus. By receiving telegrams, the device also recognizes movement telegrams of another sensor, e.g. parallel operation.

DPT: 1.008 (up/down)

|         |         |                  |  |    |
|---------|---------|------------------|--|----|
| 92, 100 | Input X | Forced Operation | 2 bit / 1<br>byte / 2<br>bytes/ 3<br>bytes | CT |
|---------|---------|------------------|--|----|

This communication object changes in functionality depending on the selected input function. This communication object sends a value on the bus with short operation when opening or closing of the contact. Depending on the configuration, the data type of this object changes. forced, percent value, decimal value,

Scene number, temperature value, brightness value and percent value (RGB) can be performed on this object.

DPT: According to parameter selection

|         |         |       |        |     |
|---------|---------|-------|--------|-----|
| 92, 100 | Input X | Scene | 1 byte | CRT |
|---------|---------|-------|--------|-----|

This communication object stores the value of the active scene number (1 - 64).

DPT: 18.001 (scene control)

|         |         |                |        |     |
|---------|---------|----------------|--------|-----|
| 92, 100 | Input X | Mode selection | 1 byte | CWT |
|---------|---------|----------------|--------|-----|

This object keeps the active HVAC state that can be toggled through press events.

Note: There can be up to 4 different HVAC state (comfort, standby, economy, building protection) selected and each press event toggles through the HVAC states that are set as available in the parameter list.

DPT: 20.102 (HVAC mode)

|         |         |          |                |     |
|---------|---------|----------|----------------|-----|
| 92, 100 | Input X | Sequence | 1 bit / 1 byte | CRT |
|---------|---------|----------|----------------|-----|

This object keeps the current command that can be toggled through press events. Used for “Single Object” parameter selection.

**Note:** Each state (State A, B, C, D) holds a different value with adjustable data length. Each press event puts the next available state’s data to the “Sequence” object.

DPT: According to parameter selection

|         |         |            |                |     |
|---------|---------|------------|----------------|-----|
| 92, 100 | Input X | Sequence A | 1 bit / 1 byte | CRT |
|---------|---------|------------|----------------|-----|

This object keeps the current command that can be toggled through press events. Used for “Multiple Object” parameter selection.

Note: Each object (Object A, B, C, D) holds a different value with adjustable data length. Each press event puts the next available state’s data to the “Sequence X” object and whichever object is holds the current state is sent to bus with its data.

DPT: According to parameter selection

|         |         |               |                            |     |
|---------|---------|---------------|----------------------------|-----|
| 92, 100 | Input X | Counter value | 1 byte / 2 bytes / 4 bytes | CRT |
|---------|---------|---------------|----------------------------|-----|

This object keeps the current value of the press counter.

DPT: According to parameter selection

|         |         |                             |                  |       |
|---------|---------|-----------------------------|------------------|-------|
| 92, 100 | Input X | RGB Red Colour / RGB Colour | 1 byte / 3 bytes | CRWTU |
|---------|---------|-----------------------------|------------------|-------|

This object either keeps the 1-Byte Red value of the RGB, or keeps the entire 3-Byte RGB value. Decision is made in the parameter list as either “1 object of 3 bytes” or 3 objects of 1 byte”.

DPT: 5.010 (counter pulses) / 232.600 (RGB value)

|         |         |                               |                  |       |
|---------|---------|-------------------------------|------------------|-------|
| 92, 100 | Input X | RGBW Red Colour / RGBW Colour | 6 bytes / 1 byte | CRWTU |
|---------|---------|-------------------------------|------------------|-------|

If the “object type” is set to “1 object”, this object keeps the 6-Byte RGBW value, but, if the “object type” is set to “4 objects”, this object keeps the 1-Byte Red value of the RGBW.

DPT: 251.600 (RGBW value) / 5.010 (counter pulses)

|         |         |                               |       |     |
|---------|---------|-------------------------------|-------|-----|
| 92, 100 | Input X | Thermostat Enable/Disable - A | 1 bit | CRT |
|---------|---------|-------------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. Thermostat status is controlled via this object.

DPT: 1.003 (enable)

|         |         |                                 |       |     |
|---------|---------|---------------------------------|-------|-----|
| 92, 100 | Input X | Thermostat Heat Cool Switch - A | 1 bit | CRT |
|---------|---------|---------------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. Heating/cooling mode changeover is controlled via this object.

DPT: 1.100 (cooling/heating)

|         |         |                                 |        |     |
|---------|---------|---------------------------------|--------|-----|
| 92, 100 | Input X | Thermostat HVAC Mode Switch - A | 1 byte | CRT |
|---------|---------|---------------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The HVAC operating mode is watched via this object.

DPT: 20.102 (HVAC mode)

|         |         |                         |         |     |
|---------|---------|-------------------------|---------|-----|
| 92, 100 | Input X | Thermostat Setpoint - A | 2 bytes | CRT |
|---------|---------|-------------------------|---------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The setpoint temperature is controlled via this object.

DPT: 9.001 (temperature °C)

|         |         |                          |        |     |
|---------|---------|--------------------------|--------|-----|
| 92, 100 | Input X | Thermostat Fan Level - A | 1 byte | CRT |
|---------|---------|--------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat on short press operation. The fan speed is controlled via this object.

DPT: 5.100 (switch)

|                |                |                                |              |            |
|----------------|----------------|--------------------------------|--------------|------------|
| <b>92, 100</b> | <b>Input X</b> | <b>Thermostat Fan Mode - A</b> | <b>1 bit</b> | <b>CRT</b> |
|----------------|----------------|--------------------------------|--------------|------------|

This object can be used via thermostat extension control function for external thermostat on short press operation. The fan auto/manual working mode is controlled via this object.

DPT: 1.003 (enable)

|                |                |                         |  |              |
|----------------|----------------|-------------------------|--|--------------|
| <b>93, 101</b> | <b>Input X</b> | <b>RGB Green Colour</b> |  | <b>RWCTU</b> |
|----------------|----------------|-------------------------|--|--------------|

This object keeps the 1-Byte green value of RGB if “3 objects of 1 Byte” option is selected in the parameter list.

DPT: 5.010 (counter pulses)

|                |                |                          |  |              |
|----------------|----------------|--------------------------|--|--------------|
| <b>93, 101</b> | <b>Input X</b> | <b>RGBW Green Colour</b> |  | <b>RWCTU</b> |
|----------------|----------------|--------------------------|--|--------------|

If the “object type” is set to “4 objects”, this object keeps the 1-Byte Green value of the RGBW.

DPT: 5.010 (counter pulses)

|                |                |                                 |              |            |
|----------------|----------------|---------------------------------|--------------|------------|
| <b>93, 101</b> | <b>Input X</b> | <b>Thermostat Status Fb - A</b> | <b>1 bit</b> | <b>CWU</b> |
|----------------|----------------|---------------------------------|--------------|------------|

This object can be used via thermostat extension control function for external thermostat on short press operation. The thermostat status is watched via this object.

DPT: 1.003 (enable)

|                |                |                                    |              |            |
|----------------|----------------|------------------------------------|--------------|------------|
| <b>93, 101</b> | <b>Input X</b> | <b>Thermostat Heat Cool Fb - A</b> | <b>1 bit</b> | <b>CWU</b> |
|----------------|----------------|------------------------------------|--------------|------------|

This object can be used via thermostat extension control function for external thermostat on short press operation. The heating/cooling mode is watched via this object.

DPT: 1.100 (cooling/heating)

|                |                |                               |               |            |
|----------------|----------------|-------------------------------|---------------|------------|
| <b>93, 101</b> | <b>Input X</b> | <b>Thermostat HVAC Fb - A</b> | <b>1 byte</b> | <b>CWU</b> |
|----------------|----------------|-------------------------------|---------------|------------|

This object can be used via thermostat extension control function for external thermostat on short press operation. The HVAC operating mode is watched via this object.

DPT: 20.102 (HVAC mode)

|                |                |                                   |                |            |
|----------------|----------------|-----------------------------------|----------------|------------|
| <b>93, 101</b> | <b>Input X</b> | <b>Thermostat Setpoint Fb - A</b> | <b>2 bytes</b> | <b>CWU</b> |
|----------------|----------------|-----------------------------------|----------------|------------|

This object can be used via thermostat extension control function for external thermostat on short press operation. The setpoint temperature is watched via this object.

DPT: 9.001 (temperature (°C))

|                |                |                                    |               |            |
|----------------|----------------|------------------------------------|---------------|------------|
| <b>93, 101</b> | <b>Input X</b> | <b>Thermostat Fan Level Fb - A</b> | <b>1 byte</b> | <b>CWU</b> |
|----------------|----------------|------------------------------------|---------------|------------|

This object can be used via thermostat extension control function for external thermostat on short press operation. The fan speed is controlled via this object.

DPT: 1.003 (enable)

|                |                |                                   |              |            |
|----------------|----------------|-----------------------------------|--------------|------------|
| <b>93, 101</b> | <b>Input X</b> | <b>Thermostat Fan Mode Fb - A</b> | <b>1 bit</b> | <b>CWU</b> |
|----------------|----------------|-----------------------------------|--------------|------------|

This object can be used via thermostat extension control function for external thermostat on short press operation. The fan auto/manual working mode is watched via this object.

DPT: 1.003 (enable)

|                |                |                      |              |              |
|----------------|----------------|----------------------|--------------|--------------|
| <b>94, 102</b> | <b>Input X</b> | <b>Switch - Long</b> | <b>1 bit</b> | <b>CRWTU</b> |
|----------------|----------------|----------------------|--------------|--------------|

This communication object changes in functionality depending on the selected input function. In accordance with the parameter setting, this communication object can be switched by actuation of the input to ON, OFF or TOGGLE.

DPT: 1.001 (switch)

|                |                |                |               |           |
|----------------|----------------|----------------|---------------|-----------|
| <b>94, 102</b> | <b>Input X</b> | <b>Dimming</b> | <b>4 bits</b> | <b>CT</b> |
|----------------|----------------|----------------|---------------|-----------|

This communication object changes in functionality depending on the selected input function. In accordance with the parameter setting, A long operation at the input has the effect that BRIGHTER or DARKER dim telegrams are sent via this communication object on the bus. A STOP telegram is sent and the cyclic sending of dim telegrams is stopped at the end of actuation with START-STOP-DIMMING.

DPT: 3.007 (dimming control)

|                |                |                                  |              |            |
|----------------|----------------|----------------------------------|--------------|------------|
| <b>94, 102</b> | <b>Input X</b> | <b>STOP / Lamella Adjustment</b> | <b>1 bit</b> | <b>CWT</b> |
|----------------|----------------|----------------------------------|--------------|------------|

This communication object changes in functionality depending on the selected input function. This communication object sends a STOP telegram or slat adjustment.

DPT: 1.007 (step)

|                |                |                                |  |           |
|----------------|----------------|--------------------------------|--|-----------|
| <b>94, 102</b> | <b>Input X</b> | <b>Forced Operation – Long</b> | <b>2 bit / 1<br/>byte / 2<br/>bytes/ 3<br/>bytes</b> | <b>CT</b> |
|----------------|----------------|--------------------------------|--|-----------|

This communication object changes in functionality depending on the selected input function. This communication object sends a value on the bus with short operation when opening or closing of the contact. Depending on the configuration, the data type of this object changes. forced, percent value, decimal value,

Scene number, temperature value, brightness value and percent value (RGB) can be performed on this object.

DPT: According to parameter selection

|         |         |             |       |     |
|---------|---------|-------------|-------|-----|
| 94, 102 | Input X | Scene Store | 1 bit | CRW |
|---------|---------|-------------|-------|-----|

This communication object, when active, decides whether to call or store the preset 8-bit scene number in the parameter list. When the store scene object is enabled the preset scene number is stored, but, when disabled preset scene number is called to be active.

DPT: 1.003 (enable)

|         |         |                 |        |      |
|---------|---------|-----------------|--------|------|
| 94, 102 | Input X | HVAC-Mode State | 1 byte | CWTU |
|---------|---------|-----------------|--------|------|

This object takes the HVAC state changed via the bus.

**Note:** Whenever this object is updated from the bus, the HVAC state that this object holds will be considered as the valid HVAC state and press events will act as if the last HVAC state is what this object is updated with.

DPT: 20.102 (HVAC mode)

|         |         |            |                |     |
|---------|---------|------------|----------------|-----|
| 94, 102 | Input X | Sequence B | 1 bit / 1 byte | CRT |
|---------|---------|------------|----------------|-----|

This object keeps the current command that can be toggled through press events. Used for “Multiple Object” parameter selection.

**Note:** Each object (Object A, B, C, D) holds a different value with adjustable data length. Each press event puts the next available state’s data to the “Sequence X” object and whichever object is holds the current state is sent to bus with its data.

DPT: According to parameter selection

|         |         |               |       |    |
|---------|---------|---------------|-------|----|
| 94, 102 | Input X | Reset counter | 1 bit | CW |
|---------|---------|---------------|-------|----|

This object is used to reset the counter value to preset start value that can be set from parameter list.

DPT: According to parameter selection

|         |         |                 |        |       |
|---------|---------|-----------------|--------|-------|
| 94, 102 | Input X | RGB Blue Colour | 1 byte | RWCTU |
|---------|---------|-----------------|--------|-------|

This object keeps the 1-Byte green value of RGB if “3 objects of 1 Byte” option is selected in the parameter list.

DPT: 5.010 (counter pulses)

|         |         |                  |        |       |
|---------|---------|------------------|--------|-------|
| 94, 102 | Input X | RGBW Blue Colour | 1 byte | RWCTU |
|---------|---------|------------------|--------|-------|

If the “object type” is set to “4 objects”, this object keeps the 1-Byte Green value of the RGBW.

DPT: 5.010 (counter pulses)

|         |         |                               |       |     |
|---------|---------|-------------------------------|-------|-----|
| 94, 102 | Input X | Thermostat Enable/Disable – B | 1 bit | CRT |
|---------|---------|-------------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The thermostat status is controlled via this object.

DPT: 1.003 (enable)

|         |         |                                 |       |     |
|---------|---------|---------------------------------|-------|-----|
| 94, 102 | Input X | Thermostat Heat Cool Switch – B | 1 bit | CRT |
|---------|---------|---------------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. Heating/cooling mode changeover is controlled via this object.

DPT: 1.100 (cooling/heating)

|         |         |                                 |        |     |
|---------|---------|---------------------------------|--------|-----|
| 94, 102 | Input X | Thermostat HVAC Mode Switch – B | 1 byte | CRT |
|---------|---------|---------------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The HVAC operating mode is controlled via this object.

DPT: 20.102 (HVAC mode)

|         |         |                         |         |     |
|---------|---------|-------------------------|---------|-----|
| 94, 102 | Input X | Thermostat Setpoint – B | 2 bytes | CRT |
|---------|---------|-------------------------|---------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The setpoint temperature is controlled via this object.

DPT: 9.001 (temperature °C)

|         |         |                          |        |     |
|---------|---------|--------------------------|--------|-----|
| 94, 102 | Input X | Thermostat Fan Level – B | 1 byte | CRT |
|---------|---------|--------------------------|--------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The fan speed is controlled via this object.

DPT: 5.100 (switch)

|         |         |                         |       |     |
|---------|---------|-------------------------|-------|-----|
| 94, 102 | Input X | Thermostat Fan Mode – B | 1 bit | CRT |
|---------|---------|-------------------------|-------|-----|

This object can be used via thermostat extension control function for external thermostat on long press operation. The fan auto/manual working mode is controlled via this object.

DPT: 1.003 (enable)

|         |         |                   |        |       |
|---------|---------|-------------------|--------|-------|
| 95, 103 | Input X | RGBW White Colour | 1 byte | RWCTU |
|---------|---------|-------------------|--------|-------|

If the “object type” is set to “4 objects”, this object keeps the 1-Byte White value of the RGBW.

**Note:** White value is the colour temperature.

DPT: 5.010 (counter pulses)

|                |                |                                 |              |            |
|----------------|----------------|---------------------------------|--------------|------------|
| <b>95, 103</b> | <b>Input X</b> | <b>Thermostat Status Fb – B</b> | <b>1 bit</b> | <b>CWU</b> |
|----------------|----------------|---------------------------------|--------------|------------|

This object can be used via thermostat extension control function for external thermostat on long press operation. The thermostat status is watched via this object.

DPT: 1.003 (enable)

|                |                |                                    |              |            |
|----------------|----------------|------------------------------------|--------------|------------|
| <b>95, 103</b> | <b>Input X</b> | <b>Thermostat Heat Cool Fb – B</b> | <b>1 bit</b> | <b>CWU</b> |
|----------------|----------------|------------------------------------|--------------|------------|

This object can be used via thermostat extension control function for external thermostat on long press operation. The heating/cooling mode is watched via this object.

DPT: 1.100 (cooling/heating)

|                |                |                               |               |            |
|----------------|----------------|-------------------------------|---------------|------------|
| <b>95, 103</b> | <b>Input X</b> | <b>Thermostat HVAC Fb – B</b> | <b>1 byte</b> | <b>CWU</b> |
|----------------|----------------|-------------------------------|---------------|------------|

This object can be used via thermostat extension control function for external thermostat. The HVAC operating mode is watched via this object.

DPT: 20.102 (HVAC mode)

|                |                |                                   |                |            |
|----------------|----------------|-----------------------------------|----------------|------------|
| <b>95, 103</b> | <b>Input X</b> | <b>Thermostat Setpoint Fb – B</b> | <b>2 bytes</b> | <b>CWU</b> |
|----------------|----------------|-----------------------------------|----------------|------------|

This object can be used via thermostat extension control function for external thermostat on long press operation. The setpoint temperature is controlled via this object.

DPT: 9.001 (temperature (°C))

|                |                |                                    |               |            |
|----------------|----------------|------------------------------------|---------------|------------|
| <b>95, 103</b> | <b>Input X</b> | <b>Thermostat Fan Level Fb – B</b> | <b>1 byte</b> | <b>CWU</b> |
|----------------|----------------|------------------------------------|---------------|------------|

This object can be used via thermostat extension control function for external thermostat on long press operation. The fan speed is watched via this object.

DPT: 1.003 (enable)

|                |                |                                   |              |            |
|----------------|----------------|-----------------------------------|--------------|------------|
| <b>95, 103</b> | <b>Input X</b> | <b>Thermostat Fan Mode Fb – B</b> | <b>1 bit</b> | <b>CWU</b> |
|----------------|----------------|-----------------------------------|--------------|------------|

This object can be used via thermostat extension control function for external thermostat on long press operation. The fan auto/manual working mode is watched via this object.

DPT: 1.003 (enable)

|                |                |                             |              |           |
|----------------|----------------|-----------------------------|--------------|-----------|
| <b>96, 104</b> | <b>Input X</b> | <b>Upper Limit Position</b> | <b>1 bit</b> | <b>CW</b> |
|----------------|----------------|-----------------------------|--------------|-----------|

This object is used for the shutter actuator indicates if it is in the lower limit position (“shutter/blind closed”). The object is intended for a 1-button operation. ‘0’ is no lower limit operation, ‘1’ lower end operation.

DPT: 1.002 (boolean)

|         |         |            |                |     |
|---------|---------|------------|----------------|-----|
| 96, 104 | Input X | Sequence C | 1 bit / 1 byte | CRT |
|---------|---------|------------|----------------|-----|

This object keeps the current command that can be toggled through press events. Used for “Multiple Object” parameter selection.

**Note:** Each object (Object A, B, C, D) holds a different value with adjustable data length. Each press event puts the next available state’s data to the “Sequence X” object and whichever object is holds the current state is sent to bus with its data.

DPT: According to parameter selection

|         |         |          |                |    |
|---------|---------|----------|----------------|----|
| 96, 104 | Input X | Overflow | 1 bit / 1 byte | CT |
|---------|---------|----------|----------------|----|

This object is sent to bus with the preset value from the parameter list when the counter value exceeds the preset end value of the counter.

DPT: 1.001 (switch) / 5.010 (counter pulses)

|         |         |                      |       |    |
|---------|---------|----------------------|-------|----|
| 97, 105 | Input X | Lower Limit Position | 1 bit | CW |
|---------|---------|----------------------|-------|----|

This object is used for the shutter actuator indicates if it is in the lower limit position (“shutter/blind closed”). The object is intended for a 1-button operation. ‘0’ is no lower limit operation, ‘1’ lower end operation.

DPT: 1.002 (boolean)

|         |         |            |                |     |
|---------|---------|------------|----------------|-----|
| 97, 105 | Input X | Sequence D | 1 bit / 1 byte | CRT |
|---------|---------|------------|----------------|-----|

This object keeps the current command that can be toggled through press events. Used for “Multiple Object” parameter selection.

**Note:** Each object (Object A, B, C, D) holds a different value with adjustable data length. Each press event puts the next available state’s data to the “Sequence X” object and whichever object is holds the current state is sent to bus with its data.

DPT: According to parameter selection

## 5.4. LED Objects

In this section, LED X objects are described in the table below. In the first column name of the object, in the second column function name, the third column data type and fourth column the objects flags, information is given.

X: 1 ... 10

| Object Number                                | Object Name | Function | Type  | Flags |
|--|-------------|----------|-------|-------|
| 106, 112, 118,<br>124, 130, 136,<br>142, 148 | Led X       | Disable  | 1 bit | CW    |

This object is used to set the iSwitch+ LED X status. “Enabled” or “Disabled” telegram is received via this object.

For example, it will be disabled when an “Enabled” telegram is received from the KNX bus line, and when a “Disabled” telegram is received, the LED X will continue working.

DPT: 1.003 (enable)

|  |       |        |       |     |
|--|-------|--------|-------|-----|
| 107, 113, 119,<br>125, 131, 137,<br>143, 149 | Led X | Status | 1 bit | CRT |
|--|-------|--------|-------|-----|

This object is used to watch LED X status. “Enabled” or “Disabled” telegram is transmitted to KNX bus via this object when LED X status is changed over device.

DPT: 1.001 (switch)

|  |       |        |       |       |
|--|-------|--------|-------|-------|
| 108, 114, 120,<br>126, 132, 138,<br>144, 150 | Led X | Switch | 1 bit | CRWTU |
|--|-------|--------|-------|-------|

This communication object changes in functionality depending on the selected input function. In accordance with the parameter setting, this communication object can be switched by actuation of the input to ON, OFF or TOGGLE.

DPT: 1.001 (switch)

|  |       |               |       |    |
|--|-------|---------------|-------|----|
| 109, 115, 121,<br>127, 133, 139,<br>145, 151 | Led X | Blink Trigger | 1 bit | CW |
|--|-------|---------------|-------|----|

This object is used to blink LED X along time set in parameter. If “Trigger” telegram is received via this object.

DPT: 1.017 (trigger)

## 5.5. Measurements Objects

In this section, Measurement's objects are described in the table below. In the first column name of the object, in the second column function name, the third column data type and fourth column the objects flags, information is given.

### 5.5.1. Temperature Measurement Objects

| Object Number | Object Name                      | Function | Type  | Flags |
|---------------|----------------------------------|----------|-------|-------|
| 166           | Measurement Temperature Internal | Disable  | 1 bit | CW    |

This object is used to set the iSwitch+ internal temperature sensor status. "Enabled" or "Disabled" telegram is received via this object.

For example, it will be disabled when an "Enabled" telegram is received from the KNX bus line, and when a "Disabled" telegram is received, the internal temperature sensor will continue the measurement. On disabled, any telegram isn't transmitted to the KNX bus.

DPT: 1.003 (enable)

|     |                                  |        |       |     |
|-----|----------------------------------|--------|-------|-----|
| 167 | Measurement Temperature Internal | Status | 1 bit | CRT |
|-----|----------------------------------|--------|-------|-----|

This object is used to watch internal temperature sensor status. "Enabled" or "Disabled" telegram is transmitted to KNX bus via this object when internal temperature sensor status is changed over device.

DPT: 1.003 (enable)

|     |                                  |                   |         |     |
|-----|----------------------------------|-------------------|---------|-----|
| 168 | Measurement Temperature Internal | Temperature Value | 2 bytes | CRT |
|-----|----------------------------------|-------------------|---------|-----|

This object is used to send the measurement value that is measured by the sensor after calibrating it. Each measurement value can be calibrated via "Adjustment factor" parameter or "Calibration" object. Depending on the parameter configuration, the calculated data can be sent to the bus line periodically or according to the amount of change.

DPT: 9.001 (temperature (°C))

|            |   |                                |                |           |
|------------|---|--------------------------------|----------------|-----------|
| <b>169</b> | <b>Measurement<br/>Temperature<br/>Internal</b> | <b>Temperature Calibration</b> | <b>2 bytes</b> | <b>CW</b> |
|------------|---|--------------------------------|----------------|-----------|

This object is used to calibrate the measurement output by measuring the actual measurement value via an external device and then writing this value to the object. When iSwitch+ received the value, calibrate its measurement output automatically.

\*This object is used to calculate the adjustment factor. The adjustment factor can't be zero or negative. Thus, you mustn't enter input value with opposite sign than the current measurement to calculate adjustment factor properly.

DPT: 9.001 (temperature (°C))

|            |   |                      |              |           |
|------------|---|----------------------|--------------|-----------|
| <b>170</b> | <b>Measurement<br/>Temperature<br/>Internal</b> | <b>Alarm - Fault</b> | <b>1 bit</b> | <b>CT</b> |
|------------|---|----------------------|--------------|-----------|

This object is used to send an alarm when the sensor is at fault that causes any reason.

DPT: 1.005 (alarm)

|            |   |                    |              |           |
|------------|---|--------------------|--------------|-----------|
| <b>171</b> | <b>Measurement<br/>Temperature<br/>Internal</b> | <b>Alarm - Low</b> | <b>1 bit</b> | <b>CT</b> |
|------------|---|--------------------|--------------|-----------|

“Low Level Alarm” object sends “Alarm” telegram when the measurement value goes below the low-level value and “No Alarm” telegram when the measurement value returns above it.

DPT: 1.005 (alarm)

|            |   |                     |              |           |
|------------|---|---------------------|--------------|-----------|
| <b>172</b> | <b>Measurement<br/>Temperature<br/>Internal</b> | <b>Alarm - High</b> | <b>1 bit</b> | <b>CT</b> |
|------------|---|---------------------|--------------|-----------|

“Alarm - High” object sends “Alarm” telegram when the measurement value exceeds the high-level value and “No Alarm” telegram when the measurement value returns below it.

DPT: 1.005 (alarm)

|            |   |                         |                            |           |
|------------|---|-------------------------|----------------------------|-----------|
| <b>173</b> | <b>Measurement<br/>Temperature<br/>Internal</b> | <b>Additional Value</b> | <b>1 bit / 1<br/>bytes</b> | <b>CT</b> |
|------------|---|-------------------------|----------------------------|-----------|

When the measurement value changed, this object sends telegrams with specific type and values according to the related parameters.

DPT: According to parameter selection

## 5.5.2. Humidity Measurement Objects

| Object Number | Object Name                   | Function | Type  | Flags |
|---------------|-------------------------------|----------|-------|-------|
| 174           | Measurement Humidity Internal | Disable  | 1 bit | CW    |

This object is used to set the iSwitch+ internal humidity sensor status. “Enabled” or “Disabled” telegram is received via this object.

For example, it will be disabled when an “Enabled” telegram is received from the KNX bus line, and when a “Disabled” telegram is received, the internal humidity sensor will continue the measurement. On disabled, any telegram isn’t transmitted to the KNX bus.

DPT: 1.003 (enable)

|     |                               |        |       |     |
|-----|-------------------------------|--------|-------|-----|
| 175 | Measurement Humidity Internal | Status | 1 bit | CRT |
|-----|-------------------------------|--------|-------|-----|

This object is used to watch internal humidity sensor status. “Enabled” or “Disabled” telegram is transmitted to KNX bus via this object when internal humidity sensor status is changed over device.

DPT: 1.003 (enable)

|     |                               |                |         |     |
|-----|-------------------------------|----------------|---------|-----|
| 176 | Measurement Humidity Internal | Humidity Value | 2 bytes | CRT |
|-----|-------------------------------|----------------|---------|-----|

This object is used to send the measurement value that is measured by the sensor after calibrating it. Each measurement value can be calibrated via “Adjustment factor” parameter or “Calibration” object. Depending on the parameter configuration, the calculated data can be sent to the bus line periodically or according to the amount of change.

DPT: 9.007 (humidity (%))

|     |                               |                      |         |    |
|-----|-------------------------------|----------------------|---------|----|
| 177 | Measurement Humidity Internal | Humidity Calibration | 2 bytes | CW |
|-----|-------------------------------|----------------------|---------|----|

This object is used to calibrate the measurement output by measuring the actual measurement value via an external device and then writing this value to the object. When iSwitch+ received the value, calibrate its measurement output automatically.

\*This object is used to calculate the adjustment factor. The adjustment factor can’t be zero or negative. Thus, you mustn’t enter input value with opposite sign than the current measurement to calculate adjustment factor properly.

DPT: 9.007 (humidity (%))

|     |                                     |               |       |    |
|-----|-------------------------------------|---------------|-------|----|
| 178 | Measurement<br>Humidity<br>Internal | Alarm - Fault | 1 bit | CT |
|-----|-------------------------------------|---------------|-------|----|

This object is used to send an alarm when the sensor is at fault that causes any reason.

DPT: 1.005 (alarm)

|     |                                     |             |       |    |
|-----|-------------------------------------|-------------|-------|----|
| 179 | Measurement<br>Humidity<br>Internal | Alarm - Low | 1 bit | CT |
|-----|-------------------------------------|-------------|-------|----|

“Low Level Alarm” object sends “Alarm” telegram when the measurement value goes below the low-level value and “No Alarm” telegram when the measurement value returns above it.

DPT: 1.005 (alarm)

|     |                                     |              |       |    |
|-----|-------------------------------------|--------------|-------|----|
| 180 | Measurement<br>Humidity<br>Internal | Alarm - High | 1 bit | CT |
|-----|-------------------------------------|--------------|-------|----|

“Alarm - High” object sends “Alarm” telegram when the measurement value exceeds the high-level value and “No Alarm” telegram when the measurement value returns below it.

DPT: 1.005 (alarm)

|     |                                     |                  |                    |    |
|-----|-------------------------------------|------------------|--------------------|----|
| 181 | Measurement<br>Humidity<br>Internal | Additional Value | 1 bit / 1<br>bytes | CT |
|-----|-------------------------------------|------------------|--------------------|----|

When the measurement value changed, this object sends telegrams with specific type and values according to the related parameters.

DPT: According to parameter selection

### 5.5.3. Air Quality Measurement Objects

| Object Number | Object Name                            | Function | Type  | Flags |
|---------------|--|----------|-------|-------|
| 182           | Measurement<br>Air Quality<br>Internal | Disable  | 1 bit | CW    |

This object is used to set the iSwitch+ internal air quality sensor status. “Enabled” or “Disabled” telegram is received via this object.

For example, it will be disabled when an “Enabled” telegram is received from the KNX bus line, and when a “Disabled” telegram is received, the internal air quality sensor will continue the measurement. On disabled, any telegram isn’t transmitted to the KNX bus.

DPT: 1.003 (enable)

|     |  |        |       |     |
|-----|--|--------|-------|-----|
| 183 | Measurement<br>Air Quality<br>Internal | Status | 1 bit | CRT |
|-----|--|--------|-------|-----|

This object is used to watch internal air quality sensor status. “Enabled” or “Disabled” telegram is transmitted to KNX bus via this object when internal air quality sensor status is changed over device.

DPT: 1.003 (enable)

|     |  |                   |         |     |
|-----|--|-------------------|---------|-----|
| 184 | Measurement<br>Air Quality<br>Internal | Air Quality Value | 2 bytes | CRT |
|-----|--|-------------------|---------|-----|

This object is used to send the measurement value that is measured by the sensor after calibrating it. Each measurement value can be calibrated via “Adjustment factor” parameter or “Calibration” object. Depending on the parameter configuration, the calculated data can be sent to the bus line periodically or according to the amount of change.

DPT: 9.008 (parts/million (ppm))

|     |  |                         |         |    |
|-----|--|-------------------------|---------|----|
| 185 | Measurement<br>Air Quality<br>Internal | Air Quality Calibration | 2 bytes | CW |
|-----|--|-------------------------|---------|----|

This object is used to calibrate the measurement output by measuring the actual measurement value via an external device and then writing this value to the object. When iSwitch+ received the value, calibrate its measurement output automatically.

\*This object is used to calculate the adjustment factor. The adjustment factor can’t be zero or negative. Thus, you mustn’t enter input value with opposite sign than the current measurement to calculate adjustment factor properly.

DPT: 9.008 (parts/million (ppm))

|     |  |               |       |    |
|-----|--|---------------|-------|----|
| 186 | Measurement<br>Air Quality<br>Internal | Alarm - Fault | 1 bit | CT |
|-----|--|---------------|-------|----|

This object is used to send an alarm when the sensor is at fault that causes any reason.

DPT: 1.005 (alarm)

|     |  |             |       |    |
|-----|--|-------------|-------|----|
| 187 | Measurement<br>Air Quality<br>Internal | Alarm - Low | 1 bit | CT |
|-----|--|-------------|-------|----|

“Low Level Alarm” object sends “Alarm” telegram when the measurement value goes below the low-level value and “No Alarm” telegram when the measurement value returns above it.

DPT: 1.005 (alarm)

|     |  |              |       |    |
|-----|--|--------------|-------|----|
| 188 | Measurement<br>Air Quality<br>Internal | Alarm - High | 1 bit | CT |
|-----|--|--------------|-------|----|

“Alarm - High” object sends “Alarm” telegram when the measurement value exceeds the high-level value and “No Alarm” telegram when the measurement value returns below it.

DPT: 1.005 (alarm)

|     |  |                  |                    |    |
|-----|--|------------------|--------------------|----|
| 189 | Measurement<br>Air Quality<br>Internal | Additional Value | 1 bit / 1<br>bytes | CT |
|-----|--|------------------|--------------------|----|

When the measurement value changed, this object sends telegrams with specific type and values according to the related parameters.

DPT: According to parameter selection

#### 5.5.4. Brightness Measurement Objects

| Object Number | Object Name                           | Function | Type  | Flags |
|---------------|---------------------------------------|----------|-------|-------|
| 190           | Measurement<br>Brightness<br>Internal | Disable  | 1 bit | CW    |

This object is used to set the iSwitch+ internal brightness sensor status. “Enabled” or “Disabled” telegram is received via this object.

For example, it will be disabled when an “Enabled” telegram is received from the KNX bus line, and when a “Disabled” telegram is received, the internal brightness sensor will continue the measurement. On disabled, any telegram isn’t transmitted to the KNX bus.

DPT: 1.003 (enable)

|     |                                       |        |       |     |
|-----|---------------------------------------|--------|-------|-----|
| 191 | Measurement<br>Brightness<br>Internal | Status | 1 bit | CRT |
|-----|---------------------------------------|--------|-------|-----|

This object is used to watch internal brightness sensor status. “Enabled” or “Disabled” telegram is transmitted to KNX bus via this object when internal brightness sensor status is changed over device.

DPT: 1.003 (enable)

|     |                                       |                  |         |     |
|-----|---------------------------------------|------------------|---------|-----|
| 192 | Measurement<br>Brightness<br>Internal | Brightness Value | 2 bytes | CRT |
|-----|---------------------------------------|------------------|---------|-----|

This object is used to send the measurement value that is measured by the sensor after calibrating it. Each measurement value can be calibrated via “Adjustment factor” parameter or “Calibration” object. Depending

on the parameter configuration, the calculated data can be sent to the bus line periodically or according to the amount of change.

DPT: 9.004 (lux)

|            |  |                               |                |           |
|------------|--|-------------------------------|----------------|-----------|
| <b>193</b> | <b>Measurement<br/>Brightness<br/>Internal</b> | <b>Brightness Calibration</b> | <b>2 bytes</b> | <b>CW</b> |
|------------|--|-------------------------------|----------------|-----------|

This object is used to calibrate the measurement output by measuring the actual measurement value via an external device and then writing this value to the object. When iSwitch+ received the value, calibrate its measurement output automatically.

\*This object is used to calculate the adjustment factor. The adjustment factor can't be zero or negative. Thus, you mustn't enter input value with opposite sign than the current measurement to calculate adjustment factor properly.

DPT: 9.004 (lux)

|            |  |                      |              |           |
|------------|--|----------------------|--------------|-----------|
| <b>194</b> | <b>Measurement<br/>Brightness<br/>Internal</b> | <b>Alarm - Fault</b> | <b>1 bit</b> | <b>CT</b> |
|------------|--|----------------------|--------------|-----------|

This object is used to send an alarm when the sensor is at fault that causes any reason.

DPT: 1.005 (alarm)

|            |  |                    |              |           |
|------------|--|--------------------|--------------|-----------|
| <b>195</b> | <b>Measurement<br/>Brightness<br/>Internal</b> | <b>Alarm - Low</b> | <b>1 bit</b> | <b>CT</b> |
|------------|--|--------------------|--------------|-----------|

"Low Level Alarm" object sends "Alarm" telegram when the measurement value goes below the low-level value and "No Alarm" telegram when the measurement value returns above it.

DPT: 1.005 (alarm)

|            |  |                     |              |           |
|------------|--|---------------------|--------------|-----------|
| <b>196</b> | <b>Measurement<br/>Brightness<br/>Internal</b> | <b>Alarm - High</b> | <b>1 bit</b> | <b>CT</b> |
|------------|--|---------------------|--------------|-----------|

"Alarm - High" object sends "Alarm" telegram when the measurement value exceeds the high-level value and "No Alarm" telegram when the measurement value returns below it.

DPT: 1.005 (alarm)

|     |                                       |                  |                    |    |
|-----|---------------------------------------|------------------|--------------------|----|
| 197 | Measurement<br>Brightness<br>Internal | Additional Value | 1 bit / 1<br>bytes | CT |
|-----|---------------------------------------|------------------|--------------------|----|

When the measurement value changed, this object sends telegrams with specific type and values according to the related parameters.

DPT: According to parameter selection

## 5.5.5. External Measurement Objects

X: 1 / 2

| Object Number | Object Name               | Function | Type  | Flags |
|---------------|---------------------------|----------|-------|-------|
| 198, 216      | Measurement<br>External X | Disable  | 1 bit | CW    |

This object is used to set the iSwitch+ external X sensor status. “Enabled” or “Disabled” telegram is received via this object.

For example, it will be disabled when an “Enabled” telegram is received from the KNX bus line, and when a “Disabled” telegram is received, the external X sensor will continue the measurement. On disabled, any telegram isn’t transmitted to the KNX bus.

DPT: 1.003 (enable)

|          |                           |        |       |     |
|----------|---------------------------|--------|-------|-----|
| 199, 217 | Measurement<br>External X | Status | 1 bit | CRT |
|----------|---------------------------|--------|-------|-----|

This object is used to watch external X sensor status. “Enabled” or “Disabled” telegram is transmitted to KNX bus via this object when external X sensor status is changed over device.

DPT: 1.003 (enable)

|          |                           |                                      |         |     |
|----------|---------------------------|--------------------------------------|---------|-----|
| 200, 218 | Measurement<br>External X | Temperature Value / Brightness Value | 2 bytes | CRT |
|----------|---------------------------|--------------------------------------|---------|-----|

This object is used to send the measurement value that is measured by the sensor after calibrating it. Each measurement value can be calibrated via “Adjustment factor” parameter or “Calibration” object.

DPT: 9.001 (temperature (°C)) / DPT: 9.004 (lux)

|          |                           |   |         |    |
|----------|---------------------------|---|---------|----|
| 201, 219 | Measurement<br>External X | Temperature Calibration /<br>Brightness Calibration | 2 bytes | CW |
|----------|---------------------------|---|---------|----|

This object is used to calibrate the measurement output by measuring the actual measurement value via an external device and then writing this value to the object. When iSwitch+ received the value, calibrate its measurement output automatically.

\*This object is used to calculate the adjustment factor. The adjustment factor can’t be zero or negative. Thus, you mustn’t enter input value with opposite sign than the current measurement to calculate adjustment factor properly.

DPT: 9.001 (temperature (°C)) / DPT: 9.004 (lux)

|          |                           |               |       |    |
|----------|---------------------------|---------------|-------|----|
| 202, 220 | Measurement<br>External X | Alarm - Fault | 1 bit | CT |
|----------|---------------------------|---------------|-------|----|

This object is used to send an alarm when the sensor is at fault that causes any reason.

DPT: 1.005 (alarm)

|          |                           |             |       |    |
|----------|---------------------------|-------------|-------|----|
| 203, 221 | Measurement<br>External X | Alarm - Low | 1 bit | CT |
|----------|---------------------------|-------------|-------|----|

“Low Level Alarm” object sends “Alarm” telegram when the measurement value goes below the low-level value and “No Alarm” telegram when the measurement value returns above it.

DPT: 1.005 (alarm)

|          |                           |              |       |    |
|----------|---------------------------|--------------|-------|----|
| 204, 222 | Measurement<br>External X | Alarm - High | 1 bit | CT |
|----------|---------------------------|--------------|-------|----|

“Alarm - High” object sends “Alarm” telegram when the measurement value exceeds the high-level value and “No Alarm” telegram when the measurement value returns below it.

DPT: 1.005 (alarm)

|          |                           |                  |                    |    |
|----------|---------------------------|------------------|--------------------|----|
| 205, 221 | Measurement<br>External X | Additional Value | 1 bit / 1<br>bytes | CT |
|----------|---------------------------|------------------|--------------------|----|

When the measurement value changed, this object sends telegrams with specific type and values according to the related parameters.

DPT: According to parameter selection

## 5.6. Calculation Objects

In this section, Calculation X objects are described in the table below. In the first column name of the object, in the second column function name, the third column data type and fourth column the objects flags, information is given.

X: 1 ... 6

| Object Number                | Object Name   | Function | Type  | Flags |
|------------------------------|---------------|----------|-------|-------|
| 214, 222, 230, 238, 246, 254 | Calculation X | Disable  | 1 bit | CW    |

This object is used to set the iSwitch+ calculation X status. “Enabled” or “Disabled” telegram is received via this object.

For example, it will be disabled when an “Enabled” telegram is received from the KNX bus line, and when a “Disabled” telegram is received, the + calculation X will continue the calculation. On disabled, any telegram isn’t transmitted to the KNX bus.

DPT: 1.003 (enable)

| Object Number                | Object Name   | Function | Type  | Flags |
|------------------------------|---------------|----------|-------|-------|
| 215, 223, 231, 239, 247, 255 | Calculation X | Status   | 1 bit | CRT   |

This object is used to watch calculation X status. “Enabled” or “Disabled” telegram is transmitted to KNX bus via this object when calculation X status is changed over device.

DPT: 1.003 (enable)

| Object Number                | Object Name   | Function  | Type            | Flags |
|------------------------------|---------------|---|-----------------|-------|
| 216, 224, 232, 240, 248, 256 | Calculation X | Probe Input Temperature / Probe Input Humidity / Probe Input Brightness / Probe Input Proximity / Probe Input Air Quality / Probe Input Pressure / Probe Input Wind Speed | 1 bit / 2 bytes | CW    |

This object is used to receive the sensor value from the KNX bus line. This value can be used as a single sensor source or mixing part for the value calculation.

DPT: According to parameter selection

| Object Number                | Object Name   | Function           | Type  | Flags |
|------------------------------|---------------|--------------------|-------|-------|
| 217, 225, 233, 241, 249, 257 | Calculation X | Probe Surveillance | 1 bit | CRT   |

This object is used to send alarm if new value is not received a long time set “KNX probe surveillance time” parameter.

DPT: 1.018 (occupancy)

|                                 |               |   |         |     |
|---------------------------------|---------------|---|---------|-----|
| 218, 226, 234,<br>242, 250, 258 | Calculation X | Output Temperature / Output Humidity /<br>Output Brightness / Output Proximity / Output<br>Air Quality / Output Pressure / Output Wind<br>Speed | 2 bytes | CRT |
|---------------------------------|---------------|---|---------|-----|

This object is used to send the calculation output value that is calculated by the calculation X channel. Depending on the parameter configuration, the calculated data can be sent to the bus line periodically or according to the amount of change.

DPT: According to parameter selection

|                                 |               |             |       |     |
|---------------------------------|---------------|-------------|-------|-----|
| 219, 227, 235,<br>243, 251, 259 | Calculation X | Alarm - Low | 1 bit | CRT |
|---------------------------------|---------------|-------------|-------|-----|

“Low Level Alarm” object sends “Alarm” telegram when the calculation output value goes below the low-level value and “No Alarm” telegram when the calculation output value returns above it.

DPT: 1.005 (alarm)

|                                 |               |              |       |     |
|---------------------------------|---------------|--------------|-------|-----|
| 220, 228, 236,<br>244, 252, 260 | Calculation X | Alarm - High | 1 bit | CRT |
|---------------------------------|---------------|--------------|-------|-----|

“Alarm - High” object sends “Alarm” telegram when the calculation output value exceeds the high-level value and “No Alarm” telegram when the calculation output value returns below it.

DPT: 1.005 (alarm)

## 5.7. Thermostat Objects

In this section, Thermostat objects are described in the table below. In the first column name of the object, in the second column function name, the third column data type and fourth column the objects flags, information is given.

X: 1 ... 5, Y: 1 / 2

| Object Number | Object Name | Function             | Type  | Flags     |
|---------------|-------------|----------------------|-------|-----------|
| 262           | Thermostat  | Thermostat Disabling | 1 bit | CW / CRT* |

This object is used to set the iSwitch+ thermostat status. “Enabled” or “Disabled” telegram is received via this object.

For example, it will be disabled when an “Enabled” telegram is received from the KNX bus line, and when a “Disabled” telegram is received, the iSwitch+ thermostat will continue working.

\*This object is used as feedback object in thermostat slave mode.

DPT: 1.003 (enable)

|     |            |                   |       |           |
|-----|------------|-------------------|-------|-----------|
| 263 | Thermostat | Thermostat Status | 1 bit | CRT / CW* |
|-----|------------|-------------------|-------|-----------|

This object is used to watch thermostat status. “Enabled” or “Disabled” telegram is transmitted to KNX bus via this object when thermostat status is changed over device.

\*This object is used as input object in thermostat slave mode.

DPT: 1.003 (enable)

|     |            |                           |        |           |
|-----|------------|---------------------------|--------|-----------|
| 266 | Thermostat | Thermostat Operation Mode | 1 byte | CW / CRT* |
|-----|------------|---------------------------|--------|-----------|

This object switches over the operating modes with a 1-byte value.

\*This object is used as feedback object in thermostat slave mode.

DPT: 20.102 (HVAC mode)

|     |            |                                  |        |    |
|-----|------------|----------------------------------|--------|----|
| 267 | Thermostat | Thermostat Operation Mode Forced | 1 byte | CW |
|-----|------------|----------------------------------|--------|----|

This object is used to set operation mode of thermostat. Its priority is highest including thermostat energy saving functions except window contact and the mode cannot be changed until “Auto” is received via this object. If “Auto” is received, the operation mode is back the HVAC mode that before enter the forced operation mode.

DPT: 20.102 (HVAC mode)

|     |            |                                  |        |           |
|-----|------------|----------------------------------|--------|-----------|
| 268 | Thermostat | Thermostat Operation Mode Status | 1 byte | CRT / CW* |
|-----|------------|----------------------------------|--------|-----------|

This object indicates the status of the operating mode with a 1-byte value.

\*This object is used as input object in thermostat slave mode.

DPT: 20.102 (HVAC mode)

|     |            |                          |       |    |
|-----|------------|--------------------------|-------|----|
| 269 | Thermostat | Operation Mode [Comfort] | 1 bit | CW |
|-----|------------|--------------------------|-------|----|

The Comfort mode activation command is sent via this object. If “On” telegram is received via this object, operation mode is changed as Comfort. If active operation mode is Comfort and “Off” telegram is received via this object, the operating mode is changed as Auto. If weekly program isn’t active, the operating mode isn’t changed and keep current state.

DPT: 1.001 (switch)

|     |            |                          |       |    |
|-----|------------|--------------------------|-------|----|
| 270 | Thermostat | Operation Mode [Standby] | 1 bit | CW |
|-----|------------|--------------------------|-------|----|

The Standby mode activation command is sent via this object. If “On” telegram is received via this object, operation mode is changed as Standby. If active operation mode is Standby and “Off” telegram is received via this object, the operating mode is changed as Auto. If weekly program isn’t active, the operating mode isn’t changed and keep current state.

DPT: 1.001 (switch)

|     |            |                          |       |    |
|-----|------------|--------------------------|-------|----|
| 271 | Thermostat | Operation Mode [Economy] | 1 bit | CW |
|-----|------------|--------------------------|-------|----|

The Economy mode activation command is sent via this object. If “On” telegram is received via this object, operation mode is changed as Economy. If active operation mode is Economy and “Off” telegram is received via this object, the operating mode is changed as Auto. If weekly program isn’t active, the operating mode isn’t changed and keep current state.

DPT: 1.001 (switch)

|     |            |                             |       |    |
|-----|------------|-----------------------------|-------|----|
| 272 | Thermostat | Operation Mode [Protection] | 1 bit | CW |
|-----|------------|-----------------------------|-------|----|

The Protection mode activation command is sent via this object. If “On” telegram is received via this object, operation mode is changed as Protection. If active operation mode is Protection and “Off” telegram is received via this object, the operating mode is changed as Auto. If weekly program isn’t active, the operating mode isn’t changed and keep current state.

DPT: 1.001 (switch)

|            |                   |  |              |                  |
|------------|-------------------|--|--------------|------------------|
| <b>273</b> | <b>Thermostat</b> | <b>Thermostat Heating/Cooling Switchover</b> | <b>1 bit</b> | <b>CW / CRT*</b> |
|------------|-------------------|--|--------------|------------------|

This object is used to change over the heating/cooling modes.

\*This object is used as feedback object in thermostat slave mode.

DPT: 1.100 (cooling/heating)

|            |                   |  |              |                  |
|------------|-------------------|--|--------------|------------------|
| <b>274</b> | <b>Thermostat</b> | <b>Thermostat Heating/Cooling Status</b> | <b>1 bit</b> | <b>CRT / CW*</b> |
|------------|-------------------|--|--------------|------------------|

Heating/cooling status information is indicated via this object.

\*This object is used as input object in thermostat slave mode.

DPT: 1.100 (cooling/heating)

|            |                   |   |              |           |
|------------|-------------------|---|--------------|-----------|
| <b>275</b> | <b>Thermostat</b> | <b>Thermostat Heating Control Disabling</b> | <b>1 bit</b> | <b>CW</b> |
|------------|-------------------|---|--------------|-----------|

This object activates or deactivates the heating system.

DPT: 1.003 (enable)

|            |                   |   |              |                  |
|------------|-------------------|---|--------------|------------------|
| <b>276</b> | <b>Thermostat</b> | <b>Thermostat Heating Control Running</b> | <b>1 bit</b> | <b>CRT / CW*</b> |
|------------|-------------------|---|--------------|------------------|

This object is used to inform about the heating control. If the heating control is active and the control value is higher than zero, ON telegram is transmitted to KNX bus. If the heating control is not active and the control value is zero, OFF telegram is transmitted to KNX bus.

\*This object is used as input object in thermostat slave mode.

DPT: 1.002 (boolean)

|            |                   |  |                       |            |
|------------|-------------------|--|-----------------------|------------|
| <b>277</b> | <b>Thermostat</b> | <b>Thermostat Heating Value - Thermostat Heating/Cooling Value</b> | <b>1 bit / 1 byte</b> | <b>CRT</b> |
|------------|-------------------|--|-----------------------|------------|

The output value of thermostat control is transmitted via the object.

DPT: 1.001 (switch) / 5.004 (percentage (0...255%))

|            |                   |   |              |           |
|------------|-------------------|---|--------------|-----------|
| <b>278</b> | <b>Thermostat</b> | <b>Thermostat Heating Value Request</b> | <b>1 bit</b> | <b>CW</b> |
|------------|-------------------|---|--------------|-----------|

This object is used to get the output value of heating controller. If "Acknowledge command" telegram is received via this object, current value of the heating controller is transmitted to KNX bus.

DPT: 1.016 (acknowledge)

|            |                   |   |              |           |
|------------|-------------------|---|--------------|-----------|
| <b>279</b> | <b>Thermostat</b> | <b>Thermostat Cooling Control Disabling</b> | <b>1 bit</b> | <b>CW</b> |
|------------|-------------------|---|--------------|-----------|

This object activates or deactivates the cooling system.

DPT: 1.003 (enable)

|     |            |                                    |       |           |
|-----|------------|------------------------------------|-------|-----------|
| 280 | Thermostat | Thermostat Cooling Control Running | 1 bit | CRT / CW* |
|-----|------------|------------------------------------|-------|-----------|

This object is used to inform about the cooling control. If the cooling control is active and the control value is higher than zero, ON telegram is transmitted to KNX bus. If the cooling control is not active and the control value is zero, OFF telegram is transmitted to KNX bus.

\*This object is used as input object in thermostat slave mode.

DPT: 1.002 (boolean)

|     |            |                          |                |     |
|-----|------------|--------------------------|----------------|-----|
| 281 | Thermostat | Thermostat Cooling Value | 1 bit / 1 byte | CRT |
|-----|------------|--------------------------|----------------|-----|

The output value of thermostat cooling control is transmitted via the object.

DPT: 1.001 (switch) / 5.004 (percentage (0...255%))

|     |            |                                  |       |    |
|-----|------------|----------------------------------|-------|----|
| 282 | Thermostat | Thermostat Cooling Value Request | 1 bit | CW |
|-----|------------|----------------------------------|-------|----|

This object is used to get the output value of cooling controller. If "Trigger" telegram is received via this object, current value of the heating controller is transmitted to KNX bus.

DPT: 1.016 (acknowledge)

|     |            |   |       |    |
|-----|------------|---|-------|----|
| 283 | Thermostat | Thermostat Additional Heating Control Disabling | 1 bit | CW |
|-----|------------|---|-------|----|

This object activates or deactivates the additional heating system.

DPT: 1.003 (enable)

|     |            |   |       |     |
|-----|------------|---|-------|-----|
| 284 | Thermostat | Thermostat Additional Heating Control Running | 1 bit | CRT |
|-----|------------|---|-------|-----|

This object is used to inform about the additional heating control. If the additional heating control is active and the control value is higher than zero, ON telegram is transmitted to KNX bus. If the additional heating control is not active and the control value is zero, OFF telegram is transmitted to KNX bus.

DPT: 1.002 (boolean)

|     |            |                                     |                |     |
|-----|------------|-------------------------------------|----------------|-----|
| 285 | Thermostat | Thermostat Additional Heating Value | 1 bit / 1 byte | CRT |
|-----|------------|-------------------------------------|----------------|-----|

The output value of thermostat additional heating control is transmitted via the object.

DPT: 1.001 (switch) / 5.004 (percentage (0...255%))

|     |            |                       |                                |       |    |
|-----|------------|-----------------------|--------------------------------|-------|----|
| 286 | Thermostat | Thermostat<br>Request | Additional<br>Heating<br>Value | 1 bit | CW |
|-----|------------|-----------------------|--------------------------------|-------|----|

This object is used to get the output value of additional heating controller. If “Trigger” telegram is received via this object, current value of the heating controller is transmitted to KNX bus.

DPT: 1.016 (acknowledge)

|     |            |                         |                                  |       |    |
|-----|------------|-------------------------|----------------------------------|-------|----|
| 287 | Thermostat | Thermostat<br>Disabling | Additional<br>Cooling<br>Control | 1 bit | CW |
|-----|------------|-------------------------|----------------------------------|-------|----|

This object activates or deactivates the additional cooling system.

DPT: 1.003 (enable)

|     |            |                       |                                  |       |     |
|-----|------------|-----------------------|----------------------------------|-------|-----|
| 288 | Thermostat | Thermostat<br>Running | Additional<br>Cooling<br>Control | 1 bit | CRT |
|-----|------------|-----------------------|----------------------------------|-------|-----|

This object is used to inform about the additional cooling control. If the additional cooling control is active and the control value is higher than zero, ON telegram is transmitted to KNX bus. If the additional cooling control is not active and the control value is zero, OFF telegram is transmitted to KNX bus.

DPT: 1.002 (boolean)

|     |            |  |                   |     |
|-----|------------|--|-------------------|-----|
| 289 | Thermostat | Thermostat<br>Additional<br>Cooling<br>Value | 1 bit / 1<br>byte | CRT |
|-----|------------|--|-------------------|-----|

The output value of thermostat additional cooling control is transmitted via the object.

DPT: 1.001 (switch) / 5.004 (percentage (0...255%))

|     |            |                       |                                |       |    |
|-----|------------|-----------------------|--------------------------------|-------|----|
| 290 | Thermostat | Thermostat<br>Request | Additional<br>Cooling<br>Value | 1 bit | CW |
|-----|------------|-----------------------|--------------------------------|-------|----|

This object is used to get the output value of additional cooling controller. If “Trigger” telegram is received via this object, current value of the heating controller is transmitted to KNX bus.

DPT: 1.016 (acknowledge)

|     |            |   |       |              |
|-----|------------|---|-------|--------------|
| 291 | Thermostat | Room<br>Temperature<br>Output (C) - Room<br>Temperature<br>Output (F) | 1 bit | CRT /<br>CW* |
|-----|------------|---|-------|--------------|

This object is used to inform about the temperature value that room controller uses.

\*This object is used as input object if thermostat temperature source is selected as “Temperature object”.

DPT: 9.001 (temperature (°C)) / 9.027 (temperature difference (K))

|     |            |                 |         |           |
|-----|------------|-----------------|---------|-----------|
| 292 | Thermostat | Actual Setpoint | 2 bytes | CRT / CW* |
|-----|------------|-----------------|---------|-----------|

The pre-configured setpoint temperature is obtained with this object.

\*This object is used as input object in thermostat slave mode.

DPT: According to parameter selection

|     |            |                 |         |           |
|-----|------------|-----------------|---------|-----------|
| 293 | Thermostat | Manual Setpoint | 2 bytes | CW / CRT* |
|-----|------------|-----------------|---------|-----------|

The setpoint temperature is configured manually with this object. If HVAC mode is Build Protection, the setpoint can't be changed via this object.

If the difference between the active setpoint and received value is higher than the "Manual setpoint range" parameter, Manual Setpoint value is set maximum or minimum limit value according to "Manual setpoint range" parameter.

\*This object is used as feedback object in thermostat slave mode.

DPT: According to parameter selection

|     |            |                       |       |    |
|-----|------------|-----------------------|-------|----|
| 294 | Thermostat | Manual Setpoint Reset | 1 bit | CW |
|-----|------------|-----------------------|-------|----|

The setpoint temperature that is desired to configure manually can be reset with this object.

DPT: 1.015 (reset)

|     |            |                                      |         |    |
|-----|------------|--------------------------------------|---------|----|
| 295 | Thermostat | Heating Comfort Setpoint Temperature | 2 bytes | CW |
|-----|------------|--------------------------------------|---------|----|

The setpoint temperature value for heating comfort mode is configured with this object.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|     |            |                                      |         |    |
|-----|------------|--------------------------------------|---------|----|
| 296 | Thermostat | Heating Standby Setpoint Temperature | 2 bytes | CW |
|-----|------------|--------------------------------------|---------|----|

The setpoint temperature value for heating standby mode is configured with this object.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|     |            |                                      |         |    |
|-----|------------|--------------------------------------|---------|----|
| 297 | Thermostat | Heating Economy Setpoint Temperature | 2 bytes | CW |
|-----|------------|--------------------------------------|---------|----|

The setpoint temperature value for heating economy mode is configured with this object.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|     |            |   |         |    |
|-----|------------|---|---------|----|
| 298 | Thermostat | Heating Protection Setpoint Temperature | 2 bytes | CW |
|-----|------------|---|---------|----|

The setpoint temperature value for heating protection mode is configured with this object.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|     |            |                                      |         |    |
|-----|------------|--------------------------------------|---------|----|
| 299 | Thermostat | Cooling Comfort Setpoint Temperature | 2 bytes | CW |
|-----|------------|--------------------------------------|---------|----|

The setpoint temperature value for cooling comfort mode is configured with this object.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|     |            |                                      |         |    |
|-----|------------|--------------------------------------|---------|----|
| 300 | Thermostat | Cooling Standby Setpoint Temperature | 2 bytes | CW |
|-----|------------|--------------------------------------|---------|----|

The setpoint temperature value for cooling standby mode is configured with this object.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|     |            |                                      |         |    |
|-----|------------|--------------------------------------|---------|----|
| 301 | Thermostat | Cooling Economy Setpoint Temperature | 2 bytes | CW |
|-----|------------|--------------------------------------|---------|----|

The setpoint temperature value for cooling economy mode is configured with this object.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|     |            |   |         |    |
|-----|------------|---|---------|----|
| 302 | Thermostat | Cooling Protection Setpoint Temperature | 2 bytes | CW |
|-----|------------|---|---------|----|

The setpoint temperature value for cooling protection mode is configured with this object.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|     |            |                        |       |    |
|-----|------------|------------------------|-------|----|
| 303 | Thermostat | Fan Controller Disable | 1 bit | CW |
|-----|------------|------------------------|-------|----|

This object is used to set the iSwitch+ fan controller status. “Enabled” or “Disabled” telegram is received via this object.

For example, it will be disabled when an “Enabled” telegram is received from the KNX bus line, and when a “Disabled” telegram is received, the iSwitch+ fan controller will continue working.

DPT: 1.003 (enable)

|     |            |                       |       |     |
|-----|------------|-----------------------|-------|-----|
| 304 | Thermostat | Fan Controller Status | 1 bit | CWT |
|-----|------------|-----------------------|-------|-----|

This object is used to watch fan controller status. “Enabled” or “Disabled” telegram is transmitted to KNX bus via this object when fan controller status is changed over device.

DPT: 1.003 (enable)

|     |            |                             |       |    |
|-----|------------|-----------------------------|-------|----|
| 305 | Thermostat | Fan Controller Working Mode | 1 bit | CW |
|-----|------------|-----------------------------|-------|----|

This object is used to switch over to automatic or manual fan speed control mode.

DPT: 1.001 (switch)

|     |            |                                    |       |     |
|-----|------------|------------------------------------|-------|-----|
| 306 | Thermostat | Fan Controller Working Mode Status | 1 bit | CRT |
|-----|------------|------------------------------------|-------|-----|

This object indicates the manual / automatic fan operating mode with 1 bit value.

DPT: 1.001 (switch)

|            |                   |   |               |            |
|------------|-------------------|---|---------------|------------|
| <b>308</b> | <b>Thermostat</b> | <b>Fan Controller Proportional Output</b> | <b>1 byte</b> | <b>CRT</b> |
|------------|-------------------|---|---------------|------------|

This object is used to send the output value of the fan proportional controller.

DPT: 5.001(percentage (0...100%))

|            |                   |                                   |              |           |
|------------|-------------------|-----------------------------------|--------------|-----------|
| <b>308</b> | <b>Thermostat</b> | <b>Fan Controller Manual Step</b> | <b>1 bit</b> | <b>CW</b> |
|------------|-------------------|-----------------------------------|--------------|-----------|

This object is used to increase or decrease the fan speed

DPT: 1.007 (step) / 1.008 (up/down)

|            |                   |                                    |               |           |
|------------|-------------------|------------------------------------|---------------|-----------|
| <b>309</b> | <b>Thermostat</b> | <b>Fan Controller Manual Stage</b> | <b>1 byte</b> | <b>CW</b> |
|------------|-------------------|------------------------------------|---------------|-----------|

This object allows the manual fan speed to be controlled with 1-byte value.

DPT: 5.100(fan stage (0...255))

|            |                   |                                      |               |            |
|------------|-------------------|--------------------------------------|---------------|------------|
| <b>310</b> | <b>Thermostat</b> | <b>Fan Controller Speed (1 Byte)</b> | <b>1 byte</b> | <b>CRT</b> |
|------------|-------------------|--------------------------------------|---------------|------------|

This object allows the fan speed to be controlled with 1-byte value.

DPT: 5.010 (counter pulses (0...255))

|            |                   |   |               |            |
|------------|-------------------|---|---------------|------------|
| <b>311</b> | <b>Thermostat</b> | <b>Fan Controller Speed Feedback Input (1 Byte)</b> | <b>1 byte</b> | <b>CWU</b> |
|------------|-------------------|---|---------------|------------|

This object waits the fan speed feedback with a 1-byte value.

DPT: 5.010 (counter pulses (0...255))

|                                |                   |                    |              |            |
|--------------------------------|-------------------|--------------------|--------------|------------|
| <b>312, 313, 314, 315, 316</b> | <b>Thermostat</b> | <b>Fan Level X</b> | <b>1 bit</b> | <b>CRT</b> |
|--------------------------------|-------------------|--------------------|--------------|------------|

This object indicates the Fan Level X value with a 1-bit value.

DPT: 1.001 (switch)

|                                |                   |                                   |              |            |
|--------------------------------|-------------------|-----------------------------------|--------------|------------|
| <b>317, 318, 319, 320, 321</b> | <b>Thermostat</b> | <b>Fan Level X Feedback Input</b> | <b>1 bit</b> | <b>CWU</b> |
|--------------------------------|-------------------|-----------------------------------|--------------|------------|

This object indicates the Fan Level X status with a 1-bit value.

DPT: 1.001 (switch)

|                 |                   |   |              |           |
|-----------------|-------------------|---|--------------|-----------|
| <b>322, 323</b> | <b>Thermostat</b> | <b>Energy Saving – Window Contact Y</b> | <b>1 bit</b> | <b>CW</b> |
|-----------------|-------------------|---|--------------|-----------|

This object is used to activate window contact function.

DPT: 1.001 (switch)

|                 |                   |   |              |           |
|-----------------|-------------------|---|--------------|-----------|
| <b>324, 325</b> | <b>Thermostat</b> | <b>Energy Saving – Presence Input Y</b> | <b>1 bit</b> | <b>CW</b> |
|-----------------|-------------------|---|--------------|-----------|

This object is used to activate presence input function.

DPT: 1.001 (switch)

|                 |                   |                                      |              |           |
|-----------------|-------------------|--------------------------------------|--------------|-----------|
| <b>326, 327</b> | <b>Thermostat</b> | <b>Energy Saving – Card Holder Y</b> | <b>1 bit</b> | <b>CW</b> |
|-----------------|-------------------|--------------------------------------|--------------|-----------|

This object is used to activate card holder function.

DPT: 1.001 (switch)

|            |                   |   |                |           |
|------------|-------------------|---|----------------|-----------|
| <b>328</b> | <b>Thermostat</b> | <b>Temperature Limit Heating Source</b> | <b>2 bytes</b> | <b>CW</b> |
|------------|-------------------|---|----------------|-----------|

This group object receives the limit temperature for heating stage. The temperature value received here is used to evaluate the limit temperature. The limit becomes active when the temperature set in the parameter is exceeded.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|            |                   |   |                |           |
|------------|-------------------|---|----------------|-----------|
| <b>329</b> | <b>Thermostat</b> | <b>Temperature Limit Cooling Source</b> | <b>2 bytes</b> | <b>CW</b> |
|------------|-------------------|---|----------------|-----------|

This group object receives the limit temperature for cooling stage. The temperature value received here is used to evaluate the limit temperature. The limit becomes active when the temperature set in the parameter is fallen below.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|            |                   |  |                |           |
|------------|-------------------|--|----------------|-----------|
| <b>330</b> | <b>Thermostat</b> | <b>Temperature Limit Additional Heating Source</b> | <b>2 bytes</b> | <b>CW</b> |
|------------|-------------------|--|----------------|-----------|

This group object receives the limit temperature for additional heating stage. The temperature value received here is used to evaluate the limit temperature. The limit becomes active when the temperature set in the parameter is exceeded.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|            |                   |  |                |           |
|------------|-------------------|--|----------------|-----------|
| <b>331</b> | <b>Thermostat</b> | <b>Temperature Limit Additional Cooling Source</b> | <b>2 bytes</b> | <b>CW</b> |
|------------|-------------------|--|----------------|-----------|

This group object receives the limit temperature for additional cooling stage. The temperature value received here is used to evaluate the limit temperature. The limit becomes active when the temperature set in the parameter is fallen below.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|     |            |      |         |    |
|-----|------------|------|---------|----|
| 332 | Thermostat | Time | 3 bytes | CW |
|-----|------------|------|---------|----|

This object is used to set date and time. Date and time are used thermostat weekly program. If weekly program is active but any telegram hasn't received over "Time" object yet, the weekly program doesn't run.

DPT: 1.008 (time of day)

## 5.8. LCD Objects

In this section, LCD objects are described in the table below. In the first column name of the object, in the second column function name, the third column data type and fourth column the objects flags, information is given.

X: 1 ... 5

| Object Number | Object Name | Function   | Type   | Flags |
|---------------|-------------|------------|--------|-------|
| 332           | LCD         | Brightness | 1 byte | CW    |

This object is used to configure the LCD's brightness.

DPT: 5.001 (percentage (0...100%))

|     |     |                  |       |    |
|-----|-----|------------------|-------|----|
| 333 | LCD | Indicator On/Off | 1 bit | CW |
|-----|-----|------------------|-------|----|

This object is used to control the "On" and "Off" indicators that are displayed on the LCD screen.

DPT: 1.001 (switch)

|     |     |                     |         |    |
|-----|-----|---------------------|---------|----|
| 335 | LCD | Outdoor Temperature | 2 bytes | CW |
|-----|-----|---------------------|---------|----|

This object is used to display outdoor temperature values on the LCD screen.

DPT: 9.001 (temperature (°C)) / DPT: 9.027 (temperature (°F))

|     |     |                      |       |     |
|-----|-----|----------------------|-------|-----|
| 336 | LCD | Fan Indicator Status | 1 bit | CWU |
|-----|-----|----------------------|-------|-----|

This object is used to watch fan controller status of the master device. "Enabled" or "Disabled" telegram is received via this object.

DPT: 1.003 (enable)

|     |     |                           |       |     |
|-----|-----|---------------------------|-------|-----|
| 337 | LCD | Fan Indicator Auto/Manual | 1 bit | CWU |
|-----|-----|---------------------------|-------|-----|

This object is used to watch fan working mode of the master device. "Enabled" or "Disabled" telegram is received via this object.

DPT: 1.003 (enable)

|     |     |                              |        |     |
|-----|-----|------------------------------|--------|-----|
| 338 | LCD | Fan Indicator Level (1-byte) | 1 byte | CWU |
|-----|-----|------------------------------|--------|-----|

This object is used to watch fan speed of the master device.

DPT: According to parameter selection

|                        |     |                       |       |     |
|------------------------|-----|-----------------------|-------|-----|
| 339 340 341<br>342 343 | LCD | Fan Indicator Level X | 1 bit | CWU |
|------------------------|-----|-----------------------|-------|-----|

This object is used to watch the individual levels of fan speed of the master device.

DPT: 1.001 (switch)

---

## CONTACT INFORMATION

---

### THE INTERRA WEBSITE

Interra provides documentation support via our website [www.interratechnology.com](http://www.interratechnology.com). This website is used as a means to make files and information easily available to customers. Accessible by using your favourite Internet browser, the website contains the following information:

- Information about our products and projects.
- Overview of Interra company and values.
- Product Support: Datasheets, product manuals, application descriptions, latest software releases, ETS databases and archived software.

### EUROPE, Turkey

Interra

Cumhuriyet Mah. Kartal Cad. Interra R&D Center  
No:95/1 Kartal/İstanbul

Tel: +90 (216) 326 26 40 Fax: +90 (216) 324 25 03

Web adress: <http://www.interratechnology.com>